

Mattel CGN30

Mattel CGN30 Hot Wheels Star Wars Galactic Battle Play Set Instruction Manual

Model: CGN30

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Mattel CGN30 Hot Wheels Star Wars Galactic Battle Play Set. Please read these instructions carefully before use to ensure proper setup and enjoyment of the product.

Safety Warning: This product is not suitable for children under 3 years due to small parts which may present a choking hazard. Recommended age: 5-8 years.

PACKAGE CONTENTS

Before beginning assembly, ensure all components are present:

- Galactic Battle Play Set components
- 1 Hot Wheels Die-Cast Star Wars X-Wing Fighter vehicle
- Instruction sheet (this document)

If any parts are missing or damaged, please contact Mattel customer support.

SETUP AND ASSEMBLY

Follow these steps to assemble your Hot Wheels Star Wars Galactic Battle Play Set:

1. **Unpack Components:** Carefully remove all pieces from the packaging.
2. **Connect Base Sections:** Join the main base sections of the play set. Ensure they click securely into place.
3. **Attach Structures:** Mount the taller structures, including the Imperial Star Destroyer section and the Death Star-themed turret, onto the designated slots on the base.
4. **Install Launch Mechanism:** Secure the orange launch mechanism and its associated arm. This is used to propel the X-Wing Fighter.
5. **Position Target Elements:** Place the TIE Fighter targets and other interactive elements as shown in

the diagrams.



Figure 1: Overview of the fully assembled Galactic Battle Play Set.

This image displays the complete play set, featuring the Imperial Star Destroyer section, the Death Star-themed turret, and the X-Wing Fighter launch mechanism, ready for action.




Figure 2: Detail of the X-Wing Fighter launch mechanism.

A hand is shown engaging the orange launch lever, demonstrating how to prepare the X-Wing Fighter for launch towards the targets.

OPERATING INSTRUCTIONS

Engage in Star Wars battles with your Hot Wheels play set:

1. **Load the X-Wing:** Place the included Hot Wheels Die-Cast Star Wars X-Wing Fighter onto the designated launch track.
2. **Prepare for Launch:** Pull back the orange launch mechanism until it locks into position.
3. **Aim and Fire:** Adjust the angle of the launch arm if possible (refer to specific play set features). Press the launch button or release mechanism to propel the X-Wing Fighter.
4. **Target TIE Fighters:** Aim to hit the TIE Fighter targets positioned around the play set to simulate destroying enemy ships. Successful hits may trigger interactive features or cause parts of the Imperial Star Destroyer to "explode" or detach.




Figure 3: X-Wing Fighter engaging the Imperial Star Destroyer.

This image illustrates the Hot Wheels X-Wing Fighter in motion, targeting the vulnerable sections of the Imperial Star Destroyer, which appears to be breaking apart.



Figure 4: X-Wing Fighter on the launch track, aiming at distant targets.

The X-Wing Fighter is shown positioned on its clear launch arm, ready to be propelled across the play set towards the TIE Fighter targets and other interactive elements.

MAINTENANCE AND CARE

To ensure the longevity of your play set:

- **Cleaning:** Wipe the play set with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the play set in a cool, dry place away from direct sunlight to prevent material degradation and color fading.
- **Inspection:** Periodically check for any loose or damaged parts. Discontinue use if significant damage is found and contact customer support.

TROUBLESHOOTING

If you encounter issues with your play set, consider the following:

- **Vehicle Not Launching:**
 - Ensure the X-Wing Fighter is correctly seated on the launch track.
 - Verify the launch mechanism is fully pulled back and locked before attempting to release.
 - Check for any obstructions in the launch path.
- **Parts Not Connecting Securely:**
 - Ensure all connectors are aligned properly.
 - Apply gentle, even pressure until parts click into place. Do not force components.

For persistent issues, please refer to the customer support information.

SPECIFICATIONS

Feature	Detail
Model Number	CGN30
Brand	Mattel
Product Dimensions (L x W x H)	45.72 x 9.53 x 30.48 cm (17.99 x 3.75 x 12 inches)
Product Weight	1.06 kilograms (2.34 lbs)
Recommended Age	5 - 8 years
Material	Plastic (PCV)
Scale	1:64 (for included vehicle)
Batteries Required	No
Included Components	Toy Car (X-Wing Fighter)

WARRANTY AND SUPPORT

Mattel products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the documentation included with your purchase or visit the official Mattel website. For customer support, questions, or to report missing/damaged parts, please contact Mattel customer service through their official channels. Contact information can typically be found on the product packaging or the Mattel website.

Online Resources: [Visit the Mattel Store on Amazon](#)