

[Manuals.plus](#) /

> [adorne](#) /

> adorne AWP1G2WHW10 1-Gang Gloss White-on-White Wall Plate Instruction Manual

adorne AWP1G2WHW10

adorne AWP1G2WHW10 1-Gang Gloss White-on-White Wall Plate Instruction Manual

Brand: adorne | Model: AWP1G2WHW10

1. PRODUCT OVERVIEW

The adorne AWP1G2WHW10 is a 1-Gang Gloss White-on-White Wall Plate designed to provide a sleek, screwless finish for your adorne electrical devices. This wall plate is part of the innovative adorne collection by Legrand, offering a modern aesthetic and easy installation for various electrical configurations.




Image 1: The adorne AWP1G2WHW10 1-Gang Gloss White-on-White Wall Plate.

2. FEATURES

- **Screwless Design:** Features a clean, modern look with no visible screws, ideal for contemporary interiors.
- **White-on-White Finish:** Specifically designed with a gloss white front and a white backer for a cohesive, all-white appearance.
- **Versatile Compatibility:** Perfectly sized to accommodate two Half-Size USB Outlets, a single Pop-Out or Standard Outlet, or any adorne Switch or Dimmer Switch.
- **Easy Installation:** Snaps easily into the existing metal frame, fitting over standard electrical boxes.
- **Modular System:** Part of the adorne modular system, which simplifies device alignment and improves fit and finish in multi-gang installations.



Image 2: Illustration of the adorne modular system, showing how devices and wall plates combine.

3. INSTALLATION INSTRUCTIONS

Before beginning installation, ensure the power to the electrical box is turned off at the circuit breaker to prevent electrical shock. This wall plate is designed for use with adorne collection devices and frames.

3.1 Understanding Gang Count

Gang count refers to the width of your electrical box and cover. A 1-gang configuration is for a single switch or stacked outlet. This AWP1G2WHW10 wall plate is a 1-gang plate.





Image 3: Visual guide to understanding gang counts for wall plates.

3.2 Step-by-Step Installation

- 1. Prepare the Electrical Box:** Ensure the existing electrical box is properly installed and wired according to local electrical codes.
- 2. Install the adorne Frame:** Mount the adorne metal frame (sold separately with adorne devices) into the electrical box using the provided screws. Ensure the frame is securely fastened and grounded.

3. **Install the adorne Device:** Snap your chosen adorne switch, dimmer, or outlet into the metal frame. The modular system ensures proper alignment.
4. **Attach the Wall Plate:** Align the AWP1G2WHW10 wall plate over the installed device and frame. Gently press the wall plate onto the frame until it snaps securely into place. No screws are required for attaching the wall plate itself.

HOW TO INSTALL *the adorne® collection*



1
FITS ALL
ELECTRICAL BOXES

+

**REQUIRES
ONE TOOL**

+

15
AND ABOUT
15 MINUTES

legrand®

Image 4: Visual steps for installing an adorne wall plate, including the frame and device.

WALL PLATE DIMENSIONS

packaged with a mounting frame to enable easy installation when paired with a device. plate are screwless - simply snap onto the included metal frame



Image 5: An adorne wall plate with a switch, showcasing the screwless design.

3.3 Installation Video

For a visual guide on installing adorne wall plates, please watch the official product video below.



Video 1: Official Legrand adorne Wall Plates promotional video, demonstrating installation and various styles.

4. OPERATION

The adorne AWP1G2WHW10 wall plate functions as a decorative cover for your adorne electrical devices. Once installed, it provides a finished and integrated appearance. The operation of the underlying switch, dimmer, or outlet is independent of the wall plate and follows the instructions provided with that specific adorne device.

5. MAINTENANCE

To maintain the appearance of your adorne wall plate, clean it periodically with a soft, damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish. Ensure the power is off before cleaning any electrical components.

6. TROUBLESHOOTING

- **Wall Plate Does Not Snap On:** Ensure the adorne metal frame is correctly installed and flush with the wall. Check for any obstructions.
- **Wall Plate Appears Loose:** Verify that the adorne metal frame is securely tightened to the electrical box. The wall plate should snap firmly onto the frame.
- **Electrical Device Not Functioning:** This issue is typically related to the wiring of the adorne device itself, not the wall plate. Refer to the instruction manual for your specific adorne switch, dimmer, or outlet, and ensure all electrical connections are secure and power is restored at the circuit breaker.

7. SPECIFICATIONS

Attribute	Value
Brand	adorne
Model Number	AWP1G2WHW10
Color	Gloss White on White
Material	Plastic
Product Dimensions (W x H)	3.45"W x 5.13"H
Finish Type	Gloss
Configuration	1-gang
Installation Type	Wall-Mounted
UPC	785007034998
Manufacturer	Legrand

8. WARRANTY INFORMATION

This adorne wall plate is covered by Legrand's standard product warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the official Legrand website or contact their customer support. Keep your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

For technical assistance, product inquiries, or to report any issues, please contact Legrand customer support. You can find contact information, FAQs, and additional resources on the official Legrand website: www.legrand.us/adorne.



