

iLive Electronics ISB250B

iLive Electronics Wireless Tailgate Party Speaker

Model: ISB250B - User Manual

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your iLive Electronics Wireless Tailgate Party Speaker, Model ISB250B. Please read this manual thoroughly before using the device and retain it for future reference.

The ISB250B is a portable wireless speaker designed for audio playback via Bluetooth, FM radio, USB, and auxiliary input. It features LED light effects and a built-in rechargeable battery for extended use.

2. SAFETY INFORMATION

WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

- Do not expose the unit to extreme temperatures, direct sunlight, dust, or moisture.
- Do not place the unit near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not block any ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Unplug this unit during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Do not dispose of batteries in fire.

3. WHAT'S IN THE BOX

Verify that all components are present before proceeding with setup.

- iLive Wireless Tailgate Party Speaker (ISB250B)
- Micro-USB to USB cable
- User's Guide

4. PRODUCT OVERVIEW

Familiarize yourself with the various components and controls of your speaker.



Figure 4.1: Front and Side View with Key Features

This image displays the iLive ISB250B speaker from the front and side, highlighting its main features. Labels indicate the location of the Bluetooth connectivity, LED lights, dual 6.5-inch full-range speakers, USB and Micro SD ports for audio playback, the integrated carry handle for portability, and the internal rechargeable battery.



Figure 4.2: Rear Control Panel

This image shows the rear control panel of the iLive ISB250B speaker. Visible controls include the Power/Volume knob, a Charging Status indicator, the DC 5V power input, an AUX IN port, a button for Source selection and LED control, playback control buttons (Play/Pause, Skip Forward/Backward), a USB port, and a Mic In jack for microphone connection.

Controls and Indicators:

- **Power/Volume Knob:** Turns the unit on/off and adjusts the master volume.
- **Charging Status Indicator:** Illuminates when charging.
- **DC 5V Input:** For connecting the Micro-USB charging cable.
- **AUX IN:** 3.5mm input for external audio devices.
- **Source/LEDs Button:** Toggles between input sources (Bluetooth, FM, USB, AUX) and controls LED light effects.
- **Playback Controls:** Play/Pause, Skip Forward, Skip Backward.
- **USB Port:** For playing audio files from a USB drive.
- **Mic In:** 6.3mm input for a microphone.

5. SETUP

5.1 Charging the Battery

The speaker has a built-in rechargeable lithium-ion battery. Before first use, fully charge the battery for approximately 5 hours.

1. Connect the small end of the included Micro-USB to USB cable to the DC 5V input on the rear panel of the speaker.
2. Connect the large end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The Charging Status indicator will illuminate during charging. It will turn off once the battery is fully charged.

A full charge provides approximately 5 hours of playback at 50% volume or 2 hours at 100% volume.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

To power on the speaker, rotate the Power/Volume knob clockwise. To power off, rotate it counter-clockwise until it clicks.

6.2 Bluetooth Pairing

The speaker supports Bluetooth v5.0 with a wireless range of up to 60 feet.

1. Power on the speaker. It will automatically enter Bluetooth pairing mode if no other source is selected. The LED lights may flash to indicate pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "ISB250B" from the list of devices.
4. Once paired, the speaker will emit an audible confirmation, and the LED lights may change their pattern.
5. You can now play audio from your device through the speaker.

6.3 FM Radio Operation

1. Power on the speaker.
2. Press the Source/LEDs button repeatedly until FM mode is selected.
3. Press and hold the Play/Pause button to initiate an automatic scan for FM stations. The speaker will save all found stations.
4. Use the Skip Forward and Skip Backward buttons to navigate between saved FM stations.

6.4 USB Playback

The USB port supports audio file playback from a USB flash drive.

1. Insert a USB flash drive containing compatible audio files into the USB port on the rear panel.
2. Press the Source/LEDs button repeatedly until USB mode is selected.
3. The speaker will automatically begin playing audio from the USB drive.
4. Use the Play/Pause, Skip Forward, and Skip Backward buttons to control playback.

6.5 Aux-in Connection

Connect external audio devices using the 3.5mm AUX IN port.

1. Connect one end of a 3.5mm audio cable (not included) to the AUX IN port on the speaker.
2. Connect the other end of the cable to the headphone jack or audio output of your external device.
3. Press the Source/LEDs button repeatedly until AUX mode is selected.
4. Control audio playback from your external device.

6.6 Microphone Input

The speaker features a microphone input for public address or karaoke.

1. Connect a microphone (not included) to the Mic In jack on the rear panel.
2. Adjust the microphone volume using the microphone's controls, if available, or the speaker's master volume.

6.7 LED Light Effects

The speaker includes integrated LED light effects to enhance the party atmosphere.

- Press the Source/LEDs button briefly to cycle through different LED light patterns or to turn them off.

6.8 Party Plus (Speaker Pairing)

You can pair two ISB250B speakers together for a larger stereo sound experience.

1. Ensure both ISB250B speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the Play/Pause button until you hear a pairing tone.
3. The two speakers will automatically connect to each other.
4. Once connected, pair your Bluetooth device to the primary speaker as described in section 6.2. Audio will now play through both speakers.

7. MAINTENANCE

7.1 Cleaning

To clean the speaker, use a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.

7.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged before storage to maintain battery health.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is depleted.	Charge the speaker using the Micro-USB cable.
No sound	Volume is too low. Incorrect source selected. Device not paired (Bluetooth).	Increase volume. Press Source/LEDs button to select correct input. Re-pair Bluetooth device.
Bluetooth device cannot pair	Speaker is not in pairing mode. Device is out of range.	Ensure speaker is in Bluetooth mode. Move device closer to speaker (within 60 ft).
FM radio static	Weak signal.	Relocate the speaker to an area with better reception.
Speaker locks up when switching apps	Software glitch or temporary issue.	Power off the speaker, wait a few seconds, then power it back on.

9. SPECIFICATIONS

Feature	Detail
Model Name	Party Speaker
Model Number	ISB250B
Speaker Type	Portable Bluetooth Speaker, Outdoor Speakers
Connectivity Technology	Bluetooth

Feature	Detail
Wireless Communication Technology	Bluetooth v5.0
Maximum Range	60 Feet
Speaker Size	6.5 Inches (Dual Full Range Speakers)
Speaker Maximum Output Power	16 Watts
Power Source	Battery Powered (1 Lithium Ion battery included)
Battery Life	~5 hours at 50% volume, ~2 hours at 100% volume
Charging Time	5 Hours
Audio Output Mode	Stereo
Included Components	Micro-USB to USB cable, User's Guide
Product Dimensions	9.45 x 8.27 x 15.16 inches
Item Weight	4.63 pounds
UPC	047323202506

10. WARRANTY AND SUPPORT

10.1 Limited Warranty

iLive Electronics products are covered by a limited warranty. For specific details regarding your product's warranty period and coverage, please refer to the warranty information provided with your purchase or visit the official iLive Electronics website.

10.2 Customer Support

For technical assistance, troubleshooting, or service inquiries, please contact iLive Electronics customer support. Contact information can typically be found in the included User's Guide or on the official iLive Electronics website.

You may also visit the [iLive Electronics Store on Amazon](#) for additional product information and resources.