

[Manuals.plus](#) /

> [Snow Peak](#) /

> Snow Peak Land Breeze Living Shell Shield Tarp /R TP-623 Instruction Manual

## Snow Peak TP-623

# Snow Peak Land Breeze Living Shell Shield Tarp /R TP-623 Instruction Manual

Model: TP-623

## INTRODUCTION

---

Thank you for choosing the Snow Peak Land Breeze Living Shell Shield Tarp /R TP-623. This versatile shelter is designed to provide a comfortable and protected living space for up to 4 people during your outdoor adventures. This manual contains important information regarding the proper setup, operation, and maintenance of your new shelter. Please read it thoroughly before use to ensure safety and optimal performance.

## PACKAGE CONTENTS

---

Verify that all the following components are included in your package:

- **Main Unit:** The primary fabric body of the shelter.
- **A-Frame:** Main structural pole.
- **C-Frames (x2):** Secondary structural poles.
- **Dura-Pin Pegs (21cm x 22):** For securing the shelter to the ground.
- **Compression Belts (x2):** For compact storage.
- **Guy Ropes:**
  - 3.5m x 4
  - 7m x 2
  - 2m x 4
- **Seam Sealing Agent:** For maintaining waterproof integrity.
- **Frame Case:** Storage bag for poles.
- **Peg Case:** Storage bag for pegs.
- **Carry Bag:** Main storage bag for the entire shelter.
- **Upright Poles (x2):** For creating an extended canopy.

## SETUP INSTRUCTIONS

---

Follow these steps for a proper and secure setup of your Land Breeze Living Shell Shield Tarp /R. It is recommended to practice setup in a familiar environment before your first trip.

1. **Choose a Site:** Select a flat, clear area free of sharp objects. Consider wind direction and potential water runoff.
2. **Unpack and Lay Out:** Remove the main unit and frames from the carry bag. Lay the main unit flat on the ground, spreading it out evenly.
3. **Assemble Frames:** Connect the sections of the A-frame and C-frames. Ensure all sections are fully seated.
4. **Insert Frames:** Locate the sleeves or attachment points on the main unit for the A-frame and C-frames. Carefully slide the poles through the sleeves or attach them according to the design.
5. **Raise the Shelter:** With assistance, lift the shelter and secure the frame ends into the designated grommets or pins.
6. **Initial Pegging:** Lightly peg down the four main corners of the shelter to hold its shape.
7. **Attach Guy Ropes:** Connect the guy ropes to the designated loops on the shelter. Extend them outwards at an angle and secure them with pegs. Adjust tension to make the shelter taut.
8. **Install Upright Poles (Optional):** If using the extended canopy feature, insert the two upright poles into the grommets at the front of the shelter and secure them with additional guy ropes and pegs.
9. **Final Adjustments:** Walk around the shelter, checking all pegs and guy ropes. Adjust tension as needed to ensure stability and proper shape. The fabric should be taut but not overstretched.



Image: The Land Breeze Living Shell Shield Tarp /R TP-623 fully set up with the optional extended canopy, providing additional shaded space.



Image: The Land Breeze Living Shell Shield Tarp /R TP-623 set up in its basic configuration, offering a spacious enclosed area.

## OPERATING INSTRUCTIONS

---

The Land Breeze Living Shell Shield Tarp /R is designed for comfort and versatility.

- **Ventilation:** Utilize the multiple zippered openings and mesh panels to control airflow and prevent condensation. Adjust as needed based on weather conditions.
- **Entry/Exit:** The main entrance can be fully opened for easy access. Ensure zippers are closed when not in use to protect against elements and insects.
- **Connecting to a Tent:** This shelter can be connected to compatible Snow Peak tents to create an integrated living and sleeping area. Refer to your tent's manual for specific connection instructions.
- **Weather Protection:** In strong winds or heavy rain, ensure all guy ropes are properly tensioned and pegs are securely driven into the ground. Close all openings to maximize protection.

## MAINTENANCE

---

Proper maintenance will extend the life of your Snow Peak shelter.

- **Cleaning:** Clean the fabric with a soft brush or sponge and mild soap (non-detergent) and lukewarm water. Do not use harsh chemicals or machine wash. Rinse thoroughly.
- **Drying:** Always ensure the shelter is completely dry before packing it away. Packing a damp shelter can lead to mildew and fabric degradation. Hang it in a shaded, well-ventilated area.
- **Storage:** Store the clean, dry shelter in its original carry bag in a cool, dry place, away from direct sunlight and

extreme temperatures.

- **Seam Sealing:** Periodically inspect seams for wear. Apply the included seam sealing agent or a compatible product to maintain waterproof integrity, especially after prolonged use or exposure to harsh weather.
- **Pole Care:** Inspect poles for bends or cracks before and after each use. Clean any dirt from pole sections and ensure shock cords are in good condition.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Shelter is not taut/sags	Insufficient tension on guy ropes or pegs.	Adjust guy rope tensioners. Re-position pegs further out from the shelter. Ensure poles are fully extended.
Water leakage	Damaged fabric, worn seam sealing, or improper setup allowing water pooling.	Inspect fabric for tears; repair if necessary. Reapply seam sealing agent. Ensure shelter is taut and pitched to shed water effectively.
Poles difficult to assemble/disassemble	Dirt in pole sections, bent sections, or worn shock cord.	Clean pole sections. Inspect for damage; replace bent sections. If shock cord is loose, it may need replacement.
Zippers sticking	Dirt, sand, or fabric caught in zipper teeth.	Clean zipper teeth with a brush. Apply a zipper lubricant. Carefully free any caught fabric.

## SPECIFICATIONS

---

<b>Brand</b>	Snow Peak
<b>Model Number</b>	TP-623
<b>Occupancy</b>	4 people
<b>Weight</b>	14.2 kg (31.31 lbs)
<b>Packed Dimensions</b>	76 x 28 x 33 cm (H)
<b>Main Fabric Material</b>	Polyester (Rainfly)
<b>Water Resistance</b>	Seam-sealed, Waterproof
<b>Mounting Type</b>	Freestanding
<b>Fastener Type</b>	Buckle
<b>Color</b>	Brown

## SAFETY INFORMATION

---

- **Fire Safety:** Keep all flame and heat sources away from the tent fabric. The fabric is not fireproof and can burn rapidly.
- **Ventilation:** Ensure adequate ventilation when using cooking appliances or heaters inside the shelter to prevent carbon monoxide buildup.
- **Weather Conditions:** Do not use the shelter in extreme weather conditions such as severe storms, heavy snow, or high winds that exceed its design capabilities.
- **Site Selection:** Avoid pitching near unstable trees, cliffs, or areas prone to flash floods.
- **Children:** Supervise children around the shelter to prevent accidents.

## WARRANTY AND SUPPORT

---

For warranty information, product support, or to purchase replacement parts, please visit the official Snow Peak website or contact their customer service department. Keep your proof of purchase for warranty claims.

[Visit Snow Peak Official Website](#)

