Vidal Sassoon VSP1107

Vidal Sassoon Ionic Technology Round Brush User Manual

Model: VSP1107

Introduction | Safety Information | Product Overview | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

Thank you for choosing the Vidal Sassoon Ionic Technology Round Brush. This manual provides essential information for the safe and effective use of your new styling tool. Please read these instructions thoroughly before first use and retain them for future reference.

2. Important Safety Information

- Always keep the brush clean and free from hair product buildup.
- Do not use this brush on extremely wet hair; it is designed for damp or dry hair.
- Keep out of reach of children.
- Inspect the brush regularly for any signs of damage. Discontinue use if bristles are bent or missing.
- This brush is intended for personal hair styling use only.

3. Product Overview

The Vidal Sassoon Ionic Technology Round Brush is designed to help create smooth, voluminous styles. Its round barrel and ionic bristles work together to reduce frizz and enhance shine.



Figure 1: The Vidal Sassoon Ionic Technology Round Brush. This image displays the full brush, highlighting its round barrel, ergonomic handle, and the ionic bristles designed for smooth styling. A bonus hair clip is also visible, typically used for sectioning hair during styling.

Key Features:

- **Ionic Bristles:** Helps to reduce frizz and static, promoting smoother, shinier hair.
- **Round Barrel Design:** Ideal for adding volume, creating curls, or straightening hair during blow-drying.

- **Ergonomic Handle:** Provides a comfortable grip for ease of use.
- **Bonus Clip:** Included for convenient hair sectioning during styling.

4. Setup

1. **Unboxing:** Carefully remove the brush and any accessories (such as the bonus clip) from the packaging.
2. **Inspection:** Before first use, inspect the brush for any manufacturing defects or damage. Ensure all bristles are intact and the handle is secure.
3. **Cleaning:** For hygienic reasons, it is recommended to gently clean the brush with mild soap and water before initial use. Allow it to air dry completely.

5. Operating Instructions

This round brush is designed to be used in conjunction with a hairdryer for optimal styling results. Ensure your hair is towel-dried and slightly damp, or completely dry, before styling.

General Styling Steps:

1. **Prepare Hair:** Ensure hair is detangled. Apply any desired heat protectant or styling products.
2. **Section Hair:** Use the bonus clip or other clips to divide your hair into manageable sections. Start with the bottom layers.
3. **Position Brush:** Place the brush at the roots of a hair section, underneath or on top, depending on the desired style.
4. **Apply Heat:** Direct the airflow from your hairdryer onto the hair section wrapped around the brush. Move the brush and hairdryer simultaneously down the hair shaft.
5. **Style as Desired:**
    - *For Volume:* Lift the hair section upwards and away from the scalp as you dry.
    - *For Straightening:* Pull the brush tautly down the hair section.
    - *For Curls/Waves:* Wrap the hair section around the barrel, hold for a few seconds with heat, then gently unroll.
6. **Repeat:** Continue with remaining sections until all hair is styled.

The ionic bristles help to distribute natural oils and reduce static, contributing to a smoother finish.

6. Maintenance and Care

Cleaning the Brush:

1. **Remove Hair:** Regularly remove loose hair from the bristles using a comb or your fingers.
2. **Wash:** For a deeper clean, wash the brush with lukewarm water and a small amount of mild shampoo or soap. Gently scrub the bristles.
3. **Rinse:** Rinse thoroughly under running water, ensuring all soap residue is removed.
4. **Dry:** Shake off excess water and allow the brush to air dry completely, preferably bristles-down, to prevent water from collecting in the base.

Storage:

Store the brush in a clean, dry place away from direct sunlight and extreme temperatures. Avoid storing it with the bristles compressed, which can cause them to bend or deform.

7. Troubleshooting

Problem	Possible Cause	Solution
Hair gets tangled in the brush.	Using too large a section of hair; hair is not fully detangled; improper brushing technique.	Section hair into smaller, more manageable portions. Ensure hair is thoroughly detangled before brushing. Brush slowly and gently.
Brush does not provide desired volume/smoothness.	Hair is too wet; insufficient heat from hairdryer; incorrect technique.	Ensure hair is damp, not soaking wet. Use adequate heat from your hairdryer. Review operating instructions for proper technique.
Bristles are bent or falling out.	Excessive force during brushing; improper storage; normal wear and tear over time.	Use gentle brushing motions. Store the brush carefully to protect bristles. If bristles are significantly damaged, consider replacing the brush.

8. Specifications

- **Model Number:** VSP1107
- **Brand:** Vidal Sassoon
- **Shape:** Round
- **Bristle Material:** Nylon (Ionic)
- **Handle Material:** Plastic
- **Special Feature:** Ionic Technology
- **UPC:** 078729711071
- **Package Dimensions:** 10.75 x 3.62 x 2.48 inches
- **Item Weight:** 4.59 ounces

9. Warranty and Support

This product is manufactured by Vidal Sassoon. For specific warranty details, please refer to the packaging or contact Vidal Sassoon customer support directly. General product support and inquiries can be directed to the manufacturer's official website or customer service channels.
Please note: Warranty terms may vary by region and retailer. Keep your proof of purchase for any warranty claims.

© 2023 Vidal Sassoon. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question