

[Manuals.plus](#) /

› [Eureka Forbes](#) /

› Eureka Forbes Euroclean iGlide Spray Mop (I-Glide) Instruction Manual

Eureka Forbes I-Glide

Eureka Forbes Euroclean iGlide Spray Mop (I-Glide) Instruction Manual

INTRODUCTION

Welcome to the instruction manual for your new Eureka Forbes Euroclean iGlide Spray Mop. This innovative 2-in-1 spray mop is designed for efficient cleaning of both dry dust and wet spills, providing a convenient and hygienic cleaning experience. Please read this manual carefully before use to ensure proper assembly, operation, and maintenance of your device.







Image: The Eureka Forbes Euroclean iGlide Spray Mop, showcasing its spray function. The mop features a grey handle, a blue water tank, and a blue mop head with a microfiber pad.

WHAT'S IN THE BOX

Upon unpacking, please ensure all the following components are present:

- **1 Rod Handle:** The main handle assembly for gripping and maneuvering the mop.
- **1 Bottle Holder:** The component that secures the water bottle to the mop.
- **1 Bottle:** The reservoir for your cleaning solution.
- **1 Mop Head:** The base unit to which the scrub pads attach.
- **2 Scrub Pads:** Reusable microfiber pads for cleaning.

SETUP INSTRUCTIONS

1. **Assemble the Handle:** Connect the rod handle sections firmly until they click into place.
2. **Attach Bottle Holder:** Slide the bottle holder onto the main mop body until it is securely seated.
3. **Insert Bottle:** Fill the provided bottle with water or your preferred cleaning solution. Insert the filled bottle into the bottle holder, ensuring it is properly aligned and sealed.
4. **Attach Scrub Pad:** Secure one of the scrub pads to the bottom of the mop head. The pads typically attach with hook-and-loop fasteners.





Image: A detailed view of the Eureka Forbes Euroclean iGlide Spray Mop, highlighting the handle with the spray trigger and the transparent water bottle.

OPERATING INSTRUCTIONS

- 1. Prepare Solution:** Ensure the bottle is filled with clean water or a suitable floor cleaning solution. Do not use harsh chemicals that may damage the mop or your flooring.
- 2. Initiate Spray:** Hold the mop handle and press the trigger located on the handle. This will activate the spray mechanism, dispensing liquid onto the floor in front of the mop head.
- 3. Mop the Floor:** Glide the mop head over the floor surface, using the spray as needed to dampen the area. The 2-in-1 design allows for effective cleaning of both dry dust and wet spills.
- 4. Adjust Handle:** The adjustable mop handle allows for comfortable cleaning without excessive bending. Adjust it to your preferred height.

MAINTENANCE AND CARE

- Scrub Pad Cleaning:** The reusable scrub pads can be easily removed from the mop head. They are machine washable; wash them with similar colors and air dry for best results. Do not use bleach or fabric softeners.
- Bottle Cleaning:** After each use, empty any remaining solution from the bottle and rinse it thoroughly with clean water. This prevents residue buildup and ensures optimal spray performance.
- Mop Head Cleaning:** Wipe down the mop head and handle with a damp cloth as needed to remove dust and grime.
- Storage:** Store the mop in a dry place, away from direct sunlight and extreme temperatures. Ensure the bottle is empty before storing for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No spray or weak spray	◦ Bottle empty or not properly inserted. ◦ Nozzle clogged. ◦ Trigger mechanism issue.	◦ Refill bottle and ensure it is securely seated. ◦ Clean the spray nozzle with a small brush or pin. ◦ Ensure the trigger is fully depressed. If the issue persists, contact customer support.
Mop not cleaning effectively	◦ Scrub pad is dirty or worn out. ◦ Insufficient cleaning solution. ◦ Incorrect cleaning solution for surface.	◦ Replace or clean the scrub pad. ◦ Ensure adequate solution is sprayed. ◦ Use a cleaning solution appropriate for your floor type.

SPECIFICATIONS

Brand	Eureka Forbes
Model Number	I-Glide
Colour	Grey/Blue
Surface Recommendation	Floor
Item Weight	1.36 kg

Handle Material	Plastic or Metal
Head Material	Microfiber
Manufacturer	EUREKA FORBES
Included Components	Rod handle, bottle holder, bottle, mop head, scrub pads

WARRANTY INFORMATION

The Eureka Forbes Euroclean iGlide Spray Mop comes with a **3-month warranty** on the product from the date of purchase. Please retain your purchase receipt as proof of warranty. This warranty covers manufacturing defects under normal use. For warranty claims or service, please refer to the support contact information below.

SUPPORT

For further assistance, product inquiries, or to register your product, please visit the official Eureka Forbes store or contact their customer service.

Official Brand Store: [Eureka Forbes Store on Amazon.in](#)

Please note that contact details like phone numbers or email addresses are not provided in the product data. Refer to the brand's official website or the provided store link for the most current support information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

