

[Manuals.plus](#) /

› [Little Tikes](#) /

› Little Tikes Sizzle and Serve Grill Kitchen Playset Instruction Manual

Little Tikes 637735M

Little Tikes Sizzle and Serve Grill Kitchen Playset Instruction Manual

PRODUCT OVERVIEW

The Little Tikes Sizzle and Serve Grill Kitchen Playset is designed to provide an engaging and imaginative play experience for children aged 18 months to 5 years. This playset allows children to mimic outdoor grilling activities, fostering creativity and social development.



Image: The Little Tikes Sizzle and Serve Grill Playset, showcasing its compact design and included accessories.

Included Accessories:

- 1 Pair of Tongs
- 1 Spatula
- 1 Bottle of Ketchup
- 1 Bottle of Mustard
- 2 Hamburgers with Buns
- 2 Hot Dogs with Buns



Image: A close-up view of the various play food items and utensils included with the grill playset.

SETUP INSTRUCTIONS

The Little Tikes Sizzle and Serve Grill is designed for quick and easy assembly without the need for tools. The components snap together in minutes, allowing for immediate play.

1. Unpack all components from the packaging.
2. Connect the grill base to the main body. Ensure all parts click securely into place.
3. Attach the lid to the grill body. For proper function, ensure the lid's hinge components are fully snapped into place. Apply firm pressure until you hear distinct clicks, confirming a secure connection. This ensures the lid stays open and closes smoothly.
4. Place the included accessories on the side trays or inside the grill.

OPERATING INSTRUCTIONS

The Sizzle and Serve Grill offers interactive features for realistic play.

- **Grill Lid:** The lid features an easy-open handle. Lift the handle to open the grill and place play food items on the grilling surface.
- **Mobility:** The grill is equipped with built-in wheels on the base, allowing for easy movement. Tilt the grill slightly and pull it using the side handle to relocate it.
- **Cooking Knob:** A knob on the side tray turns with a clicking sound, simulating a real grill ignition or temperature control.
- **Accessories:** Use the tongs and spatula to handle the play hamburgers and hot dogs. Apply pretend ketchup and mustard for a complete play experience.



Image: Two children engaging in imaginative play with the grill, demonstrating its use.



Image: A child demonstrating the grill's mobility by pushing it across a patio.

MAINTENANCE

To ensure the longevity and cleanliness of your Little Tikes Sizzle and Serve Grill, follow these simple maintenance guidelines:

- **Cleaning:** Wipe down all plastic surfaces with a damp cloth and mild soap. Rinse thoroughly and dry completely before storage. Avoid abrasive cleaners or solvents.
- **Storage:** Store the playset indoors when not in use to protect it from extreme weather conditions and prolong its lifespan.
- **Inspection:** Periodically check all parts for wear or damage. Discontinue use if any part is broken or compromised.

TROUBLESHOOTING

Problem	Solution
Lid does not stay open or detaches easily.	During assembly, ensure the lid's hinge components are fully snapped into place. Apply firm pressure until you hear distinct clicks, confirming a secure connection.
Grill is unstable or tips over.	Ensure the grill is placed on a flat, stable surface. For increased stability, especially during active play, consider placing a small, appropriate weight on the bottom shelf.

SPECIFICATIONS

- **Brand:** Little Tikes
- **Model Number:** 637735M
- **Dimensions (L x W x H):** 19.50 inches x 15.00 inches x 24.00 inches
- **Item Weight:** 5.6 Pounds
- **Material Type:** Plastic
- **Age Range:** Kid, Toddler (Manufacturer Minimum Age: 18 months, Maximum Age: 60 months)
- **Included Components:** Sizzle and grill role play accessories

WARRANTY INFORMATION

This product is covered by a 90-day warranty against manufacturer defects. Please retain your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your Little Tikes Sizzle and Serve Grill Kitchen Playset, please contact Little Tikes customer service. Refer to the official Little Tikes website for current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question