

Miele CM 6100

Miele CM 6100 Automatic Coffee Machine User Manual

Model: CM 6100

- Setup
- Operating
- Maintenance
- Troubleshooting
- Specifications
- Warranty & Support

1. Setup

Follow these steps to set up your Miele CM 6100 Automatic Coffee Machine for first use.

- Unpacking:** Carefully remove all packaging materials. Ensure all components are present: the coffee machine, water tank, drip tray, coffee grounds container, and any included accessories.
- Positioning:** Place the coffee machine on a stable, level, and heat-resistant surface. Ensure adequate ventilation around the appliance.
- Initial Cleaning:** Before first use, wipe the exterior of the machine with a damp cloth. Remove and rinse the water tank, drip tray, and coffee grounds container with warm water.
- Filling the Water Tank:** Remove the water tank, fill it with fresh, cold tap water up to the MAX mark, and reinsert it securely.
- Filling the Bean Container:** Open the lid of the bean container and fill it with whole coffee beans. Close the lid firmly to preserve aroma. The machine also supports pre-ground coffee via a separate chute.
- Power Connection:** Plug the power cord into a grounded electrical outlet.



Figure 1: Miele CM 6100 Automatic Coffee Machine, Lotus White. This image shows the front view of the coffee machine with its water tank and bean container visible.

The Miele CM 6100 features the *AromaticSystem*, which ensures an intense coffee aroma through intelligent brewing technology.

2. Operating Instructions

This section details the basic operation of your Miele CM 6100 coffee machine.

2.1 Powering On/Off

- To turn on the machine, press the **On/Off** button. The machine will perform an automatic rinse cycle.
- To turn off the machine, press the **On/Off** button again. The machine will perform another rinse cycle before shutting down.

2.2 Preparing Coffee

The Miele CM 6100 is a fully automatic espresso machine capable of preparing various coffee specialties.

1. **Select Beverage:** Use the control panel to select your desired beverage (e.g., Espresso, Coffee, Cappuccino).
2. **Adjust Settings (Optional):** Depending on the beverage, you may be able to adjust coffee strength, water volume, or temperature.
3. **Start Brewing:** Place a cup under the coffee spout and press the **Start** button or the selected beverage button.

2.3 OneTouch and OneTouch for Two

This feature allows for convenient preparation of single or double servings of your favorite coffee specialties.

- **OneTouch:** Select a beverage like Espresso or Cappuccino, and the machine will prepare a single serving with a single touch.
- **OneTouch for Two:** For beverages like Espresso or Coffee, select the 'Two Cups' option to prepare two servings simultaneously.

2.4 Using the Cappuccinatore

The integrated Cappuccinatore allows for quick preparation of warm milk or creamy milk froth directly into your cup.

1. **Connect Milk Tube:** Attach the milk tube to the Cappuccinatore and place the other end into a container of cold milk.
2. **Select Milk Beverage:** Choose a milk-based beverage (e.g., Cappuccino, Latte Macchiato) from the menu.
3. **Start Preparation:** Place your cup under the Cappuccinatore spout and press the **Start** button. The machine will automatically froth and dispense milk, then add coffee.

3. Maintenance

Regular cleaning and maintenance ensure optimal performance and longevity of your Miele CM 6100 coffee machine.

3.1 Automatic Cleaning Programs

The machine features several automatic cleaning programs to simplify maintenance.

- **Rinse Program:** Automatically runs when the machine is switched on or off.
- **Milk System Rinse:** After preparing milk-based beverages, the machine will prompt you to rinse the milk system. Follow the on-screen instructions.
- **Brew Unit Cleaning:** The machine will periodically prompt for a brew unit cleaning. Use Miele cleaning tablets as instructed.
- **Descaling:** The machine will indicate when descaling is required. Use Miele descaling agents and follow the program steps.

3.2 Manual Cleaning

- **Drip Tray and Coffee Grounds Container:** Empty and rinse these components daily or when prompted by the machine. *Note: These parts are not dishwasher safe.*

- **Water Tank:** Rinse the water tank regularly with warm water.
- **Cappuccinatore:** Disassemble the Cappuccinatore components and clean them thoroughly with warm water after each use, especially after preparing milk.
- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners.



Figure 2: Miele CM 6100 Automatic Coffee Machine. Regular cleaning of removable parts like the drip tray and water tank is essential for hygiene and performance.

4. Troubleshooting

This section provides solutions for common issues you might encounter with your Miele CM 6100 coffee machine.

Problem	Possible Cause	Solution
No coffee is dispensed.	Water tank empty; coffee beans empty; brew unit blocked.	Fill water tank; fill bean container; perform brew unit cleaning program.
Coffee is too weak.	Incorrect grind setting; insufficient coffee strength selected.	Adjust grind setting to finer; increase coffee strength in settings.
Milk is not frothing correctly.	Cappuccinatore dirty; milk tube blocked; milk too warm.	Clean Cappuccinatore thoroughly; ensure milk is cold.
Machine displays 'Descale' message.	Limescale buildup.	Run the automatic descaling program using Miele descaling agent.
Machine displays 'Clean Brew Unit' message.	Coffee residue buildup in brew unit.	Run the automatic brew unit cleaning program using Miele cleaning tablets.

If the problem persists after attempting these solutions, please refer to the Warranty & Support section for further assistance.

5. Specifications

Key technical specifications for the Miele CM 6100 Automatic Coffee Machine.

Feature	Detail
Brand	Miele
Model Number	CM 6100
Capacity (Water Tank)	1.8 Liters
Color	Lotus White
Coffee Machine Type	Espresso Machine
Item Weight	9.9 Kilograms
Operating Mode	Fully Automatic
Voltage	230 Volts AC (VAC)
Coffee Input Type	Whole Bean, Ground Coffee
Power Source	Mains Powered
Dishwasher Safe Parts	No

6. Warranty & Support

For warranty information and customer support, please refer to the official Miele documentation included with your product or visit the Miele website.

- **Warranty:** Your Miele CM 6100 coffee machine is covered by a manufacturer's warranty. Details regarding the

warranty period and terms can be found in the warranty card or on the official Miele website for your region.

- **Customer Support:** For technical assistance, spare parts, or service requests, please contact Miele customer service. Contact details are typically available on the Miele official website or in the product's accompanying literature.
- **Online Resources:** Additional support, FAQs, and product registration may be available on the official Miele website.

© 2023 Miele. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00QI9QUSS>

More documents and user manuals: <https://manuals.plus/>