

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Moen](#) /

› [Moen 87066SRS Nori Collection Pullout Spray High-Arc Kitchen Faucet with Soap Dispenser Instruction Manual](#)

### Moen 87066SRS

# Moen 87066SRS Nori Collection Pullout Spray High-Arc Kitchen Faucet with Soap Dispenser Instruction Manual

Model: 87066SRS | Finish: Spot Resist Stainless

## 1. INTRODUCTION

---

Thank you for choosing the Moen 87066SRS Pullout Spray High-Arc Kitchen Faucet with Soap Dispenser from the Nori Collection. This manual provides detailed instructions for the proper installation, operation, and maintenance of your new kitchen faucet. Designed for modern kitchens, this faucet features a Spot Resist Stainless finish to minimize fingerprints and water spots, a high-arc design for ample clearance, and a convenient pullout spray head with the Reflex system for smooth operation and secure docking.



Image 1.1: The Moen 87066SRS Faucet and Soap Dispenser.

## 2. SAFETY INFORMATION

---

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in property damage, personal injury, or voiding of the warranty. Always turn off the main water supply before beginning any plumbing work. If you are unsure about any part of the installation process, consult a qualified plumber.

- Wear safety glasses during installation.
- Ensure all connections are secure to prevent leaks.
- Do not overtighten nuts or connections, as this may cause damage.

## 3. PACKAGE CONTENTS

---

Verify that all components are present before beginning installation:

- Moen 87066SRS Pullout Spray High-Arc Kitchen Faucet
- Soap Dispenser
- Mounting Hardware
- Duralock Quick Connect System Components
- Installation Instructions (this manual)

## 4. SETUP (INSTALLATION)

---

The Moen 87066SRS faucet is designed for easy installation, featuring a single-hole deck mount and the Duralock quick connect system. An escutcheon plate is included for 3-hole sink configurations.

### 4.1 Pre-Installation Steps

1. Turn off the main water supply to your kitchen sink.
2. Remove your old faucet and clean the sink area thoroughly.
3. Ensure the mounting surface is clean and dry.

### 4.2 Faucet Installation

1. Place the escutcheon plate (if using for a 3-hole sink) and gasket onto the sink deck.
2. Insert the faucet body through the center hole of the sink and escutcheon plate.
3. From underneath the sink, secure the faucet body using the provided mounting hardware. Ensure the faucet is aligned correctly before fully tightening.
4. Connect the hot and cold water supply lines to your home's water supply using the Duralock quick connect system. Ensure a secure, leak-free connection.
5. Attach the pullout spray hose to the faucet's main body using the quick connect fitting.
6. Install the weight onto the pullout spray hose, approximately 6 inches from the bottom of the spray head, to ensure proper retraction.

### 4.3 Soap Dispenser Installation

1. Insert the soap dispenser body into the designated hole on your sink deck.
2. From underneath, secure the dispenser with the provided nut.
3. Attach the soap bottle to the dispenser shank.
4. Fill the dispenser from the top by removing the pump head.



*Image 4.1: The pullout spray head extended for use.*

## 5. OPERATING INSTRUCTIONS

---

Your Moen 87066SRS faucet is designed for intuitive and efficient use.

### 5.1 Water Flow and Temperature Control

- **Turn On/Off:** Lift the single-handle lever to turn on the water. Push down to turn off.
- **Temperature Adjustment:** Move the lever to the left for hot water and to the right for cold water.
- **Flow Adjustment:** The further you lift the lever, the greater the water flow.

### 5.2 Pullout Spray Head Operation

- **Extend:** Gently pull the spray head down from the faucet spout. The flexible hose allows for extended reach within and around the sink.
- **Retract:** The Reflex system ensures the spray head retracts smoothly and docks securely back into the spout when released.
- **Spray Modes:** The spray head features a button to switch between two water delivery modes: a steady stream for filling and a powerful spray for rinsing.

### 5.3 Soap Dispenser Use

- Press down on the pump head to dispense soap directly into your sink or onto a sponge.

### 5.4 Video Demonstration

Watch this video for a visual demonstration of the pullout kitchen faucet's features and operation:

Your browser does not support the video tag.

## 6. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your Moen faucet.

### 6.1 Cleaning the Faucet

- The Spot Resist Stainless finish is designed to resist fingerprints and water spots. Clean with a soft, damp cloth and mild soap.
- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- For stubborn water spots, a 50/50 solution of white vinegar and water can be used, followed by rinsing and drying.

### 6.2 Refilling the Soap Dispenser

- To refill, simply lift the pump head straight up from the dispenser body.
- Pour liquid soap directly into the opening.
- Replace the pump head.

## 7. TROUBLESHOOTING

If you encounter any issues with your faucet, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Low Water Flow	Aerator clogged; Supply lines kinked; Water supply partially off.	Clean or replace aerator; Check and straighten supply lines; Ensure water supply valves are fully open.
Leaking Faucet	Loose connections; Damaged O-rings or cartridge.	Check and tighten all connections; Contact Moen customer support for replacement parts.
Spray Head Does Not Retract Fully	Weight on hose is misplaced or obstructed.	Ensure the hose weight is correctly positioned and free from obstructions under the sink.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Moen
Model Name	Moen 87066SRS Pullout Spray High-Arc Kitchen Faucet with Soap Dispenser from The Nori Collection
Finish Type	Spot Resist Stainless
Material	Stainless Steel (Faucet), Plastic (Handle)
Mounting Type	Deck Mount
Number of Handles	1

Feature	Detail
Hole Count	3 (with escutcheon plate)
Special Feature	Pull Down Sprayer, Reflex System
Maximum Flow Rate	1.5 Gallons Per Minute
Spout Height	17 Inches
Spout Reach	8.63 Inches
Hose Length	68 Inches
Product Dimensions	2.76"D x 2.76"W x 9.72"H
Item Weight	0.01 Ounces (Note: This weight may refer to packaging or a specific component, actual product weight will be higher)
UPC	026508250365

## 9. WARRANTY AND SUPPORT


Your Moen 87066SRS faucet comes with a limited warranty. For specific details regarding your warranty coverage, please refer to the warranty documentation included with your product packaging or visit the official Moen website.






For technical assistance, replacement parts, or any questions not covered in this manual, please contact Moen Customer Support:

- **Website:** [www.moen.com](http://www.moen.com)
- **Phone:** Refer to the Moen website for regional contact numbers.

© 2025 Moen Incorporated. All rights reserved. Specifications are subject to change without notice.

### Related Documents - 87066SRS

	<p><a href="#">Moen 87042SRS Edison One-Handle Kitchen Faucet Installation Guide</a></p> <p>Comprehensive installation guide for the Moen 87042SRS Edison one-handle kitchen faucet, including parts list, step-by-step instructions, cleaning recommendations, and warranty information.</p>
---	---

	<p><a href="#">MOEN Cadia 87869SRS Single-Handle High Arc Pulldown Kitchen Faucet Illustrated Parts</a></p> <p>Illustrated parts list for the MOEN Cadia 87869SRS Single-Handle High Arc Pulldown Kitchen Faucet, including part numbers and descriptions. Order parts directly from MOEN.</p>
	<p><a href="#">Moen Faucet Finish Care and Cleaning Guide</a></p> <p>Comprehensive guide to cleaning and maintaining Moen faucet finishes, including LifeShine® and Non-LifeShine® types, with instructions for general cleaning, removing water spots, and warranty information.</p>
	<p><a href="#">Moen Inara Series 87463 Illustrated Parts List</a></p> <p>Detailed illustrated parts list for the Moen Inara Series 87463 Single-Handle High Arc Pulldown Kitchen Faucet, including part numbers, finishes, and descriptions.</p>
	<p><a href="#">Moen Cadia MotionSense Wave Faucet Illustrated Parts List</a></p> <p>Detailed illustrated parts list for the Moen Cadia MotionSense Wave Hands-Free, Single-Handle High arc Pulldown Kitchen Faucet (Model 87869EWSRS). Includes part descriptions, kit numbers, and finishes.</p>
	<p><a href="#">Moen Arbor Motionsense Touchless Kitchen Faucet - User Manual &amp; Illustrated Parts</a></p> <p>Detailed user manual and illustrated parts list for the Moen Arbor Spot Resist Stainless Motionsense Two-Sensor Touchless Kitchen Faucet (Model 7594ESRS) with Power Clean and pull-down spray head. Includes part numbers and available finishes.</p>