iHome IHIBT66

iHome IBT66 Portable Color Changing Bluetooth Speaker User Manual

Introduction

Thank you for purchasing the iHome IBT66 Portable Color Changing Bluetooth Speaker. This manual provides detailed instructions on how to set up, operate, and maintain your speaker. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.
The iHome IBT66 is a compact and portable wireless speaker designed to deliver clear audio and enhance your listening experience with dynamic color-changing light modes. Its Bluetooth connectivity allows for seamless streaming from compatible devices.

What's in the Box

- iHome IBT66 Portable Color Changing Bluetooth Speaker
- USB Charging Cable
- User Manual (this document)

Controls and Indicators



Image of the iHome IBT66 portable Bluetooth speaker, showcasing its compact design and color-changing capabilities.

Familiarize yourself with the speaker's controls and indicators:

- **Power Button:** Press and hold to turn the speaker ON/OFF.
- **Bluetooth Pairing Button:** Press to enter Bluetooth pairing mode.
- **Volume Up/Next Track Button:** Press to increase volume. Press and hold for next track.
- **Volume Down/Previous Track Button:** Press to decrease volume. Press and hold for previous track.
- **Play/Pause Button:** Press to play or pause audio.
- **Light Mode Button:** Press to cycle through different color-changing light modes.
- **Charging Port:** Connect the USB charging cable here.
- **LED Indicator:** Shows power status, charging status, and Bluetooth pairing status.

Charging the Speaker

Before initial use, fully charge your iHome IBT66 speaker.

1. Connect the small end of the included USB charging cable to the Charging Port on your speaker.
2. Connect the larger end of the USB charging cable to a powered USB port (e.g., computer, USB wall adapter).
3. The LED indicator will illuminate to show charging status. It will typically turn off or change color when fully charged.
4. A full charge usually takes approximately 2-3 hours.

Note: Do not use damaged charging cables or adapters.

Setup: Bluetooth Pairing

Follow these steps to pair your iHome IBT66 speaker with a Bluetooth-enabled device:

1. **Power On:** Press and hold the Power Button on the speaker until the LED indicator lights up and you hear an audible prompt.

2. **Enter Pairing Mode:** The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing LED light (e.g., blue or white). If not, press the Bluetooth Pairing Button.
3. **Enable Bluetooth on Your Device:** On your smartphone, tablet, or other Bluetooth device, go to the Bluetooth settings and ensure Bluetooth is enabled.
4. **Select Speaker:** Look for "iHome IBT66" (or similar) in the list of available devices and select it.
5. **Confirm Pairing:** Once paired, the LED indicator will stop flashing and remain solid, and you may hear a confirmation tone.

Your speaker is now ready to play audio wirelessly.
Note: The speaker will attempt to reconnect to the last paired device automatically when powered on.

Operating the Speaker

Audio Playback

- After successful Bluetooth pairing, open your preferred music or audio app on your connected device.
- Start playing audio. The sound will be streamed to your iHome IBT66 speaker.
- Use the Volume Up/Down buttons on the speaker or your connected device to adjust the volume.
- Press the Play/Pause button to control playback.
- Press and hold Volume Up/Down for next/previous track.

Color Changing Light Modes

The iHome IBT66 features dynamic color-changing lights to enhance your listening experience.

- Press the Light Mode Button to cycle through various light effects.
- Available modes may include solid colors, fading colors, pulsing to music, or off.
- Continue pressing the button until you find your desired light mode.

Maintenance

Proper care ensures the longevity of your iHome IBT66 speaker.

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speaker. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To maintain battery health, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.
- **Water Exposure:** This speaker is not waterproof. Avoid exposing it to water or excessive moisture.

Troubleshooting

Problem	Possible Solution
Speaker does not turn on.	◦ Ensure the battery is charged. Connect the speaker to a power source using the USB cable. ◦ Press and hold the Power Button for a few seconds.

Problem	Possible Solution
Cannot pair with Bluetooth device.	◦ Make sure the speaker is in pairing mode (flashing LED). ◦ Ensure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device. ◦ Turn off and on both the speaker and your device's Bluetooth. ◦ Forget "iHome IBT66" from your device's Bluetooth list and try pairing again.
No sound or low volume.	◦ Increase the volume on both the speaker and your connected device. ◦ Ensure the speaker is successfully paired and connected. ◦ Check if the audio source on your device is playing.
Lights are not working.	◦ Press the Light Mode Button to cycle through modes, ensuring it's not set to "off". ◦ Ensure the speaker has sufficient battery charge.

Specifications

- **Brand:** iHome
- **Model Number:** IHIBT66
- **Connectivity Technology:** Bluetooth
- **Speaker Type:** Portable
- **Special Features:** Portable, Color Changing Lights
- **Power Source:** Battery Powered
- **UPC:** 047532906097
- **GTIN:** 047532906097

Warranty and Support

iHome products are designed with quality and performance in mind. For specific warranty information, please refer to the warranty card included with your purchase or visit the official iHome website. Keep your proof of purchase for warranty claims.

For technical support or customer service inquiries, please visit the iHome support section on their official website or contact their customer service line. Contact details are typically available on the product packaging or the official iHome website.

Website: www.ihomeaudio.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question