Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Logitech /
- > Logitech 980-000910 Bluetooth Audio Adapter User Manual

Logitech 980-000910

Logitech 980-000910 Bluetooth Audio Adapter

Model: 980-000910 | Brand: Logitech

INTRODUCTION

The Logitech 980-000910 Bluetooth Audio Adapter allows you to wirelessly stream audio from your Bluetoothenabled devices, such as smartphones and tablets, to any speaker system with RCA or 3.5mm inputs. This compact adapter provides a convenient way to enjoy your digital music through your existing home stereo system, computer speakers, or AV receiver.



Image: Front view of the Logitech Bluetooth Audio Adapter, showcasing its compact design, the prominent Bluetooth pairing button with a blue glow, and the Logitech logo on the side.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Logitech Bluetooth Audio Adapter (Model: 980-000910)
- RCA to 3.5 mm Audio Cable
- Power Cable
- User Documentation

SETUP

1. Connect the Adapter to Your Audio System

The Logitech Bluetooth Audio Adapter can connect to your speakers or audio system using either RCA or 3.5mm (AUX) inputs.

1. Choose your connection type:

- For RCA inputs (red and white ports), use the provided RCA to 3.5mm cable. Connect the RCA ends to your audio system and the 3.5mm end to the AUX input on the Bluetooth Audio Adapter.
- For 3.5mm (AUX) inputs, use a standard 3.5mm audio cable (not included) to connect your audio system to the AUX input on the Bluetooth Audio Adapter.
- 2. **Connect to Power:** Plug the provided power cable into the adapter and then into an AC power source. The adapter will power on automatically.



 $Image: Rear\ view\ of\ the\ adapter,\ highlighting\ the\ AUX\ (3.5mm)\ and\ RCA\ input\ ports\ for\ connecting\ to\ various\ audio\ systems.$



Image: The adapter positioned next to a speaker, illustrating a typical setup where the adapter is connected to an audio output device.

2. Pair Your Bluetooth Device

Once the adapter is powered on and connected to your audio system, you can pair your Bluetooth-enabled device.

- 1. Ensure your audio system is turned on and set to the correct input source (e.g., AUX, RCA).
- 2. On the Logitech Bluetooth Audio Adapter, press the large Bluetooth pairing button located on the top. The blue indicator light will begin to blink rapidly, indicating it is in pairing mode.
- 3. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings and enable Bluetooth.
- 4. Scan for available devices. You should see "Logitech Bluetooth Adapter" or a similar name appear in the list.
- 5. Select the adapter from the list to connect. Once connected, the blue indicator light on the adapter will glow solid, and you will hear a confirmation tone through your speakers.



Image: Top-down view of the adapter, emphasizing the large, central Bluetooth button used for pairing.



Image: A hand pressing the Bluetooth pairing button on the adapter, demonstrating the one-push pairing action.

OPERATING THE ADAPTER

Automatic Reconnection

Once paired, your device will automatically reconnect to the Logitech Bluetooth Audio Adapter when it is within range (up to 15 meters or 49.21 feet line of sight) and Bluetooth is enabled on your device.

Multipoint Bluetooth

The adapter supports multipoint Bluetooth, allowing you to pair two Bluetooth-enabled devices simultaneously, such as a smartphone and a tablet. You can switch between these devices to stream audio wirelessly without needing to re-pair each time. Simply pause audio on one device and start playing on the other.

MAINTENANCE

To ensure the longevity and optimal performance of your Logitech Bluetooth Audio Adapter, follow these simple maintenance guidelines:

- Cleaning: Use a soft, dry cloth to clean the exterior of the adapter. Do not use liquid cleaners or aerosols, as they may damage the device.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- Handling: Avoid dropping the adapter or subjecting it to strong impacts.
- Ventilation: Ensure the adapter is placed in an area with adequate ventilation to prevent overheating.

TROUBLESHOOTING

If you encounter issues with your Logitech Bluetooth Audio Adapter, try the following troubleshooting steps:

• No Audio:

- Ensure the adapter is properly connected to your audio system's input (RCA or 3.5mm).
- Verify that your audio system is turned on and set to the correct input source.
- Check the volume levels on both your streaming device and your audio system.

• Cannot Pair Device:

- Make sure the adapter's Bluetooth button has been pressed and the indicator light is blinking rapidly (pairing mode).
- Ensure Bluetooth is enabled on your streaming device and it is within the 15-meter range.
- Try turning off and on Bluetooth on your streaming device, or restart the device.
- If previously paired, try "forgetting" the device on your streaming device's Bluetooth settings and repairing.

• Intermittent Connection/Poor Audio Quality:

- Reduce the distance between your streaming device and the adapter.
- Remove any obstacles (walls, large metal objects) that may be interfering with the Bluetooth signal.
- Avoid placing the adapter near other wireless devices that may cause interference (e.g., Wi-Fi routers, cordless phones).

SPECIFICATIONS

Feature	Detail
Product Dimensions	1.97 x 1.97 x 0.91 inches (50.8 x 22.32 x 57.15 mm)
Item Weight	1.2 ounces (34 g)
Model Number	980-000910
Brand	Logitech
Hardware Interface	Bluetooth
Color	Black
Compatible Devices	Desktop, Laptop, Smartphones, Tablets (with Bluetooth)
Data Link Protocol	Bluetooth
Data Transfer Rate	980 Megabits Per Second
Wireless Range	Up to 49.21 feet (15 meters) line of sight
Inputs	RCA, 3.5 mm (AUX)
Features	Multipoint Bluetooth, One-push pairing, Automatic reconnection

Feature	Detail
UPC	088564682115

WARRANTY INFORMATION

The Logitech 980-000910 Bluetooth Audio Adapter comes with a**1-Year Limited Hardware Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For full terms and conditions, please refer to the official Logitech warranty policy or contact customer support.

SUPPORT

For further assistance, technical support, or to view frequently asked questions, please visit the official Logitech support website or contact their customer service. You can also find more information on the Logitech Store on Amazon.

© 2024 Logitech. All rights reserved.

Logitech and the Logitech logo are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries.

Related Documents - 980-000910




Logitech Bluetooth Audio Receiver: Complete Setup Guide

A comprehensive guide to setting up and using the Logitech Bluetooth Audio Receiver for wireless audio streaming. Learn how to connect to speakers, pair devices, and manage multiple connections.



Logitech Bluetooth Audio Receiver: Complete Setup Guide

A comprehensive setup guide for the Logitech Bluetooth Audio Receiver, detailing how to connect the device to speakers, pair multiple Bluetooth devices, and manage connections for seamless wireless audio streaming.



Documents - Logitech - 980-000910



[pdf]

yesica gutierrez AC 353500 2 Index of images producto audioyvideoshop ||| Logitech Bluetooth Audio Adapter Haga streaming de msica a sus altavoces con tecnologa Bluetooth Str ... de RCA a 3,5mm Cable de alimentacin Documentacin del usuario Nmero de referencia N de referencia 980-000910 ...

lang:es score:17 filesize: 389.86 K page count: 4 document date: 2014-04-29

[pdf] User Manual Frequently Asked Questions Specifications Documentation Warranty

var www html sideloads logitech hardware warranty information original Logitech K480 Bluetooth Multi Device Portable Wireless Keyboard with Integrated Stand Phone Holder Works Windows and Mac Computers Android iOS Tablets Smartphones Black Standard Packaging G933 Artemis Spectrum RGB 7 1 Dolby DTS Headphone Surround Sound Gaming Headset PC PS4 Xbox One Switch Mobile Compatible Advanced Audio Drivers Adapter for Streaming Limited Hardware Warranty 920 006342 Product Documentation B00NAOZHYM B00MUTWLW 981 000585 980 000910 warrants to the purchaser that your product shall be free from defects in material workmanship length of time identified on 71lk22fgkJS m media amazon images I na ssl click here Amazon Group Video Conferencing Bundle Expansion Mics Big Meeting Rooms Electronics For about this please mouse check keys which contribute easy usability synnex co th Frequently Asked Questions As moment it still has 6 months or roughly until April 2021 before expires G920 Driving Force Racing Wheel Floor Pedals Real Feedback Stainless Steel Paddle Shifters Leather Steering Cover Series X S Games G602 Lag Free Mouse 11 Programmable Buttons Upto 2500 DPI 910 003820 Logitech G Shifter G29 G923 Wheels PlayStation 5 Playstation 4 Z333 2 Speakers Easy access Volume Control Jack TV DVD Blueray Player Game Console typing between computer phone tablet PackagingLogitech BlackLogitech DPILogitech Streaming920 B00MUTWLW981 Black910 DPI980 StreamingLogitech Electronicslogitech expiresLimited productAmazon pleaseAmazon GamesAmazon GamesLogitech BlackBluetooth Electronicsm 71lk22fgkJSm 71lk22fgkJSimages 71lk22fgkJSmanual internal |||

Limited Hardware Warranty Logitech warrants to the original purchaser that your Logitech hardware product shall be free from defects in material and workmanship for the length of time, identified on your product package and/or at www.logitech.com under specifications for your product, from the date ...

lang:en score:12 filesize: 214.31 K page count: document date:

Limited Hardware Warranty

Logisch sources is the original purchiser that your Logisch hardware product shall be free from defects in mental and wednumbing for the legisly of time, includined no year product shall be considered to the control of the legisly of time, includined no year product products of the legisly of the production of year products, from the date of control of the legislation of

How to Start

The first thing to do if you think you may have a warranty claim is to visit <u>http://www.logitech.com/support</u> where you will find a wide range of Support and FAQ p
with valuable technical assistance.


If you do not find a solution on our website, please contact the retailer from when you made your pectase. Valid warranty claims are generally processed through the point-of-perchase retailer during the first thirty (30) days after purchase. This period of time may vary depend on the retailer.

If your warranty claim cannot be processed through the point-of-purchase reaider, please virour <u>Support Warranty FAQ</u> section to find out how to contact our Support department.

Remedies

Copieds a state of the part of the copied and the copied and the copied and the copied and copied a

This warranty ones in over proteins of entangle resuming from (1) accessive, network, misupplication, or any unanchorized penjar, modification or disascentifyly (2) improper operation or ministenance, usage not in accordance with product instructions or connection to improper voltage supply; (3) uses of consumables, such as replacement batteries, but supplied by Logitech except where such restriction is prohibited by applicable law; (4) lost parts that were originally



Bluum MSRP Price List - REMC Bid Item Number 229011

A comprehensive price list from Bluum, detailing Manufacturer, Display Name, and MSRP for a wide range of products. This document serves as a reference for pricing and product availability within the REMC Bid Item Number 229011.

lang:de score:7 filesize: 770.94 K page_count: 190 document date: 2024-10-01