Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VCM 904125

VCM Udina Wall Display Cabinet - Model 904125 - User Manual

Brand: VCM | Model: 904125

1. Introduction

Thank you for choosing the VCM Udina Wall Display Cabinet. This cabinet is designed for displaying various collectibles such as miniature cars, figures, trains, beauty products, crystals, watches, and shells. It features 2 adjustable glass shelves and 2 ESG safety glass doors, offering both functionality and a modern aesthetic. This manual provides essential information for safe assembly, operation, and maintenance of your new display cabinet.



Image 1.1: The VCM Udina Wall Display Cabinet in white.

2. Safety Information

To prevent personal injury, harm to animals, or property damage, the furniture must be securely mounted/fixed to the wall. Improper mounting can lead to injuries. Use only wall fittings suitable for your wall type. For questions regarding appropriate mounting hardware, please contact a specialized company. This product is not a toy, as children and animals could injure themselves or others. Keep mounting hardware and accessories out of reach of children and animals to prevent injury or choking hazards.

3. Package Contents

Before beginning assembly, please ensure all components are present and undamaged. The package includes:

- 1x VCM Udina Wall Display Cabinet (disassembled)
- Mounting hardware
- Simple assembly instructions

4. Setup and Assembly

The VCM Udina Wall Display Cabinet is delivered disassembled and requires assembly. Follow the included simple assembly instructions carefully. Wall mounting is required for stability and safety.

4.1. Dimensions and Planning

Before assembly, plan the location for your display cabinet. Consider the dimensions and ensure the wall is suitable for mounting.




Image 4.1: Dimensions of the VCM Udina Wall Display Cabinet (Height: 80 cm, Width: 60 cm, Depth: 25 cm).

4.2. Assembly Steps (General Guidance)

1. Unpack all components and verify against the parts list.
2. Assemble the main frame of the cabinet according to the provided diagrams.
3. Insert the glass shelves into the desired positions. The shelves are adjustable.
4. Attach the ESG safety glass doors.
5. Securely mount the cabinet to a sturdy wall using the appropriate mounting hardware. Refer to the safety warnings in Section 2.



Image 4.2: The Udina cabinet installed in a living space.

5. Operating the Display Cabinet

The VCM Udina Wall Display Cabinet is designed for straightforward use.

5.1. Opening and Closing Doors

The cabinet features two glass doors. Gently slide or pivot the doors to open and close them. Ensure they are fully closed to protect your displayed items from dust.

5.2. Adjusting Shelves

The two glass shelves are adjustable. To change their height, carefully remove the items, lift the shelf, and reposition the shelf supports into the desired holes along the cabinet sides. Ensure the shelf is level and securely seated before placing items on it.



Image 5.1: Interior view showcasing adjustable glass shelves.

5.3. Optional Accessories

The display cabinet can be enhanced with optional accessories such as 'VCM Leuchto' LED lighting for illumination and a 'VCM Sicha' lock for added security. These accessories are sold separately.

6. Maintenance

To keep your VCM Udina Wall Display Cabinet in optimal condition, follow these simple maintenance guidelines:

- **Cleaning Wood Surfaces:** Wipe wooden parts with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.

- **Cleaning Glass Surfaces:** Use a standard glass cleaner and a lint-free cloth to clean the glass doors and shelves.
- **Dusting:** Regularly dust all surfaces with a dry, soft cloth.
- **Inspection:** Periodically check all screws and fittings to ensure they remain tight, especially the wall mounting hardware. Retighten if necessary.

7. Troubleshooting

If you encounter any issues with your VCM Udina Wall Display Cabinet, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Cabinet feels wobbly after wall mounting.	Improper wall mounting or loose fittings.	Ensure the cabinet is securely fixed to a sturdy wall using appropriate hardware. Check and tighten all mounting screws. If unsure, consult a professional.
Glass doors do not close properly or are misaligned.	Hinges are loose or misaligned.	Adjust the door hinges according to the assembly instructions. Tighten any loose screws on the hinges.
Shelves are not level.	Shelf supports are not inserted correctly or are uneven.	Remove items from the shelf, re-insert the shelf supports firmly into the desired holes, ensuring they are at the same height on both sides.

8. Specifications

Feature	Detail
Brand	VCM
Model Number	904125
Color	White
Material	Wood, Glass (ESG safety glass)
Product Dimensions (H x W x D)	80 cm x 60 cm x 25 cm
Item Weight	18.5 Kilograms
Maximum Weight Capacity	20 Kilograms
Mounting Type	Wall Mount
Number of Shelves	2 (adjustable)
Number of Doors	2
Number of Compartments	3
Assembly Required	Yes
Country of Origin	Bulgaria

9. Warranty and Support

9.1. Manufacturer's Warranty

For warranty inquiries, please contact the manufacturer directly. The manufacturer's warranty description can be found by contacting: Service@vcm-gruppe.de.

9.2. Spare Parts Availability

Spare parts are available for 2 years from the date of purchase.

9.3. Customer Support

For any questions or assistance regarding your VCM Udina Wall Display Cabinet, please contact the manufacturer at: amazon@vcm-gruppe.de.

© 2023 VCM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00R5B6AFQ

More documents and user manuals: **https://manuals.plus/**