

Zippo Armor High Polish Chrome Wind and Star Lighter (C14)

Zippo Armor High Polish Chrome Windproof Lighter User Manual

Model: Armor High Polish Chrome Wind and Star Lighter (C14)

Brand: Zippo

1. INTRODUCTION

This manual provides essential information for the safe and effective use, maintenance, and care of your Zippo windproof lighter. Your Zippo lighter is a durable, all-metal device designed for reliability in various conditions.



This image displays the Zippo Armor High Polish Chrome Wind and Star Lighter. The lighter features a highly polished chrome finish with an intricate engraved design of nautical waves on the left side and a compass rose on the right. A small blue gem is set in the center of the compass rose. The lighter is closed, showcasing its sleek, rectangular form.

Key Features:

- Genuine Zippo windproof lighter with distinctive Zippo "click".
- All metal construction ensures durability.
- Windproof design functions effectively in most outdoor environments.
- Refillable for a lifetime of use.
- Made in USA.

2. SETUP AND FUELING

Your Zippo lighter is shipped without fuel for safety reasons. Before first use, it must be filled with Zippo premium lighter fluid.

Fueling Instructions:

1. Remove the inner unit from the lighter case.
2. Lift the felt pad on the bottom of the inner unit to expose the packing material.
3. Slowly saturate the packing material with Zippo premium lighter fluid. Do not overfill. Stop when the fluid reaches the top of the packing, or when you see the fluid at the top of the wick.
4. Insert the inner unit back into the case.
5. Wipe any excess fluid from the lighter and your hands before igniting.

Warning: Lighter fluid is flammable. Keep away from open flames and sources of ignition. Keep out of reach of children.

3. OPERATING INSTRUCTIONS

To operate your Zippo windproof lighter:

1. Open the lighter lid. You will hear the distinctive Zippo "click".
2. Spin the flint wheel downwards with your thumb to create a spark.
3. The lighter should ignite.
4. To extinguish the flame, close the lid. Do not blow out the flame.

The windproof design allows the flame to remain lit in windy conditions, making it suitable for outdoor use.

4. MAINTENANCE

Regular maintenance ensures optimal performance of your Zippo lighter.

Refueling:

Refuel your lighter as described in Section 2 when the flame becomes weak or fails to ignite.

Flint Replacement:

If the lighter fails to spark, the flint may need replacement. Use genuine Zippo flints for best results.

1. Remove the inner unit from the case.
2. Unscrew the flint spring at the bottom of the inner unit.
3. Remove the old flint (if any) and insert a new Zippo flint into the tube.
4. Replace the flint spring and tighten it securely.

Wick Replacement:

If the wick is black or frayed, it may need trimming or replacement. Use genuine Zippo wicks.

1. Remove the inner unit, felt pad, and all packing material.
2. Pull the old wick out with pliers.
3. Insert a new wick through the chimney hole from the top.
4. Weave the wick through the packing material, ensuring it is evenly distributed.
5. Trim the wick even with the top of the chimney.
6. Replace the packing material and felt pad.

5. TROUBLESHOOTING

If your Zippo lighter is not performing as expected, consider the following common issues and solutions:

Problem	Solution
Lighter does not light.	Check fuel level and refill if necessary. Ensure flint is present and not worn.
Weak or inconsistent flame.	Refuel the lighter. Trim or replace the wick if it appears worn or dirty.
Flint wheel does not spark.	Replace the flint. Ensure the flint spring is tightened.

6. SPECIFICATIONS


Feature	Detail
ASIN	B00RN819TS
Brand	Zippo
Color	Chrome
Material	Metal
Style	Modern
Fuel Type	Zippo Premium Lighter Fluid
Number of Items	1
Date First Available	March 6, 2015






7. WARRANTY AND SUPPORT

Your Zippo lighter is backed by a lifetime guarantee: "It works or we fix it free." This warranty covers the mechanical function of your lighter. For service or repairs, please visit the official Zippo website or contact their customer support.

Zippo lighters are proudly Made in USA.

Related Documents - Armor High Polish Chrome Wind and Star Lighter (C14)

	<p>Zippo Arc Lighter Insert User Manual and Safety Guide</p> <p>Comprehensive user manual and safety instructions for the Zippo Arc Lighter Insert, Double Beam model #Z8C23. Includes operating, ignition, recharging, compatibility, and safe battery disposal information.</p>
---	---

	<p>Zippo Flex Neck Utility Lighter XL: Instructions and Safety Guide</p> <p>Comprehensive instructions for refilling, operating, and adjusting the Zippo Flex Neck Utility Lighter XL, along with essential safety warnings and guidelines.</p>
	<p>Zippo Windproof Lighter: User Manual and Safety Guide</p> <p>Detailed instructions for operating, filling, replacing flints, and adjusting the wick of your Zippo windproof lighter, along with essential safety warnings and maintenance tips.</p>
	<p>Zippo Windproof Lighter Instructions and Care</p> <p>Comprehensive guide to using and maintaining your Zippo windproof lighter, including safety precautions and warranty information.</p>
	<p>Zippo Windproof Lighter: Instructions, Maintenance & Guarantee</p> <p>Learn how to properly fill, re-flint, and maintain your Zippo Windproof Lighter with this comprehensive instruction manual. Includes important safety warnings and details on the Zippo Lifetime Guarantee.</p>
	<p>Zippo Mini MPL Candle Lighter Instructions - User Guide</p> <p>Official instructions for the Zippo Mini MPL Candle Lighter. Learn how to operate, refill, and adjust the flame safely. Includes warranty information and safety warnings.</p>