

[Manuals.plus](#) /

> [Wahl Professional](#) /

> Wahl Professional Clipper Guide Set #3160-100 Instruction Manual

Wahl Professional WA-3165

Wahl Professional Clipper Guide Set

MODEL: #3160-100 (WA-3165)

Instruction Manual

Introduction

The Wahl Professional Clipper Guide set, model #3160-100, provides four distinct cutting lengths for professional use. These guides are designed for precise hair cutting, ensuring consistent results. Each guide is clearly labeled with its size for easy identification. This set includes guides for 1/8 inch, 1/4 inch, 3/8 inch, and 1/2 inch cutting lengths. These guides are compatible with all Wahl full-sized clipper blades, with the exception of the Competition series blades.




Image: The Wahl Professional Clipper Guide Set #3160-100, showing the four different sized guides.

Setup

1. **Safety First:** Always ensure your hair clipper is turned off and unplugged from the power source before attaching or detaching any clipper guides.
2. **Select Guide:** Choose the desired cutting guide based on the required hair length. The sizes are typically marked on each guide.
3. **Attach Guide:** Align the guide with the clipper blade. Gently push the guide onto the blade until it snaps securely into place. Ensure both sides of the guide are firmly seated.
4. **Verify Attachment:** Before operating the clipper, gently tug on the guide to confirm it is securely attached and will not dislodge during use.

Operating Instructions

1. **Prepare Hair:** Ensure hair is clean and dry for optimal cutting performance.
2. **Attach Guide:** Follow the 'Setup' instructions to securely attach the chosen clipper guide to your Wahl full-sized clipper.
3. **Power On:** Plug in the clipper and turn it on.

- 4. Begin Cutting:** Hold the clipper with the guide flat against the head or desired area. Move the clipper against the direction of hair growth using smooth, overlapping strokes.
- 5. Maintain Angle:** Keep a consistent angle and pressure to achieve an even cut.
- 6. Change Guides:** To change cutting lengths, turn off and unplug the clipper. Carefully remove the current guide and attach a new one as per the 'Setup' instructions.

Maintenance

- **Clean After Each Use:** After every use, remove the guide from the clipper.
- **Remove Hair:** Use a cleaning brush (often supplied with clippers) to brush off any loose hair from both the guide and the clipper blade.
- **Rinse Guides:** The clipper guides can be rinsed under cool running water to remove stubborn hair or debris.
- **Dry Thoroughly:** Ensure the guides are completely dry before storing them or reattaching them to the clipper. Air drying is recommended.
- **Storage:** Store the guides in a clean, dry place, away from direct sunlight or extreme temperatures, to prolong their lifespan.

Troubleshooting

- **Guide Not Attaching Securely:**
Solution: Ensure the guide is correctly aligned with the clipper blade. Apply firm, even pressure until you hear or feel a click, indicating it's snapped into place. Check for any hair or debris obstructing the fit between the guide and the clipper blade.
- **Uneven Cut:**
Solution: Verify that the clipper guide is fully and securely seated on the clipper blade. Ensure you are using consistent pressure and maintaining a uniform angle during the cutting process. Hair buildup on the guide or blade can also cause uneven cutting; clean both thoroughly.
- **Guides Feel Loose After Extended Use:**
Solution: Over time, plastic guides may experience wear. If guides consistently feel loose or do not provide a secure fit, replacement may be necessary to ensure precise cutting.

Specifications

Model Number	#3160-100 (WA-3165)
Pack Contents	4 Clipper Guides
Cutting Lengths	1/8", 1/4", 3/8", 1/2"
Material	Nylon
Approximate Dimensions	3 x 2 x 3 inches
Compatibility	Fits all Wahl full-sized blades (except Competition series)
Manufacturer	WAHL
UPC	043917226958, 094393228073

Warranty and Support

Wahl Professional products purchased from authorized dealers typically include a manufacturer's warranty. For specific warranty details, terms, and conditions, please refer to the documentation provided with your original clipper purchase or visit the official Wahl Professional website. For technical assistance, product inquiries, or support, please contact Wahl Professional customer service directly.

Official Website: www.wahlpro.com

© 2023 Wahl Professional. All rights reserved.