Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEGO 70012

LEGO Legends of Chima Razar's CHI Raider 70012 Instruction Manual

Official Guide for Assembly and Play

Introduction

Welcome to the world of LEGO Legends of Chima! This instruction manual provides detailed guidance for assembling and enjoying your Razar's CHI Raider (Set 70012). This set allows you to construct a formidable raven-themed vehicle, complete with minifigures and accessories, for imaginative play.



Image: The complete LEGO Legends of Chima Razar's CHI Raider set. It features the large, raven-like vehicle with articulated wings and legs, two raven minifigures, one eagle minifigure, a small vehicle, and a jungle-themed stand with a blue CHI crystal.

Assembly Instructions

Follow these general guidelines for assembling your LEGO Razar's CHI Raider. Refer to the numbered instruction booklets included in your package for specific step-by-step visual guides.

1. **Unpack and Sort:** Carefully open all bags and sort the LEGO elements by color or type to make assembly easier. Ensure all pieces are present before beginning.
2. **Follow Numbered Steps:** LEGO instruction booklets are designed with clear, sequential steps. Build one section at a time, ensuring each piece is firmly connected.
3. **Pay Attention to Detail:** Observe the images in the instruction booklet closely for correct piece placement and orientation.

4. **Minifigure Assembly:** Assemble the included minifigures according to their specific instructions.
5. **Final Checks:** Once assembly is complete, review the model to ensure all parts are correctly attached and the structure is stable.

Note: If you encounter any difficulties or missing pieces, please refer to the Troubleshooting section.

Operating Features

The Razar's CHI Raider set is designed for interactive play. Explore the various features of your assembled model:

- **Articulated Wings:** The large wings of the Raider can be adjusted for different flight poses.
- **Cockpit:** Open the cockpit to place a minifigure inside for piloting the vehicle.
- **Missile Launchers:** Engage the spring-loaded missile launchers for action play. (*Specific mechanism details are in the assembly guide.*)
- **Landing Gear/Claws:** Position the vehicle's legs and claws for landing or attacking stances.
- **Minifigures and Accessories:** Utilize the included Razar, Rizzo, and Eris minifigures, along with their weapons and the CHI crystal stand, to create your own Legends of Chima adventures.

Maintenance

To ensure the longevity and cleanliness of your LEGO set, follow these simple maintenance tips:

- **Cleaning:** Use a soft, damp cloth to gently wipe down the LEGO bricks. For deeper cleaning, bricks can be washed by hand in lukewarm water (max 40°C / 104°F) with a mild detergent. Rinse thoroughly and air dry. Do not use hot water, harsh chemicals, or abrasive materials.
- **Storage:** Store your LEGO set in a cool, dry place away from direct sunlight to prevent discoloration and warping of plastic elements. Keep small pieces in a container to avoid loss.
- **Disassembly:** If disassembling the set, do so carefully to avoid stressing or breaking the bricks.

Troubleshooting

Should you encounter any issues during assembly or play, consider the following:

- **Missing Pieces:** Double-check all packaging and sorting areas. If a piece is genuinely missing, contact LEGO Customer Service (see Support section).
- **Assembly Errors:** Review the instruction booklet steps carefully. Sometimes a small piece is misplaced or oriented incorrectly, affecting subsequent steps. Disassemble the problematic section and re-build.
- **Loose Connections:** Ensure all bricks are pressed firmly together. LEGO connections should be snug.

Specifications

Feature	Detail
Model Number	70012
Brand	LEGO
Number of Pieces	412

Feature	Detail
Material	Plastic
Recommended Age	3 years and up
Product Dimensions (L x W x H)	35.6 x 5.1 x 25.4 cm
Item Weight	635 g

Warranty and Support

LEGO products are manufactured to high-quality standards. If you have any questions, require replacement parts, or need further assistance, please contact LEGO Customer Service.

- **Official LEGO Website:** Visit www.lego.com/service for support, missing parts requests, and frequently asked questions.
- **Contact Information:** Specific contact details (phone, email) can be found on the official LEGO website for your region.
- **Warranty:** LEGO products typically come with a limited warranty covering manufacturing defects. Please refer to the official LEGO website for detailed warranty terms and conditions.

LEGO and the LEGO logo are trademarks of the LEGO Group. ©2023 The LEGO Group. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00RYX1BMM

More documents and user manuals: **https://manuals.plus/**