

[Manuals.plus](#) /

› [Bauknecht](#) /

› Bauknecht BLPE 8200 PT Electric Oven User Manual

Bauknecht BLPE 8200 PT

Bauknecht BLPE 8200 PT Electric Oven User Manual

Model: BLPE 8200 PT

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Bauknecht BLPE 8200 PT electric oven. Please read these instructions thoroughly before using the appliance and keep them for future reference.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the oven is correctly installed by a qualified professional before use.
- Do not touch hot surfaces. Use oven mitts or pot holders.
- Supervise children when the oven is in use. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Never use water to extinguish grease fires. Smother the fire or use a dry chemical or foam-type extinguisher.
- Do not store flammable materials in or near the oven.
- Disconnect the appliance from the power supply before cleaning or maintenance.
- During pyrolytic cleaning, the oven reaches very high temperatures. Keep children and pets away. Ensure proper ventilation.
- The oven door may become hot during operation. Exercise caution.
- This appliance features a child safety lock. Refer to the operating section for activation and deactivation.

3. PRODUCT OVERVIEW

The Bauknecht BLPE 8200 PT is a high-performance built-in electric oven designed for modern kitchens. It offers a generous 73-liter capacity and an A-20% energy efficiency rating, ensuring excellent cooking results with reduced energy consumption.

Key Features:

- **Energy Efficiency Class A-20%:** Superior energy performance.
- **73 Liter Capacity:** Large cooking volume for various dishes.
- **Pyrolytic Self-Cleaning:** Advanced system for effortless cleaning.
- **12 Oven Functions:** Versatile cooking options including conventional, hot air, grill, defrost, and keep warm.
- **ProTouch Stainless Steel:** Specially treated surface to prevent rapid re-soiling and fingerprints.
- **Child Safety Lock:** Enhances safety in households with children.
- **Lightronic Regime:** Optimized lighting for better visibility inside the oven.
- **Timer Function:** For precise cooking control.

ProTouch Stainless Steel Finish

The oven features a ProTouch stainless steel finish, which is specially treated to resist fingerprints and reduce the rate at which the surface gets dirty, making it easier to maintain a clean appearance.



Image 3.1: Close-up of the Bauknecht BLPE 8200 PT oven's ProTouch stainless steel surface, highlighting its anti-fingerprint properties. This image also shows awards for innovation in kitchen design.

4. SETUP AND INSTALLATION

The Bauknecht BLPE 8200 PT is designed as a built-in appliance. Proper installation is crucial for safe and optimal performance. Installation should only be performed by a qualified technician in accordance with local regulations and the provided installation template.

4.1. Electrical Connection

Ensure the electrical supply matches the voltage and frequency specified on the appliance's rating plate. The oven must be properly earthed. Do not use extension cords or multiple adapters.

4.2. Installation Dimensions

Refer to the diagram below for precise dimensions and clearances required for installation into a kitchen cabinet. Ensure adequate ventilation around the appliance.



Image 4.1: Detailed diagram showing the required installation dimensions in millimeters for the Bauknecht BLPE 8200 PT built-in oven, including cabinet cut-out sizes and clearances.

4.3. First Use

Before first use, remove all packaging materials and accessories from the oven cavity. Clean the interior with a damp cloth. It is recommended to heat the empty oven at maximum temperature for approximately 30 minutes to burn off any manufacturing residues. Ensure good ventilation during this process.

5. OPERATING INSTRUCTIONS

Your Bauknecht BLPE 8200 PT oven features intuitive controls for selecting cooking functions, temperature, and time.

5.1. Control Panel

The oven is equipped with metal rotary knobs for function and temperature selection, and a digital display for time and additional settings. The control panel also includes a timer function.




Image 5.1: Front view of the Bauknecht BLPE 8200 PT electric oven, showing the control panel with rotary knobs and digital display.

5.2. Cooking Functions

The oven offers 12 functions to cater to various cooking needs. Rotate the function selector knob to choose your desired cooking mode.

- **Conventional Heating (Upper and Lower Heat):** Ideal for baking cakes, pastries, and roasting meats on one level.
- **Hot Air (Convection):** For cooking on multiple levels simultaneously without flavor transfer, suitable for baking and roasting.
- **Grill:** For grilling small quantities of meat, toast, or browning dishes.
- **Defrost Function:** Gently thaws frozen food.
- **Keep Warm Function:** Maintains food at serving temperature.
- **Fast Heating:** Quickly preheats the oven to the desired temperature.
- **Lightronic Regime:** Specific setting for optimized internal lighting during cooking.
- *Consult the full recipe book or specific function guide for detailed usage of all 12 functions.*

5.3. Setting Temperature and Time

After selecting a function, use the temperature selector knob to set the desired temperature. The digital display allows you to set cooking duration or a delayed start time using the timer function.

5.4. Child Safety Lock

To activate/deactivate the child safety lock, refer to the specific instructions in the full manual. This feature prevents accidental operation of the oven.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Bauknecht oven.

6.1. Pyrolytic Self-Cleaning

The pyrolytic cleaning function heats the oven cavity to very high temperatures (around 475°C), turning food residues into ash. This ash can then be easily wiped away once the oven has cooled.

- Remove all accessories (racks, trays, side supports) from the oven before starting a pyrolytic cycle.
- Wipe away any large spills or loose food particles.
- Ensure the kitchen is well-ventilated during the cleaning cycle.
- The oven door will lock automatically during the cycle and remain locked until the oven has cooled down to a safe temperature.
- After the cycle, once the oven is cool, wipe the interior with a damp cloth to remove the ash.

6.2. General Cleaning

- **Exterior:** Clean the ProTouch stainless steel surface with a soft cloth and a mild detergent. Avoid abrasive cleaners or scouring pads to prevent damage.
- **Oven Door:** The oven door may feature a "SimpleClean-Tür" design, allowing for easier cleaning. Refer to the specific instructions for removing and cleaning the inner glass panels if applicable.



SimpleClean-Tür

Dieses Szenebild ist beispielhaft. Alle Informationen entnehmen Sie bitte der Artikelbeschreibung.

Image 6.1: Close-up of the Bauknecht BLPE 8200 PT oven door, illustrating the "SimpleClean-Tür" feature designed for easier

maintenance and cleaning of the glass panels.

- **Accessories:** Wash racks and trays in warm soapy water or in a dishwasher if suitable.

7. TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Oven does not heat up.	No power supply; oven not switched on; timer not set.	Check power connection and circuit breaker. Ensure oven is switched on and a cooking time is set.
Oven light not working.	Light bulb is faulty.	Replace the oven light bulb (ensure oven is disconnected from power).
Excessive smoke during cooking.	Food spills or grease accumulation.	Clean the oven cavity thoroughly. Use a drip tray for fatty foods.
Pyrolytic cleaning not starting.	Oven door not fully closed; accessories still inside.	Ensure the door is securely closed and all accessories are removed.
Child lock activated.	Accidental activation.	Refer to the operating instructions for deactivating the child safety lock.

8. TECHNICAL SPECIFICATIONS

Specification	Value
Model	BLPE 8200 PT
Brand	Bauknecht
Type	Built-in Electric Oven
Color	Stainless Steel
Capacity	73 Liters
Energy Efficiency Class	A-20% (on a scale of A to G)
Conventional Energy Consumption	0.89 kWh
Hot Air Energy Consumption	0.79 kWh
Heating Methods	Hot Air (Heißluft), Convection (Umluft)
Special Features	Anti-fingerprint, Fast heating, Defrost function, Grill function, Keep warm function, Timer, Pyrolysis, Child safety lock

Specification	Value
Installation Type	Built-in (Einbau)
Door Opening	Front
Weight	40.5 Kilograms
Material	Stainless Steel

9. WARRANTY AND CUSTOMER SUPPORT

9.1. Warranty Information

Your Bauknecht BLPE 8200 PT oven comes with a manufacturer's warranty. Please refer to the warranty card included with your appliance for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

9.2. Customer Support

Should you encounter any issues not covered in the troubleshooting section, or require professional assistance, please contact Bauknecht customer service. You can find contact details on the official Bauknecht website or in the documentation provided with your appliance.

When contacting support, please have your appliance model number (BLPE 8200 PT) and serial number ready. The serial number is typically located on a label inside the oven door frame.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00RZ4JHR6>

More documents and user manuals: <https://manuals.plus/>