

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Nintendo](#) /

› [Nintendo New 3DS XL - Black Instruction Manual](#)

Nintendo REDSVAAA

Nintendo New 3DS XL - Black Instruction Manual

Model: REDSVAAA

INTRODUCTION

The Nintendo New 3DS XL is a portable gaming system that enhances the 3D gaming experience with super-stable 3D technology and additional control features. This manual provides essential information for setting up, operating, and maintaining your New Nintendo 3DS XL system.

PACKAGE CONTENTS

Please ensure all items are present before proceeding with setup:

- Nintendo New 3DS XL System
- Stylus
- MicroSDHC Memory Card (pre-installed)
- Quick-Start Guide
- AR Cards

Note: An AC adapter is not included with the New Nintendo 3DS XL. This system uses the same AC adapter as the Nintendo DSi, Nintendo 3DS, and Nintendo 2DS.

SETUP

1. Charging the Battery

Before first use, fully charge the system's battery. Connect a compatible AC adapter (sold separately) to the charging port on the back of the system and plug it into a wall outlet. The charge indicator light will illuminate orange while charging and turn off when fully charged.

2. Initial System Configuration

Upon powering on your New Nintendo 3DS XL for the first time, you will be guided through initial setup steps, including:

- Language selection

- Date and time settings
- User profile creation
- Internet connection setup

Ensure a stable internet connection for system updates and online features.

3. Linking Nintendo Account and Nintendo Network ID

To access the Nintendo eShop, download demos, and manage digital purchases, you will need to link a Nintendo Network ID (NNID) to your system and then link your NNID to a Nintendo Account. Follow the on-screen instructions in the System Settings menu under "Nintendo Network ID Settings" to create or link your NNID. Then, visit the Nintendo Account website on a computer or smart device to link your NNID to your Nintendo Account.

Your browser does not support the video tag.

Video: How to link your Nintendo Account and Nintendo Network ID. This video demonstrates the process of linking your Nintendo Account with your Nintendo Network ID, which is essential for accessing online services and digital content on your New Nintendo 3DS XL.

OPERATING YOUR SYSTEM

1. Powering On/Off

Press the POWER button located on the bottom right side of the system to turn it on. To turn off, hold the POWER button until the system powers down.

2. Basic Controls

- **Circle Pad:** Located on the left, used for analog movement.
- **C Stick:** A new feature on the right side, providing enhanced camera and control options in compatible games.
- **A/B/X/Y Buttons:** Standard action buttons on the right.
- **D-Pad:** Digital directional input on the left.
- **L/R Buttons:** Shoulder buttons.
- **ZL/ZR Buttons:** New additional shoulder buttons for enhanced control in compatible games.
- **HOME Button:** Returns to the HOME Menu.
- **START/SELECT Buttons:** Located below the A/B/X/Y buttons.



Image: A top-down view of the open Nintendo New 3DS XL, displaying the game "Super Monkey Ball 3D" on its top screen and game selection options on the bottom touch screen. The C Stick is visible on the right side.

3. 3D Functionality (Face Tracking 3D)

The New Nintendo 3DS XL features "super-stable 3D" technology, which uses the inner camera to track your face and adjust the 3D image in real-time. This provides a more comfortable and consistent 3D viewing experience compared to previous models.

- **3D Slider:** Located on the right side of the top screen, allowing you to adjust the depth of the 3D effect or turn it off completely.
- **Parental Controls:** It is recommended to restrict 3D mode for children aged 6 and under. This can be

configured in the System Settings.

Your browser does not support the video tag.

Video: New Nintendo 3DS XL Features. This video highlights key features of the New Nintendo 3DS XL, including the enhanced Face Tracking 3D and the new C Stick for improved controls.

4. Playing Games

The New Nintendo 3DS XL is compatible with all Nintendo 3DS games and most Nintendo DS games. Nintendo DS games will not appear in 3D.

- Insert game cards into the slot on the back of the system.
- Select the game icon from the HOME Menu to start playing.
- Some games may take advantage of the faster processing power for improved performance or graphics.

5. amiibo Support

The New Nintendo 3DS XL has built-in amiibo compatibility and NFC support. Place amiibo figures on the bottom screen to interact with compatible games.

MAINTENANCE

1. Cleaning Your System

Use a soft, dry cloth to clean the screens and exterior of the system. Avoid using harsh chemicals or abrasive materials. For stubborn smudges on the screen, a slightly damp cloth can be used, followed by immediate drying.

2. Battery Care

To prolong battery life, avoid exposing the system to extreme temperatures. If storing the system for an extended period, charge the battery to about 50% before storage and recharge it every six months.

3. Software Updates

Periodically check for system software updates via the System Settings menu. Updates can improve performance, add new features, and enhance security.

TROUBLESHOOTING

- **Unstable 3D Effect:** Ensure your face is within the camera's view and the system is held steadily. Adjust the 3D slider if needed.
- **System Not Responding:** Hold the POWER button for several seconds to force a shutdown, then restart the system.
- **Game Card Not Reading:** Ensure the game card is inserted correctly and fully into the slot. Clean the contacts on the game card if necessary.
- **Charging Issues:** Verify the AC adapter is securely connected to both the system and the power outlet. Use a compatible Nintendo AC adapter.

SPECIFICATIONS

Model Number	REDSVAAA
--------------	----------

Dimensions	1.5 x 7.09 x 5.12 inches
Weight	1 pound
Release Date	February 13, 2015
Manufacturer	Nintendo of America
Battery	1 Lithium Metal battery (included)
Language	English
Rating	Everyone



Image: A close-up side view of the Nintendo New 3DS XL, highlighting its slim profile and the hinge mechanism.

WARRANTY AND SUPPORT

For warranty information, technical support, or to register your product, please visit the official Nintendo support website or refer to the warranty card included in your product packaging. Keep your proof of purchase for warranty claims.