Dreambaby L1950

Dreambaby Royale Converta Play Yard Extension

Model: L1950

Introduction

This instruction manual provides important information for the safe and correct installation, use, and maintenance of your Dreambaby Royale Converta Play Yard Extension. This extension is designed to increase the width of the Dreambaby Royale Converta Play Yard (Model L849) by 49 inches. Please read and understand all instructions before assembly and use. Keep this manual for future reference.



Image of a single Dreambaby Royale Converta Play Yard Extension panel.

Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always ensure all components are securely fastened before use.
- Never leave children unattended in or around the play yard, even with the extension installed.
- This extension is designed for use only with the Dreambaby Royale Converta Play Yard (Model L849). Do not use

with other products.

- Regularly check the extension and play yard for loose parts, damage, or wear. Discontinue use if any damage is found.
- Keep small parts away from children during assembly.
- Do not allow children to climb on the extension or play yard.
- Ensure the play yard, once extended, is placed on a flat, stable surface.

Package Contents

Verify that all components are present before beginning assembly:

- 1 x Dreambaby Royale Converta Play Yard Extension Panel (49 inches)
- Connection hardware (e.g., pins, connectors)
- Instruction Manual

Setup Instructions

The Dreambaby Royale Converta Play Yard Extension is designed for easy integration with your existing Royale Converta Play Yard. Follow these steps to attach the extension:

1. **Prepare the Play Yard:** Ensure your Dreambaby Royale Converta Play Yard is disassembled or configured to allow for the addition of the extension panel. Identify the connection points where you wish to add the extension.
2. **Align the Extension:** Position the extension panel next to the desired section of the play yard. The connection points on the extension should align with those on the play yard panel.
3. **Connect Panels:** Insert the provided connection hardware (e.g., pins, clips) into the aligned holes on both the play yard panel and the extension panel. Ensure a secure and tight fit.
4. **Secure All Connections:** Once the extension is in place, double-check all connection points to ensure they are fully engaged and locked. The play yard and extension should form a rigid, stable structure.
5. **Final Check:** Gently push and pull on the assembled structure to confirm stability. There should be no wobbling or loose connections.



Image showing multiple Dreambaby Royale Converta Play Yard Extension panels connected in a linear configuration.



Image depicting the Dreambaby Royale Converta Play Yard with extensions configured as a wide safety gate.

Operating Instructions

Once the extension is securely installed, the Royale Converta Play Yard will function as a larger enclosure or wider gate. The extension itself does not have moving parts or operational features beyond its structural role in expanding the play yard.

- Refer to the original Dreambaby Royale Converta Play Yard manual for instructions on operating the gate mechanism and reconfiguring the play yard shape.
- Always ensure the gate is properly latched when in use.



Image of the Dreambaby Royale Converta Play Yard configured into a square play area, potentially including extension panels.



Image of the Dreambaby Royale Converta Play Yard configured into a hexagonal play area, demonstrating versatility with extension panels.

Care and Maintenance

To ensure the longevity and safety of your play yard extension, follow these care instructions:

- **Cleaning:** Wipe surfaces with a damp cloth and mild soap. Do not use abrasive cleaners or harsh chemicals, as these can damage the finish or material.
- **Inspection:** Periodically inspect all parts for wear, damage, or loose connections. Pay close attention to hinges, locking mechanisms, and panel joints.
- **Storage:** If storing the extension, ensure it is clean and dry. Store in a cool, dry place away from direct sunlight.

Troubleshooting

If you encounter issues with your Dreambaby Royale Converta Play Yard Extension, consider the following:

- **Unstable Connection:** Ensure all connection hardware is fully engaged and tightened. Re-check alignment of panels.
- **Difficulty Connecting:** Verify that you are using the correct extension for the Dreambaby Royale Converta Play Yard (Model L849). Ensure no debris is obstructing the connection points.
- **Damaged Parts:** If any part of the extension is damaged, discontinue use immediately and contact Dreambaby customer support for replacement parts or further assistance. Do not attempt to repair damaged components yourself.

Specifications

Feature	Detail
Model Number	L1950
Brand	Dreambaby
Material	Metal
Color	White
Item Dimensions	49 x 4 x 28 inches (L x W x H)
Item Weight	4.5 Kilograms
UPC	703588019500, 795418813464

Warranty Information

Dreambaby products are manufactured to high-quality standards. For specific warranty details, including coverage and duration, please refer to the warranty information provided with your original Dreambaby Royale Converta Play Yard or visit the official Dreambaby website. Keep your proof of purchase for any warranty claims.

Support and Contact Information

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Dreambaby customer support. Contact details can typically be found on the product packaging or the official Dreambaby website:

Website: www.dreambaby.com

Customer Service: Refer to the website for regional contact numbers or email addresses.

© 2024 Dreambaby. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question