Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gerber D502062PNVT

Gerber D502062PNVT Mid-Town Single Handle Tub and Shower Trim Kit User Manual

Model: D502062PNVT

Introduction

This manual provides essential information for the installation, operation, and maintenance of your Gerber D502062PNVT Mid-Town Single Handle Tub and Shower Trim Kit. This kit is designed to provide a single-handle control for both tub and shower functions, featuring a 2.0 GPM showerhead and a diverter on the spout. Please read these instructions thoroughly before beginning installation or use to ensure proper function and longevity of your product.




HOT



Image: Gerber D502062PNVT Mid-Town Single Handle Tub and Shower Trim Kit in Polished Nickel.

Safety Information

- Always turn off the main water supply before installing or servicing the trim kit.
- Wear appropriate personal protective equipment, such as safety glasses, during installation.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not use harsh chemicals or abrasive cleaners on the finish, as this may damage the product.

Package Contents

Verify that all components are present before beginning installation:

- Single handle for temperature and flow control
- Efficient Flow Mono Chic single function showerhead
- All brass 12-3/4-inch showerarm
- Tub spout with integrated diverter
- Mounting hardware

Note: The rough-in valve is NOT included with this trim kit. This trim kit is designed for use with Danze valve D112000BT or D115000BT.



Image: Individual components of the tub and shower trim kit, including handle, showerhead, shower arm, and tub spout.

Setup (Installation)

This section outlines the general steps for installing the trim kit. Refer to the specific instructions provided with your Danze rough-in valve (D112000BT or D115000BT) for detailed valve installation procedures.

Tools Required (Not Included):

- Adjustable wrench
- Screwdriver (Phillips and/or flathead)
- Plumber's tape
- Sealant (if required for tub spout)

Installation Steps:

1. **Prepare the Valve:** Ensure the rough-in valve (D112000BT or D115000BT) is correctly installed and secured within the wall according to its specific instructions. Flush the water lines to remove any debris.
2. **Install the Tub Spout:** Apply plumber's tape to the threads of the tub spout nipple extending from the wall. Thread the tub spout onto the nipple and tighten securely. Ensure the spout is properly aligned. Some installations may require a sealant at the wall connection.
3. **Install the Shower Arm and Showerhead:** Apply plumber's tape to the threads of the shower arm. Thread the shower arm into the shower outlet in the wall and tighten. Position the shower arm so it extends horizontally from the wall. Thread the showerhead onto the shower arm and hand-tighten, then use a wrench for a final quarter-turn.
4. **Install the Handle Trim:** Follow the instructions provided with your rough-in valve for installing the escutcheon plate and handle assembly. Typically, this involves securing the escutcheon to the valve body and then attaching the handle.
5. **Test for Leaks:** Once all components are installed, slowly turn on the main water supply. Check all connections for leaks. If leaks are detected, turn off the water supply and re-tighten the connections.



Image: An example of the installed tub and shower trim kit, showing the handle, showerhead, and tub spout.

Operating Instructions

Your Gerber D502062PNVT trim kit features a single handle for controlling water flow and temperature, and a diverter on the tub spout to switch between tub and shower functions.

- **Turning Water On/Off:** Lift the single handle to turn on the water. Push the handle down to turn off the water.
- **Adjusting Temperature:** Rotate the single handle left for hotter water and right for colder water.
- **Diverting Water to Shower:** With the water flowing from the tub spout, pull up the diverter knob located on the top of the tub spout. Water will then flow from the showerhead. Push the diverter knob down to return water flow to the tub spout.

Maintenance

Proper care and maintenance will ensure the lasting beauty and performance of your trim kit.

- **Cleaning the Finish:** The Permanence PVD finish is designed to resist corrosion and scratching. Clean the surface with a soft, damp cloth and mild soap. Rinse thoroughly with water and dry with a soft cloth.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, ammonia, bleach, or other harsh chemicals, as these can damage the finish and void your warranty.
- **Showerhead Maintenance:** Periodically clean the showerhead nozzles to remove mineral buildup. Many showerheads feature flexible rubber nozzles that can be cleaned by gently rubbing them with your fingers. For stubborn buildup, a solution of vinegar and water can be used.

Troubleshooting

If you encounter issues with your trim kit, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Low water flow from showerhead/tub spout	Mineral buildup in showerhead; partially closed shut-off valves; debris in valve.	Clean showerhead nozzles. Ensure shut-off valves are fully open. Consult valve manual for cleaning debris.
Water leaking from connections	Loose connections; worn seals/gaskets.	Turn off water supply and gently tighten connections. Replace worn seals or gaskets if necessary.
Diverter not working properly	Debris in diverter mechanism; worn diverter seal.	Flush the system. If issue persists, the diverter may need to be inspected or replaced by a professional.
Difficulty adjusting temperature	Issue with the valve cartridge.	Refer to your rough-in valve manual for cartridge adjustment or replacement.

If these solutions do not resolve the issue, please contact Gerber customer support or a qualified plumber.

Specifications

- **Model Number:** D502062PNVT
- **Brand:** Gerber (Danze by Gerber)
- **Finish Type:** Polished Nickel (Permanence PVD)
- **Material:** Metal (Brass handle)
- **Number of Handles:** 1
- **Mounting Type:** Wall Mount
- **Showerhead Flow Rate:** 2.0 Gallons Per Minute (GPM) at 80 psi
- **Included Components:** Handle, Shower Arm, Showerhead, Tub Spout with Diverter
- **Valve Compatibility:** Danze D112000BT or D115000BT (Valve Not Included)
- **Item Weight:** Approximately 6.9 pounds
- **UPC:** 719934025415

Warranty

This Gerber product is backed by a **Limited Lifetime Warranty** against manufacturer's defects. For specific details

regarding warranty coverage, terms, and conditions, please refer to the official warranty documentation provided with your purchase or visit the Gerber website.

Support

For technical assistance, replacement parts, or any questions regarding your Gerber D502062PNVT Mid-Town Single Handle Tub and Shower Trim Kit, please contact Gerber customer support:

- **Website:** Visit the official Gerber Store on Amazon or the main Gerber website for product information and support resources.
- **Phone:** Refer to the contact information provided in your product packaging or on the official Gerber website for customer service phone numbers.

When contacting support, please have your model number (D502062PNVT) and proof of purchase readily available.

© 2026 Gerber. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00S7477KW

More documents and user manuals: **https://manuals.plus/**