

[Manuals.plus](#) /

› [Cornat](#) /

› Cornat Pontos SPK1200 Cistern User Manual - 6/9 Litre Dual Flush

Cornat SPK1200

Cornat Pontos SPK1200 Cistern User Manual

Model: SPK1200 | Brand: Cornat

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Cornat Pontos SPK1200 cistern. This product features a 6/9 litre dual-flush technology, adjustable to 3/4.5 litres, designed for efficient water usage. Please read this manual thoroughly before installation and use to ensure proper function and safety.



Figure 1: Cornat Pontos SPK1200 Cistern. This image shows the main unit of the cistern in white, highlighting its compact design.

2. SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or maintenance work on the cistern.
- Ensure all connections are secure and watertight to prevent leaks.
- If you are unsure about any step, consult a qualified plumber.
- Keep small parts out of reach of children to prevent choking hazards.
- Do not use abrasive cleaners or harsh chemicals on the cistern's surface, as this may damage the finish.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- Cornat Pontos SPK1200 Cistern (White)
- Internal flush mechanism (pre-installed or separate)

- Internal fill valve (pre-installed or separate)
- Mounting hardware (screws, washers, seals)
- Water supply connection hose (may be included or sold separately)
- Instruction Manual (this document)



Figure 2: Product Packaging. The image displays the retail box for the Cornat Pontos cistern, indicating the dual-flush volumes.

4. SETUP AND INSTALLATION

4.1 Tools Required (Not Included)

- Adjustable wrench
- Screwdriver (Phillips or flathead, depending on screws)
- Drill (if new mounting holes are required)

- Level
- Pencil
- Sealant tape (PTFE tape)

4.2 Installation Steps

1. **Prepare the Area:** Turn off the main water supply to the toilet. Flush the toilet to empty the existing tank. Disconnect and remove the old cistern if applicable. Clean the mounting surface.
2. **Mount the Cistern:** Position the new Cornat Pontos cistern on the toilet bowl or wall mounting points. Use the provided mounting hardware to secure it firmly. Ensure the cistern is level before tightening all fasteners.
3. **Connect Water Supply:** Connect the water supply line to the fill valve inlet on the cistern. Use sealant tape on threaded connections to ensure a watertight seal. Hand-tighten, then use a wrench for a final quarter-turn. Do not overtighten.
4. **Connect to Toilet Bowl (if applicable):** If the cistern mounts directly to the toilet bowl, ensure the rubber gasket is correctly seated between the cistern and the bowl, and tighten the bolts evenly to prevent leaks.
5. **Adjust Fill Valve:** Once water supply is reconnected and turned on, the cistern will begin to fill. Adjust the fill valve float mechanism to set the desired water level. The water level should be below the overflow pipe.
6. **Adjust Flush Volume:** The Cornat Pontos cistern features adjustable dual-flush volumes. Refer to the internal mechanism for specific adjustment points. Typically, a small adjustment lever or screw allows switching between 6/9 litre and 3/4.5 litre flush options. Test both flush options to ensure proper operation.
7. **Leak Check:** After installation, turn on the main water supply slowly and check all connections for leaks. Tighten any leaking connections gently.

5. OPERATING INSTRUCTIONS

The Cornat Pontos SPK1200 cistern is equipped with a 2-volume dual-flush system, allowing you to choose between a full flush and a reduced flush for water conservation.

- **Full Flush (6 or 9 litres):** Press and hold the larger flush button (or push the lever fully down) for a complete flush. This is typically used for solid waste. The exact volume (6 or 9 litres) depends on the internal adjustment made during installation.
- **Reduced Flush (3 or 4.5 litres):** Press the smaller flush button (or push the lever partially down and release) for a water-saving flush. This is ideal for liquid waste. The exact volume (3 or 4.5 litres) depends on the internal adjustment made during installation.

Ensure the flush buttons or lever operate smoothly and return to their original position after each flush.

6. MAINTENANCE

6.1 Cleaning

- Clean the exterior of the cistern with a soft cloth and mild, non-abrasive cleaning solution.
- Do not use harsh chemicals, abrasive pads, or solvents, as these can damage the surface finish.
- For internal cleaning, turn off the water supply, flush the cistern to empty it, and then wipe down accessible surfaces.

6.2 Regular Checks

- Periodically check for leaks around the base of the cistern and all water connections.

- Ensure the fill valve is operating correctly and the water level is maintained below the overflow pipe.
- Inspect the flush mechanism for any signs of wear or obstruction.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Water continuously runs into the toilet bowl.	• Faulty flush valve seal. • Fill valve not shutting off completely. • Water level too high.	• Inspect and clean or replace the flush valve seal. • Adjust or replace the fill valve. • Adjust the fill valve float to lower the water level.
Weak or incomplete flush.	• Low water level in cistern. • Obstruction in flush mechanism. • Incorrect flush volume setting.	• Adjust fill valve to increase water level. • Check and clear any obstructions in the flush valve. • Ensure the flush volume is set correctly for a full flush.
Cistern not filling.	• Water supply turned off. • Blocked fill valve.	• Check if the water supply valve is open. • Inspect and clean or replace the fill valve.

8. SPECIFICATIONS

Model: SPK1200

Brand: Cornat

Type: Cistern (Toilet Tank)

Flush Technology: 2-volume dual flush

Flush Volumes: 6/9 litres (adjustable to 3/4.5 litres)

Color: White

Material: High-quality plastic

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the point of purchase or contact your retailer. For technical support or replacement parts, please contact Cornat customer service through their official website or the contact details provided with your product.

Please retain your proof of purchase for warranty claims.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question