

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lenox](#) /
- › [Lenox 853556 Disney Princess Jasmine Ornament Instruction Manual](#)

**Lenox 853556**

# Lenox Disney Princess Jasmine Ornament Instruction Manual

Model: 853556

## INTRODUCTION

---

This manual provides essential information for the proper handling, display, and care of your Lenox Disney Princess Jasmine Ornament. Please read these instructions carefully to ensure the longevity and enjoyment of your collectible.

## PRODUCT OVERVIEW

---

The Lenox Disney Princess Jasmine Ornament is a finely crafted collectible made from ivory china, accented with gold details. It features Princess Jasmine from Disney's Aladdin, holding a magic lamp. This ornament is designed for decorative display.



Image: Front view of the Lenox Disney Princess Jasmine Ornament. The ornament depicts Princess Jasmine in an ivory gown, holding a white magic lamp. She has dark hair and gold accents on her jewelry and clothing. A gold rope is attached for hanging.

## SETUP

---

### Unboxing

1. Carefully remove the ornament from its iconic seasonal red box.
2. Inspect the ornament for any visible damage before proceeding.

### Hanging the Ornament

1. Utilize the attached lustrous gold rope with tassel for hanging.
2. Select a secure location for display, such as a Christmas tree branch or an ornament stand, ensuring it is stable and not prone to being knocked down.

## OPERATING (DISPLAY)

---

This ornament is intended for decorative purposes. Once hung, ensure it is positioned away from direct sunlight, extreme temperatures, or areas with high humidity to preserve its finish and material integrity.

## MAINTENANCE

---

### Cleaning

- To clean, gently wipe the ornament with a soft, dry, lint-free cloth.
- Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the porcelain and gold accents.

### Storage

- When not on display, store the ornament in its original packaging or a dedicated ornament storage box.
- Store in a cool, dry place, away from extreme temperature fluctuations and direct sunlight.

## TROUBLESHOOTING

---

### Accidental Breakage

In the event of accidental breakage, Lenox offers a Breakage Replacement Program. Please refer to the warranty section or contact Lenox customer service for details on how to utilize this program.

### Preventing Damage

- Handle the ornament with care at all times.
- Keep out of reach of children and pets to prevent accidental drops or damage.
- Do not hang where it can be easily knocked down or subjected to strong vibrations.

## SPECIFICATIONS

---

Feature	Detail
Brand	Lenox
Model Number	853556
Material Type	Porcelain
Color	Ivory
Height	4 3/4 inches (approximately 12.06 cm)
Item Dimensions (L x W x H)	1 x 1 x 4.75 inches
Item Weight	0.29 Pounds (approximately 131.5 grams)
Theme	Aladdin Jasmine
Subject Character	Disney Princess Jasmine
Included Components	Ornament, Cord And String

## WARRANTY AND BREAKAGE REPLACEMENT PROGRAM

---

Lenox stands by the quality and durability of its products. This ornament is covered by Lenox's lifetime breakage replacement policy. This program is designed to guarantee many years of enjoyment to each customer.

For details on how to utilize the Breakage Replacement Program, please visit the official Lenox website or contact their customer service directly. Proof of purchase may be required.

## **CUSTOMER SUPPORT**

---

For further assistance, questions, or to learn more about Lenox products, please visit the official Lenox website or contact their customer service department. Contact information can typically be found on the Lenox brand website or within the product packaging.

You can also visit the [Lenox Store on Amazon](#) for additional product information and offerings.