



Manuals.plus /

› UNIX /

› UNIX WN06-57 Junior Shoe Fitter, Yellow

UNIX WN06-57

UNIX WN06-57 Junior Shoe Fitter Instruction Manual

This manual provides comprehensive instructions for the proper use, maintenance, and care of your UNIX WN06-57 Junior Shoe Fitter.

1. INTRODUCTION

The UNIX WN06-57 Junior Shoe Fitter is a specialized tool designed to assist in adjusting the fit of larger shoes, particularly for juniors, without causing discomfort or damage to the fingertips. It acts as a fingertip protection tool, making it easier to manage shoe sizes up to 26 cm. This device is made from durable EPR material, ensuring both flexibility and resilience for repeated use.



Figure 1: The UNIX WN06-57 Junior Shoe Fitter, shown in its original packaging. The packaging highlights its purpose for junior shoes, its ability to adjust larger sizes up to 26cm, and its soft, elastic material designed for fingertip protection.

2. SETUP

The UNIX WN06-57 Junior Shoe Fitter requires no complex assembly or setup. It is ready for immediate use directly out of its packaging. Simply remove the two shoe fitter pieces from the plastic bag.

- **Unpacking:** Carefully open the product packaging and remove the shoe fitter components.
- **Inspection:** Before first use, inspect both pieces of the shoe fitter for any signs of damage or manufacturing defects. If any issues are found, do not use the product and contact customer support.

3. OPERATING INSTRUCTIONS

The Junior Shoe Fitter is designed to help push the foot into shoes that might be slightly too large or difficult to put on, protecting the user's fingers from being pinched or scraped.

1. **Identify the Shoe:** Ensure the shoe you are attempting to adjust is suitable for the shoe fitter (up to 26 cm in size).
2. **Position the Fitter:** Hold one piece of the shoe fitter with the curved end facing towards the toe of the

shoe. The flatter, wider end should be held in your hand.

- 3. Insert into Shoe:** Gently insert the curved end of the fitter into the heel area of the shoe, positioning it against the inner back wall.
- 4. Guide the Foot:** While holding the shoe fitter in place, guide the foot into the shoe. The fitter will provide a smooth surface for the heel to slide against, preventing friction and protecting your fingers.
- 5. Remove the Fitter:** Once the foot is comfortably inside the shoe, carefully pull the shoe fitter out. Its flexible EPR material allows for easy removal.
- 6. Repeat for Other Shoe:** Use the second piece of the shoe fitter for the other shoe, following the same steps.

Note: The "slit (new function)" mentioned on the packaging refers to the design of the fitter which enhances its flexibility and fit, making it more effective in various shoe types.

4. MAINTENANCE

Proper maintenance will extend the life of your UNIX WN06-57 Junior Shoe Fitter.

- **Cleaning:** Wipe the shoe fitter with a damp cloth after use, especially if it comes into contact with dirt or moisture. Mild soap can be used if necessary.
- **Drying:** Ensure the shoe fitter is completely dry before storing to prevent any material degradation.
- **Storage:** Store the shoe fitter in a cool, dry place, away from direct sunlight and extreme temperatures. Keeping it in its original packaging or a small bag can help protect it from dust and damage.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the EPR material.

5. TROUBLESHOOTING

If you encounter any issues while using your shoe fitter, refer to the following table:

Problem	Possible Cause	Solution
Fitter feels too stiff or inflexible.	May be due to cold temperatures or improper storage.	Allow the fitter to warm up to room temperature. Ensure proper storage conditions.
Fitter slips out of shoe easily.	Incorrect positioning or shoe material is too slick.	Ensure the fitter is firmly pressed against the inner heel. Try a different angle of insertion.
Difficulty inserting foot even with fitter.	Shoe might be too small or foot is not properly aligned.	Verify shoe size is within the 26 cm limit. Adjust foot angle. Ensure the shoe opening is wide enough.

6. SPECIFICATIONS

Attribute	Detail
Model Name	WN06-57
Brand	UNIX ()
Material	EPR material
Color	Yellow
Size Compatibility	One size fits most (up to 26 cm)
Included Components	No (refers to additional components beyond the two fitter pieces)
Batteries Required	No
Package Dimensions	9.4 x 5.7 x 2.2 cm
Item Weight	20 g
Department	Unisex-Adult (though marketed for juniors)
First Available Date	15 February 2024

7. WARRANTY INFORMATION

Specific warranty information for the UNIX WN06-57 Junior Shoe Fitter is not provided in the product details. Please refer to the retailer's return policy or contact the manufacturer directly for any warranty-related inquiries.

8. SUPPORT

For further assistance, questions, or concerns regarding your UNIX WN06-57 Junior Shoe Fitter, please contact the manufacturer or your point of purchase. Keep your purchase receipt handy for any support requests.

Manufacturer: (Unix)

Online Resources: Check the official UNIX website or the retailer's product page for updated information or FAQs.