



Manuals.plus /

› Harper /

› Harper UD888 Compact Espresso Machine User Manual

## Harper UD888

# Harper UD888 Compact Espresso Machine User Manual

Model: UD888 (HAR3760139036772)

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

Please read all instructions carefully before using the Harper UD888 Espresso Machine. Retain this manual for future reference.

- **Electrical Safety:** Ensure the voltage rating on the appliance matches your local power supply. Do not immerse the appliance, cord, or plug in water or any other liquid.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Hot Surfaces:** Avoid contact with hot surfaces. Use handles or knobs. Steam and hot water can cause severe burns.
- **Maintenance:** Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- **Damage:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- **Intended Use:** This appliance is designed for household use only. Do not use outdoors.

## 2. PRODUCT OVERVIEW

---

The Harper UD888 is a compact espresso machine designed for ease of use and quick coffee preparation. It features a 1000W heating element and 2.5 bars of pressure.



Figure 2.1: Front view of the Harper UD888 Espresso Machine with the ceramic cup.

### Components:

- **Main Unit:** Houses the heating element and pump.
- **Water Reservoir:** 0.3L capacity, located at the top.
- **Filter Holder:** Holds the coffee filter.
- **Coffee Filters:** Two included for different coffee intensities.
- **On/Off Button:** Power control.
- **Drip Tray:** Removable and washable for easy cleaning.
- **Ceramic Cup:** 210ml capacity, included with the machine.

### 3. SETUP AND FIRST USE

---

Before using your Harper UD888 for the first time, follow these steps:

1. **Unpack:** Carefully remove all packaging materials and ensure all components are present.
2. **Clean:** Wash the water reservoir, filter holder, coffee filters, and ceramic cup with warm, soapy water. Rinse thoroughly and dry.
3. **Position:** Place the machine on a stable, flat, heat-resistant surface near an electrical outlet.
4. **Fill Water Reservoir:** Open the top lid and fill the 0.3L water reservoir with fresh, cold water. Do not exceed the MAX fill line.




Figure 3.1: Top view of the machine with the lid open for water filling.

5. **Initial Rinse Cycle:** Without adding coffee, place an empty cup on the drip tray. Plug in the machine and press the On/Off button. Allow the machine to run a full cycle to flush out any manufacturing residues. Discard the water. Repeat this process 2-3 times.

## 4. OPERATING INSTRUCTIONS

---

Follow these steps to brew coffee with your Harper UD888:

1. **Prepare Water:** Ensure the water reservoir is filled with fresh, cold water up to the desired level for your coffee.
2. **Insert Filter:** Choose one of the two provided filters based on your preferred coffee intensity. Place the filter into the filter holder.



Figure 4.1: The two included coffee filters.

3. **Add Coffee:** Add your preferred ground coffee or compatible coffee pod into the filter. Do not overfill.
4. **Place Cup:** Position the ceramic cup (or another suitable cup) on the drip tray directly under the coffee outlet.
5. **Start Brewing:** Plug in the machine and press the On/Off button. The machine will begin heating and then brewing.



Figure 4.2: The espresso machine in operation, brewing coffee.

6. **Finish Brewing:** The machine will automatically stop once the brewing cycle is complete.
7. **Enjoy:** Carefully remove your cup and enjoy your coffee.
8. **Power Off:** Press the On/Off button to turn off the machine if it does not automatically power down. Unplug the machine from the outlet after use.

## 5. CLEANING AND MAINTENANCE

---

Regular cleaning ensures optimal performance and extends the life of your espresso machine.

- **Daily Cleaning:** After each use, unplug the machine and allow it to cool. Remove and empty the filter holder and drip tray. Wash these parts, along with the filters and cup, with warm, soapy water. Rinse and dry thoroughly.
- **Exterior Cleaning:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or scourers.
- **Descaling:** Over time, mineral deposits can build up in the machine. Descale your machine every 2-3 months, or more frequently if you have hard water. Use a commercial descaling solution suitable for coffee machines, following the product's instructions. Alternatively, you can use a solution of white vinegar and water (1 part vinegar to 2 parts water). Run the descaling solution through the machine as if brewing coffee, then run several cycles of plain water to rinse thoroughly.
- **Storage:** When not in use for an extended period, ensure the machine is clean and dry. Store it in a cool, dry place.

## 6. TROUBLESHOOTING

---

If you encounter issues with your Harper UD888, consult the table below:

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; Power outlet fault.	Ensure the machine is securely plugged into a working outlet.
No coffee dispenses.	No water in reservoir; Filter clogged; Machine needs descaling.	Fill water reservoir. Clean the filter. Perform a descaling cycle.
Coffee is too weak.	Insufficient coffee grounds; Coarse grind; Wrong filter used.	Add more coffee grounds. Use a finer grind. Ensure the correct filter for desired strength is used.
Coffee overflows from filter.	Too much coffee grounds; Filter clogged.	Reduce coffee grounds. Clean the filter thoroughly.
Machine leaks.	Water reservoir not properly seated; Drip tray full.	Ensure water reservoir is correctly positioned. Empty and clean the drip tray.

## 7. SPECIFICATIONS

<b>Brand</b>	Harper
<b>Model Number</b>	HAR3760139036772 (UD888)
<b>Power</b>	1000 Watts
<b>Pressure</b>	2.5 bars
<b>Water Reservoir Capacity</b>	0.3 Liters
<b>Material</b>	Plastic, Stainless Steel, Ceramic
<b>Weight</b>	1.6 Kilograms
<b>Special Features</b>	Compact design, 2 filters (for strong/long coffee), Automatic On/Off button, Removable drip tray, Includes 210ml ceramic cup, Compatible with Senseo pods.

## 8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or contact Harper customer service directly. Keep your proof of purchase for any warranty claims.

For further assistance or to report a problem, please visit the official Harper website or contact their customer support line.