

Eglo 86715

Eglo MESTRE Wall Lamp (Model 86715)

Instruction Manual

Brand: Eglo | Model: 86715

1. INTRODUCTION

Thank you for choosing the Eglo MESTRE Wall Lamp. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before beginning installation and retain them for future reference.

2. SAFETY INSTRUCTIONS

- **Electrical Safety:** Always disconnect the power supply at the main fuse or circuit breaker before installation, maintenance, or bulb replacement.
- **Qualified Installation:** Installation should be performed by a qualified electrician or a competent person if you are unsure about electrical wiring.
- **Indoor Use Only:** This product is designed for indoor use in dry locations only. Do not expose to moisture or direct water.
- **Bulb Compatibility:** Use only bulbs with an E27 base and a maximum wattage of 60W. Exceeding the maximum wattage can cause overheating and damage to the fixture.
- **Handling:** Handle the glass shade with care to prevent breakage.
- **Cleaning:** Do not use abrasive cleaners or solvents on the lamp. Refer to the maintenance section for cleaning instructions.

3. PACKAGE CONTENTS

Please check that all parts are present and undamaged before installation.

- Eglo MESTRE Wall Lamp fixture
- Mounting hardware (screws, wall plugs)
- Assembly instructions

Note: Light bulb is not included and must be purchased separately.

4. SETUP AND INSTALLATION

Follow these steps to install your Eglo MESTRE Wall Lamp. If you are not confident with electrical installations, please consult a qualified electrician.

1. Prepare for Installation:

- Turn off the main power supply to the circuit where the lamp will be installed.
- Unpack all components and ensure they are intact.

2. Mark Mounting Points:

- Hold the mounting bracket against the wall at the desired installation location.
- Mark the drilling points using a pencil.

3. Drill Holes and Insert Wall Plugs:

- Drill holes at the marked points using an appropriate drill bit for your wall type.
- Insert the provided wall plugs into the drilled holes.

4. Secure Mounting Bracket:

- Attach the mounting bracket to the wall using the screws. Ensure it is firmly secured.

5. Connect Electrical Wires:

- Connect the household electrical wires to the lamp's wires according to local electrical codes (typically: Live to Live, Neutral to Neutral, Earth to Earth). Use appropriate terminal blocks.
- Ensure all connections are secure and insulated.

6. Attach the Fixture:

- Carefully align the lamp fixture with the mounting bracket and secure it with the provided screws.

7. Install the Bulb:

- Screw an E27 bulb (max 60W) into the lamp holder.

8. Restore Power:

- Turn the main power supply back on.
- Test the lamp to ensure it functions correctly.



Front view of the Eglo MESTRE Wall Lamp, showcasing its antique brown metal frame, decorative top scrollwork, and beige calcified glass shade.



The Eglo MESTRE Wall Lamp mounted on a light pink wall in a room, providing ambient lighting. A wooden cabinet with glass doors is visible in the background.

5. OPERATING INSTRUCTIONS

The Eglo MESTRE Wall Lamp is operated via a standard wall switch connected to its electrical circuit. Simply toggle the wall switch to turn the lamp on or off.

6. MAINTENANCE

- **Cleaning:** Ensure the power is off before cleaning. Wipe the metal parts with a soft, dry cloth. For the glass shade, use a soft, damp cloth and mild detergent if necessary, then dry thoroughly. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Bulb Replacement:**
 - Turn off the power supply at the main switch.
 - Allow the old bulb to cool completely before touching it.
 - Carefully unscrew the old E27 bulb.
 - Screw in a new E27 bulb (max 60W).
 - Restore power and test the lamp.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not light up	No power supply Faulty bulb Incorrect wiring	Check main power switch/circuit breaker Replace bulb Check wiring connections (consult electrician)
Light flickers	Loose bulb Incompatible bulb Loose wiring connection	Tighten bulb Ensure bulb is compatible (E27, max 60W) Check wiring connections (consult electrician)
Lamp overheats	Bulb wattage too high	Replace with a bulb that does not exceed 60W

If you experience any issues not listed here or if the problem persists, please contact Eglo customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Eglo
Model Name	MESTRE
Model Number	86715
Color	Antique Brown / Gold
Material	Steel Alloy, Glass
Shade Material	Calcified Glass
Shade Color	Beige

Feature	Detail
Style	Wall Lamp / Wall Sconce
Dimensions (L x W x H)	30 cm x 16 cm x 33.5 cm (11.81 x 6.3 x 13.19 inches)
Weight	Approx. 1.0 Count (Unit sales volume/weight)
Indoor/Outdoor Use	Indoor Only
Room Type	Kitchen, Hallway, Entrance
Power Source	AC/DC
Voltage	230 Volt
Bulb Base	E27
Max Wattage	60 Watt
Number of Lights	1
Compatible Bulb Type	LED (Energy-saving bulbs can be used)
Control Method	Wall Switch
Mounting Type	Wall Mounting
Assembly Required	No (Minor assembly for installation)
EU Energy Efficiency Label	A to G

33,5 cm / 13.19 inch



30 cm / 11.81 inch

Diagram showing the dimensions of the Eglo MESTRE Wall Lamp. The lamp measures approximately 30 cm (11.81 inches) in width and 33.5 cm (13.19 inches) in height.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. For technical support or further assistance, please visit the official Eglo website or contact their customer service department.

Eglo Website: www.eglo.com

