Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > NERF /
- > NERF Rebelle Codebreaker Crossbow Blaster Instruction Manual B1703

NERF B1703

NERF Rebelle Codebreaker Crossbow Blaster Instruction Manual

Model: B1703

1. Introduction

The NERF Rebelle Codebreaker Crossbow Blaster is designed for engaging play, featuring real crossbow action and an 8-dart rotating drum for rapid firing. This blaster includes a unique passcode lock mechanism for exclusive use and special Message Darts for secret communication. This manual provides essential information for the safe and proper use, setup, and maintenance of your blaster.

2. SAFETY INFORMATION

WARNING: To avoid injury:

- Do not aim at eyes or face.
- Use only darts designed for this product. Do not modify darts or the blaster.
- · Adult supervision is recommended during play.

Always ensure a clear play area and be aware of your surroundings to prevent accidents.



Image: Product packaging highlighting safety warnings and features.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1x NERF Rebelle Codebreaker Crossbow Blaster
- 7x Collectible Darts
- 1x Message Dart
- 1x Decoder



Image: The Codebreaker Crossbow Blaster shown with its accompanying darts and decoder.

4. SETUP

4.1. Assembly

The NERF Rebelle Codebreaker Crossbow Blaster requires no assembly. It is ready for use directly out of the packaging.

4.2. Loading Darts

- 1. Ensure the blaster is not primed.
- 2. Insert darts one by one into the 8-dart rotating drum.
- 3. Push each dart firmly until it is fully seated within the drum. Darts must be pushed all the way in for proper firing.

4.3. Setting the Passcode

The blaster features a passcode lock for exclusive use. Refer to the specific instructions included in the physical packaging for setting and resetting your unique passcode. This mechanism prevents unauthorized firing of the blaster.

5. OPERATING INSTRUCTIONS

5.1. Firing the Blaster

- 1. Ensure the passcode lock is disengaged (if set).
- 2. Pull back the priming handle (bowstring) until it locks into place. This primes the blaster.
- 3. Aim at your target, ensuring it is clear of people or animals.
- 4. Pull the trigger to fire a dart.
- 5. To rapid-fire, continue pulling the priming handle and trigger in quick succession. The 8-dart rotating drum will advance automatically.



Image: Demonstrating the proper way to hold and aim the blaster.

5.2. Using Message Darts and Decoder

The Codebreaker Crossbow includes a special Message Dart and a decoder. Write secret messages on the Message Dart and use the decoder to reveal messages written by others. This feature adds an element of espionage to your play.



Image: A closer view of the blaster, illustrating the dart drum and firing mechanism.

6. MAINTENANCE

To ensure the longevity and optimal performance of your blaster:

- Keep the blaster clean and free of dust and debris. Wipe with a dry cloth as needed.
- Store the blaster and darts in a cool, dry place away from direct sunlight.
- Do not use water or chemical cleaners on the blaster.

7. TROUBLESHOOTING

• Darts not firing or jamming:

Ensure darts are fully inserted into the drum. If darts are not pushed all the way in, the blaster may

not fire correctly. Check for any damaged darts and replace them if necessary.

· Trigger locking unexpectedly:

The trigger lock mechanism can be sensitive. If the trigger locks, ensure your passcode is correctly entered and the lock is fully disengaged. Adjust the middle dial of the trigger lock if it feels too sensitive or is not engaging/disengaging properly.

· Reduced firing range:

Ensure darts are in good condition and not worn out. Only use official NERF darts designed for this product.

8. SPECIFICATIONS

• Model Number: B1703

• Brand: NERF

Dart Capacity: 8 darts (rotating drum)
Firing Range: Up to 75 feet (22 meters)
Product Dimensions: 7.3 x 50.2 x 29.8 cm

• Item Weight: 703 g

• Recommended Age: 8 years and up

Assembly Required: NoBatteries Required: No

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official NERF website. Contact details for customer service are typically provided on the product packaging or manufacturer's website.

© 2025 NERF. All rights reserved.

Related Documents - B1703



Nerf Hyper MACH-100 Blaster: Operating and Safety Instructions

Comprehensive guide for the Nerf Hyper MACH-100 blaster, detailing how to load, fire, clear jams, store the blaster, and important safety precautions. Includes battery information and product compatibility.



Nerf Roblox Arsenal Pulse Laser Blaster Instructions

Comprehensive guide on how to operate, load, fire, and clear jams for the Nerf Roblox Arsenal Pulse Laser motorized dart blaster. Includes safety warnings and battery information.



NERF Modulus ECS-10 Blaster: Instructions and Safety Guide

Official instructions and safety information for the NERF Modulus ECS-10 blaster by Hasbro. Learn how to load, fire, maintain, and safely use your NERF blaster.



Nerf N-Strike Elite Strongarm Blaster: User Guide

Official instructions for the Nerf N-Strike Elite Strongarm toy blaster. Learn how to load darts, fire single shots, and use the slam-fire feature for rapid firing. Includes safety warnings and product details.



Nerf Ultra One Blaster: Assembly, Loading, and Firing Instructions

A comprehensive guide to assembling, loading, and operating the Nerf Ultra One Motorized Blaster, including important safety information and troubleshooting tips.



Nerf Fortnite AR-L Blaster: Instructions and Features

This document provides instructions and details for the Nerf Fortnite AR-L Blaster, including how to clear jams, insert batteries, load and fire darts, and store the blaster. It features multilingual support and highlights key components like the trigger, flip-up sight, tactical rail, and acceleration button.

Documents - NERF - B1703



[pdf]

2015 CANADIAN MEDIA KIT hasbro en CA corporate upload |||

GET READY FOR SILLY, SPUDTACULAR ADVENTURES WITH MR. POTATO HEAD The MR. POTATO HEAD cast of char ... ODEBREAKER Crossbow Age: 8 years and up/Approximate Retail Price: 32.99/Available: Fall 2015/SKU: **B1703** Girls can keep their secrets safe with the NERF REBELLE CODEBREAKER Crossbow. This eight dart...

lang:en score:9 filesize: 13.68 M page_count: 190 document date: 2015-06-22



[pdf]

DOSSIER DE PRESSE CANADIEN 2015 hasbro fr CA corporate upload |||

M. PATATE S APPRTE VIVRE DES AVENTURES AUSSI LOUFOQUES QU PATATANTES Les personnages de la gamme ... EBREAKER ge : 8 ans et plus/Prix de dtail approximatif : 32,99 /En vente : automne 2015/Article : **B1703** Les filles pourront protger leurs secrets groe I arbalte CODEBREAKER de NERF REBELLE. Cette ...

lang:fr score:8 filesize: 12.61 M page_count: 183 document date: 2015-06-22