

[Manuals.plus](#) /

> [hofstein](#) /

> Hofstein Rom LED Floor Lamp with Dimmer and Reading Arm, Bronze - Instruction Manual

hofstein 8505

Hofstein Rom LED Floor Lamp with Dimmer and Reading Arm, Bronze

Model: 8505 | Brand: Hofstein

1. INTRODUCTION

Thank you for choosing the Hofstein Rom LED Floor Lamp. This elegant floor lamp features a main uplighter and an adjustable reading arm, both equipped with energy-efficient LEDs. The integrated stepless dimmer allows for precise control over light intensity, providing optimal illumination for various activities. This manual provides essential information for safe installation, operation, and maintenance of your new lamp.



Figure 1: The Hofstein Rom LED Floor Lamp in a modern living room environment, showcasing its bronze finish and dual light sources.

2. SAFETY INSTRUCTIONS

- Read all instructions carefully before assembly and use.
- This product is designed for **indoor use only**. Do not expose to moisture or extreme temperatures.
- Ensure the power supply voltage matches the lamp's requirements before plugging in.
- Always unplug the lamp from the power outlet before cleaning, maintenance, or moving.
- Do not attempt to modify or repair the lamp. Repairs should only be performed by qualified personnel.
- The LED light sources are **non-replaceable**. Do not attempt to remove or replace them.
- Keep packaging materials out of reach of children to prevent choking hazards.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all components are present and undamaged. If any parts are missing or damaged, contact your retailer immediately.

- Lamp Base

- Main Pole Sections (typically 2-3 sections)
- Uplighter Head with integrated LED
- Adjustable Reading Arm with integrated LED
- Power Adapter/Cable
- Assembly Tools (e.g., Allen key, wrench)



Figure 2: Overview of all parts included in the package, laid out for easy identification prior to assembly.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Hofstein Rom LED Floor Lamp:

1. Place the lamp base on a flat, stable surface.
2. Carefully thread the power cable through the main pole sections.
3. Screw the first main pole section securely into the lamp base. Ensure it is tightened firmly to prevent wobbling.
4. Attach subsequent main pole sections, twisting them clockwise until fully secured.
5. Connect the adjustable reading arm to the designated point on the main pole. Ensure the electrical connection is secure.

6. Attach the uplighter head to the top of the final main pole section, ensuring all connections are firm.
7. Once fully assembled, ensure all connections are tight and the lamp is stable.
8. Plug the power adapter into a suitable wall outlet.




Figure 3: Diagram illustrating the assembled lamp with key dimensions, including its total height of 180 cm and base diameter of 25 cm.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off and Dimming

The Hofstein Rom LED Floor Lamp features a built-in stepless dimmer switch located on the main pole. This switch controls both the main uplighter and the reading arm simultaneously.

- To turn the lamp **ON**, press the dimmer switch briefly.
- To turn the lamp **OFF**, press the dimmer switch briefly again.
- To **dim** the light, press and hold the dimmer switch. The light intensity will gradually increase or decrease. Release the switch when the desired brightness is reached.

5.2 Adjusting the Reading Arm

The reading arm is flexible and can be adjusted to direct light precisely where needed. Gently bend the arm to position the light for reading or other tasks. Avoid excessive force or bending beyond its natural range of motion.



Figure 4: Visual representation of the stepless dimmer functionality, demonstrating light output from 100% to off.

6. MAINTENANCE

6.1 Cleaning

To clean your lamp, ensure it is unplugged from the power outlet. Use a soft, dry cloth to wipe down the metal surfaces. Do not use abrasive cleaners, solvents, or polishes, as these can damage the finish. For the light diffusers, a slightly damp cloth can be used, followed by a dry cloth.

6.2 LED Light Source

The LED light sources in this lamp are integrated and have an average lifespan of 20,000 hours. They are not designed to be replaced by the user. If the LEDs cease to function, the entire lamp unit may require professional servicing or replacement.

7. TROUBLESHOOTING

If you encounter issues with your lamp, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply. Loose connection.	Check if the power adapter is securely plugged into the wall outlet and the lamp. Test the outlet with another device. Ensure all lamp sections are tightly screwed together.
Dimmer is not responding.	Power interruption. Faulty switch.	Unplug the lamp for 30 seconds and plug it back in to reset. If the issue persists, contact customer support.
Light flickers or is inconsistent.	Unstable power. Internal wiring issue.	Ensure the lamp is plugged into a stable power source. Avoid using with extension cords or power strips that may be overloaded. If flickering continues, contact customer support.

If these solutions do not resolve the issue, please contact Hofstein customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	8505
Dimensions (H x W x D)	180 cm x 50 cm x 26 cm
Weight	5.66 kg
Material	Metal (Antique Brass finish), Glass, Plastic
Light Source	Integrated LED (non-replaceable)
Number of Lights	2 (1 Uplighter, 1 Reading Arm)
Uplighter Power	18 Watt LED
Reading Arm Power	5 Watt LED
Total Lumen Output	1440 Lumen
Color Temperature	3000 Kelvin (Warm White)
Dimmable	Yes, stepless dimmer via built-in switch
Lifespan	Approx. 20,000 hours
Switching Cycles	Approx. 10,000 cycles
Energy Efficiency Class	F
Usage	Indoor use only



Figure 5: Energy label indicating the lamp's efficiency class.

9. WARRANTY AND SUPPORT

Hofstein is committed to providing high-quality lighting solutions. Your satisfaction is our priority. This product is subject to a 30-day return policy from the date of purchase, allowing for refunds or replacements in case of defects or dissatisfaction.

For any questions, technical support, or warranty claims, please contact Hofstein customer service. Our dedicated team is ready to assist you and ensure a smooth resolution to any issues you may encounter.

You can find more information and contact details on the official Hofstein website or through your retailer.