CalExotics SE-0499-85-3

CalExotics 8-Function Classic Chic Curve Vibrator User Manual

Model: SE-0499-85-3

Introduction Setup Operation Maintenance Troubleshooting Specifications Warranty Support

Introduction

This manual provides instructions for the safe and effective use of the CalExotics 8-Function Classic Chic Curve Vibrator. Please read these instructions carefully before first use and retain for future reference. This device is designed for personal use to provide vibration, pulsation, and escalation functions.



Image: The CalExotics 8-Function Classic Chic Curve Vibrator in black, showcasing its ergonomic design.

Setup

1. Battery Installation

1. Locate the battery compartment cap at the base of the vibrator. This is typically a twist-off or pull-off cap.
2. Twist or pull the cap to open the battery compartment.
3. Insert two (2) AAA batteries (not included) into the compartment, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Securely replace the battery compartment cap, ensuring it is tightly sealed to maintain the waterproof integrity of the device.



Image: Close-up of the vibrator's base, indicating the battery compartment area. The base features a silver ring and an '8X' marking, suggesting the location for battery access.

2. Initial Cleaning

Before first use, and after every subsequent use, clean the vibrator thoroughly. Refer to the Maintenance section for detailed cleaning instructions.

Operation

1. Powering On/Off

- To turn the device **ON**, press and hold the power button (usually located on the base or control panel) for 2-3 seconds. The device will start on its lowest setting.
- To turn the device **OFF**, press and hold the power button again for 2-3 seconds.

2. Function Selection

- The vibrator features 8 intense functions of vibration, pulsation, and escalation.
- Once the device is on, short presses of the power button will cycle through the different functions.
- Experiment with each function to find your preferred setting.

3. Waterproof Use

This device is waterproof and can be used in or out of water. Ensure the battery compartment cap is securely fastened before exposing the device to water.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and operation of the CalExotics 8-Function Classic Chic Curve Vibrator. This video shows the product's design and how to use its functions.

Maintenance

1. Cleaning

- Always clean the vibrator before and after each use.
- Wash the device with warm water and a mild, toy-safe soap or a specialized toy cleaner.
- Rinse thoroughly to remove all soap residue.
- Pat dry with a lint-free cloth or allow to air dry completely before storing.
- Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the material.

2. Storage

- Store the vibrator in a cool, dry, and clean place.
- Keep it away from direct sunlight and extreme temperatures.
- If storing for extended periods, remove the batteries to prevent leakage and damage to the device.
- Avoid storing with other toys made of different materials, especially silicone, to prevent material degradation or reactions.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Batteries are dead or low. Batteries are inserted incorrectly. Battery compartment cap is not fully secured.	Replace with fresh AAA batteries. Ensure batteries are inserted with correct polarity (+/-). Tighten the battery compartment cap securely.
Vibration is weak or inconsistent.	Batteries are low.	Replace with fresh AAA batteries.

Specifications

Model Number: SE-0499-85-3

Dimensions: 1.75 x 2.25 x 8.25 inches

Weight: 2.72 ounces

Power Source: 2 x AAA batteries (not included)

Material: Acrylonitrile Butadiene Styrene (ABS), Plastic, Silicone

Color: Black

Functions: 8 vibration, pulsation, and escalation patterns

Waterproof: Yes






Image: Product packaging displaying key features and specifications in multiple languages, including the 8 functions, satin finish, easy push-button operation, body-safe material, and waterproof design.

Warranty Information

The CalExotics 8-Function Classic Chic Curve Vibrator is backed by a **1-year limited manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or failure to follow the instructions in this manual. For warranty claims or further details, please refer to the contact information provided in the Support section.

Customer Support

If you have any questions, require assistance, or need to make a warranty claim, please contact CalExotics customer service. Specific contact details can typically be found on the official CalExotics website or on the product packaging. For general inquiries, visit the official CalExotics website: www.calexotics.com

© 2023 CalExotics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question