

[manuals.plus](#) /

› [Astralpool](#) /

› [AstralPool Pulit Advance +5 Robotic Pool Cleaner User Manual](#)

## Astralpool Pulit Advance +5

# AstralPool Pulit Advance +5 Robotic Pool Cleaner User Manual

Model: Pulit Advance +5

## INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your AstralPool Pulit Advance +5 Robotic Pool Cleaner. Please read this manual thoroughly before using the appliance.



Image: The AstralPool Pulit Advance +5 Robotic Pool Cleaner, a blue and dark blue unit with a handle, designed for efficient pool cleaning.

## IMPORTANT SAFETY INSTRUCTIONS

- Always disconnect the power supply before performing any maintenance or cleaning.

- Do not operate the cleaner if the power cable is damaged.
- Ensure the power supply unit is placed at least 3.5 meters (11.5 feet) from the edge of the pool.
- Do not enter the pool while the cleaner is operating.
- This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

## SETUP AND INITIAL USE

---

### Unpacking

Carefully remove all components from the packaging. Verify that all parts are present:

- Pulit Advance +5 Robotic Pool Cleaner unit
- Power supply unit
- 18m self-floating cable
- Transport caddy
- PVA brushes
- Standard filter cartridges (fine and coarse filters available separately)



Image: The AstralPool Pulit Advance +5 cleaner shown with its transport caddy and the coiled self-floating cable, ready for setup.

### Connecting the Cleaner

1. Place the power supply unit in a shaded area, at least 3.5 meters (11.5 feet) from the pool edge.
2. Connect the self-floating cable to the cleaner unit. Ensure a secure connection.
3. Connect the other end of the self-floating cable to the power supply unit.
4. Plug the power supply unit into a grounded electrical outlet.

## OPERATING INSTRUCTIONS

## Placing the Cleaner in the Pool

Gently lower the cleaner into the pool. Allow it to sink to the bottom, releasing any trapped air bubbles. Ensure the cable is not tangled.



Image: A front view of the AstralPool Pulit Advance +5, highlighting its compact design and the "Powered by Aquabot" branding.

## Starting a Cleaning Cycle

Once the cleaner is at the bottom of the pool and the power supply is connected, press the ON/OFF button on the power supply unit. The cleaner will begin its cleaning cycle automatically.

The Pulit Advance +5 operates in cycles of 1.5 to 2 hours, utilizing its Aquasmart electronic control system to efficiently clean the pool floor, walls, and waterline. The effective vibrating cleaning brush dislodges dirt from all surfaces.

## Adjustable Suction Nozzles

The cleaner features height-adjustable suction nozzles to ensure perfect adaptation to any pool type, optimizing cleaning performance.

## MAINTENANCE

### Cleaning Filter Cartridges

The Pulit Advance +5 features top-access filter cartridges, making them easy to clean without direct contact with dirt. A LED indicator on the power supply unit will illuminate when the filter needs cleaning.

1. Disconnect the power supply unit from the electrical outlet.
2. Remove the cleaner from the pool.
3. Open the top access cover of the cleaner.
4. Remove the filter cartridges.
5. Rinse the cartridges thoroughly with a garden hose until all debris is removed.
6. Reinsert the clean filter cartridges and close the top access cover.




Image: The AstralPool Pulit Advance +5 with its top filter compartments open, demonstrating the easy access for cleaning the filter cartridges.

## Brush Maintenance

Periodically inspect the PVA brushes for wear and tear. Replace them if they show significant damage to ensure optimal cleaning performance.



Image: An underside view of the AstralPool Pulit Advance +5, clearly showing its PVA brushes and traction system, essential for effective pool cleaning.

## Cable Management

After each use, carefully coil the self-floating cable to prevent tangling and damage. Store the cleaner and cable in a dry, shaded area.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Cleaner does not start	No power to unit; Cable not properly connected; Power supply unit malfunction.	Check power outlet; Ensure all cable connections are secure; Contact customer support if power supply unit is faulty.
Poor cleaning performance	Clogged filter cartridges; Worn brushes; Obstruction in suction nozzles.	Clean filter cartridges; Inspect and replace brushes if necessary; Check and clear suction nozzles.
Cleaner does not climb walls	Clogged filter; Air trapped in cleaner; Water chemistry imbalance (e.g., high calcium).	Clean filter; Tilt cleaner to release air bubbles; Check pool water chemistry.
Cable tangles	Improper cable deployment; Excessive cable length in pool.	Ensure cable is fully extended and untangled before placing cleaner; Only use necessary cable length.

## SPECIFICATIONS

Feature	Detail
Model Number	Pulit Advance +5
Cleaning Area	Pool floor, walls, and waterline
Cleaning Cycle Time	1.5 - 2 hours
Cable Length	18 meters (self-floating)
Filter Type	Top-access filter cartridges (standard, fine, coarse)
Brushes	PVA brushes
Control System	Aquasmart electronic control
Dimensions (L x W x H)	0.16 x 0.16 x 0.14 cm (Product only, not shipping dimensions)
Weight	500 grams (Product only, not shipping weight)
Material	Plastic

## WARRANTY INFORMATION

Specific warranty terms and conditions for the AstralPool Pulit Advance +5 Robotic Pool Cleaner are typically provided at the point of purchase or within separate documentation included with the product. Please refer to your purchase receipt and the warranty card for details regarding coverage period, what is covered, and how to make a claim.

*Note: The product description mentions "Information indisponible sur les pièces détachées" (Information unavailable on spare parts). This suggests that spare parts availability might not be guaranteed or easily accessible.*

## CUSTOMER SUPPORT

For technical assistance, spare parts, or warranty claims, please contact your authorized AstralPool dealer or visit the official AstralPool website for support contact information.

It is recommended to have your product model number (Pulit Advance +5) and purchase date available when contacting support.

© 2024 AstralPool. All rights reserved.

## Related Documents - Pulit Advance +5

	<p><a href="#">AstralPool QB800 Robotic Pool Cleaner: User Manual &amp; Guide</a></p> <p>This manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of the AstralPool QB800 Robotic Pool Cleaner.</p>
	<p><a href="#">AstralPool Classic Plus Multiport Valve: Installation, Maintenance, and Troubleshooting Guide</a></p> <p>Detailed guide for the AstralPool Classic Plus multiport valve (model 73950-1000). Covers valve operations, step-by-step installation, essential maintenance procedures, a complete parts list, and common troubleshooting solutions for swimming pool filter systems.</p>
	<p><a href="#">Astralpool Rousillon Automatic Pool Cover Installation and Maintenance Manual</a></p> <p>A comprehensive guide for the installation and maintenance of the Astralpool Rousillon automatic pool cover, detailing components, civil engineering requirements, assembly steps, electrical installation, and safety features.</p>
	<p><a href="#">Astralpool Adjustable Bottom Nozzle Installation and Maintenance Manual</a></p> <p>Comprehensive guide for installing and maintaining the Astralpool Adjustable Bottom Nozzle, covering product features, step-by-step installation, assembly, start-up, and technical specifications for optimal swimming pool cleaning.</p>



## [Astralpool Winterizer Copper Free: Pool Maintenance Guide](#)

Comprehensive guide to using Astralpool Winterizer Copper Free for complete winter pool maintenance, preventing algae and bacteria growth. Includes product properties, characteristics, instructions, and dosage recommendations.



## [AstralPool E Series Saltwater Chlorinator Installation Manual](#)

Comprehensive installation, operation, and maintenance guide for the AstralPool E Series Saltwater Chlorinator (E25/E35). Covers safety warnings, system overview, plumbing, electrical connections, water chemistry, operation modes, electrode maintenance, winterizing, and troubleshooting.