

HAWKINS HC50

Hawkins 5 Litre Contura Pressure Cooker (HC50) Instruction Manual

1. PRODUCT OVERVIEW

This manual provides essential information for the safe and efficient use of your Hawkins 5 Litre Contura Pressure Cooker, model HC50. This aluminium inner lid cooker is designed for cooking for 5 to 7 persons.



Image 1: Hawkins 5 Litre Contura Pressure Cooker (HC50).

2. KEY FEATURES

- **Capacity:** Ideal for cooking for 5 to 7 persons.
- **Curved Body:** Facilitates easy stirring and provides better visibility of food.
- **Easy Food Removal:** The design aids in simpler removal of cooked food.
- **Inner-Fitting Safety Lid:** Ensures the lid will not open until internal pressure has completely fallen, enhancing safety.
- **Material:** Constructed from pure, virgin aluminium.
- **Pressure Regulator:** New improved pressure regulator operates at 1 kg/cm² (15 Pounds/Square Inch) pressure.
- **Thermal Efficiency:** Heats fast and evenly, saving fuel and cooking faster.
- **Safety Valve:** Located under the lid handle bar for additional safety.
- **Gasket:** Designed to last longer due to reduced rubbing during opening or closing.

Hawkins Contura Features & Benefits

1. New improved Pressure Regulator

2. Operates at 1 kg/cm²
(15 Pounds/Square Inch) pressure

3. Saves more fuel

4. Thermal-efficient:
heats fast and evenly

5. Cooks faster

6. Curved body for
easy stirring



7. Pressure-locked Safety Lid –
cannot be opened while there is
pressure inside

8. Safety Valve under Lid
Handle Bar for greater safety

9. Gasket lasts longer since
it is not rubbed during
opening or closing

10. Made from pure,
virgin aluminium

Backed by
India's Widest Network of
Hawkins Authorised
Service Centres

**692 SERVICE CENTRES IN
INDIA, NEPAL AND BHUTAN**

As at 2019



Image 2: Visual representation of key features and benefits.

3. UNPACKING AND COMPONENTS

Upon receiving your Hawkins Contura Pressure Cooker, inspect the packaging for any damage. The strong, sealed product carton ensures your cooker reaches you in factory-fresh condition.

The strong, sealed product carton...




..ensures your cooker reaches you in factory-fresh condition.

Image 3: Product carton.


Carefully remove all contents from the box. The following items should be included:

What is Inside the Carton

1. Pressure Cooker Lid



2. Rubber Gasket



3. Vent Weight



4. Guarantee Card



5. Cookbook



6. Service Centre Directory



7. Cooker Body



Image 4: Contents of the carton.

1. Pressure Cooker Lid
2. Rubber Gasket
3. Vent Weight (Pressure Regulator)
4. Guarantee Card
5. Cookbook (may include recipes and instructions)
6. Service Centre Directory
7. Cooker Body

4. SETUP

Before first use, wash the cooker body and lid thoroughly with warm soapy water. Rinse and dry completely. Ensure the rubber gasket is properly seated in the lid's groove. Place the vent weight (pressure regulator) onto the vent tube on the lid.

5. OPERATING INSTRUCTIONS

5.1. Filling the Cooker

- Add food and liquid to the cooker. Do not fill the cooker more than two-thirds full. For foods that expand during cooking (e.g., rice, lentils), do not fill more than half full.
- Ensure the rim of the cooker and the gasket are clean and free from food particles.

5.2. Closing the Lid

- Place the lid on the cooker body, aligning the lid handle with the body handle.
- Press down firmly on the lid and turn the lid handle until it locks securely under the body handle. The inner-fitting design ensures a tight seal.

5.3. Cooking

- Place the cooker on a heat source (gas, electric, or induction).
- Cook on high heat until steam starts to escape steadily from the vent tube and the vent weight begins to whistle.
- Reduce the heat to maintain a steady flow of steam and whistling. Cook for the time specified in your recipe.

5.4. Opening the Cooker

- After cooking, remove the cooker from the heat source.
- Allow the pressure to drop naturally. Do NOT attempt to open the lid until all pressure has been released. The inner-fitting lid is a safety feature and will not open if pressure remains inside.
- To check if pressure has dropped, gently lift the vent weight. If no steam escapes, it is safe to open.
- Turn the lid handle to unlock it from the body handle and carefully lift the lid.

6. MAINTENANCE AND CARE

- **Cleaning:** Wash the cooker body and lid with warm soapy water after each use. Avoid abrasive cleaners or scouring pads that can damage the aluminium finish.
- **Gasket Care:** Regularly inspect the rubber gasket for cracks, tears, or hardening. Replace the gasket if it shows signs of wear to ensure a proper seal.
- **Vent Weight:** Clean the vent weight and vent tube regularly to prevent blockages. Ensure the vent tube is clear by passing a thin wire through it.
- **Storage:** Store the cooker with the lid inverted on the body to allow air circulation and prevent odors.
- **Dishwasher Safety:** This pressure cooker is NOT dishwasher safe. Hand wash only.

7. TROUBLESHOOTING

- **Steam Leaking from Lid:** Check if the gasket is properly seated, clean, and not worn out. Ensure the lid is closed securely.
- **Pressure Not Building:** Verify the lid is properly closed and sealed. Check the vent tube and vent weight for blockages. Ensure sufficient liquid is in the cooker.
- **Food Sticking to Bottom:** Ensure adequate liquid is used and the heat is not excessively high. The cooker features a heavy-duty sandwich base for even heating, but proper heat management is still important.
- **Lid Difficult to Open:** This is a safety feature. Ensure all pressure has been released before attempting to open the lid. If the vent weight is still hissing, wait longer.


8. SPECIFICATIONS

Attribute	Detail
Brand	HAWKINS
Model Number	HC50
Capacity	5 Liters (5.3 Quarts)
Material	Aluminium
Color	Silver
Finish Type	Matte
Product Dimensions (D x W x H)	15"D x 9"W x 6.5"H
Item Weight	5.2 Pounds
Control Method	Touch (Manual Operation)
Dishwasher Safe	No
Compatible Stovetops	Gas, Electric, Induction

Hawkins Contura

Available in 7 sizes

Choose the model that suits you, and see what its dimensions and weight are










	<p>30 cm/12 inch</p> <p>1.5 Litre Ideal for 1 or 2 Persons Length: 32.2 cm / 12.7 in Height: 14.5 cm / 5.7 in Diameter: 17.3 cm / 6.8 in Weight: 1.0 kg/ 2.2 lb Packed wt.: 1.6 kg/ 3.5 lb</p>		<p>30 cm/12 inch</p> <p>4 Litre Ideal for 4 to 6 Persons Length: 37.7 cm / 14.8 in Height: 21.2 cm / 8.4 in Diameter: 20.9 cm / 8.2 in Weight: 1.5 kg/ 3.3 lb Packed wt.: 2.3 kg/ 5.1 lb</p>
	<p>2 Litre Ideal for 2 or 3 Persons Length: 34.2 cm / 13.5 in Height: 14.9 cm / 5.9 in Diameter: 19.7 cm / 7.8 in Weight: 1.2 kg/ 2.6 lb Packed wt.: 1.8 kg/ 4.0 lb</p>		<p>5 Litre Ideal for 5 to 7 Persons Length: 41.8 cm / 16.5 in Height: 19.5 cm / 7.7 in Diameter: 24.7 cm / 9.7 in Weight: 1.8 kg/ 4.0 lb Packed wt.: 2.6 kg/ 5.7 lb</p>
	<p>3 Litre Ideal for 3 or 4 Persons Length: 34.2 cm / 13.5 in Height: 18.6 cm / 7.3 in Diameter: 19.7 cm / 7.8 in Weight: 1.4 kg/ 3.1 lb Packed wt.: 2.0 kg/ 4.4 lb</p>		<p>6.5 Litre Ideal for 7 to 9 Persons Length: 41.8 cm / 16.5 in Height: 23.2 cm / 9.1 in Diameter: 24.7 cm / 9.7 in Weight: 2.0 kg/ 4.4 lb Packed wt.: 2.9 kg/ 6.4 lb</p>
	<p>3.5 Litre Ideal for 4 or 5 Persons Length: 38.0 cm / 15.0 in Height: 16.6 cm / 6.5 in Diameter: 23.1 cm / 9.1 in Weight: 1.5 kg/ 3.3 lb Packed wt.: 2.1 kg/ 4.6 lb</p>	<p>30 cm/12 inch</p>	<p>30 cm/12 inch</p>

Image 5: Hawkins Contura Pressure Cooker size chart (5 Litre model highlighted).



Image 6: Side view with approximate dimensions.

9. WARRANTY AND SUPPORT

Your Hawkins Contura Pressure Cooker comes with a **5-year guarantee**. For any service or support needs, please refer to the Service Centre Directory included in your product packaging.

As of 2019, Hawkins has 692 service centers across India, Nepal, and Bhutan to assist with product support.

Related Documents - HC50



[Hawkins Pressure Cookers: 2023 Catalog of Quality Cookware](#)

Explore the comprehensive 2023 catalog from Hawkins Cookers Limited, featuring a wide range of durable and safe pressure cookers. Discover models like Classic, Futura, Contura, Instaa, Hevibase, Ceramic Nonstick, Miss Mary, and Bigboy, along with accessories. Ideal for modern kitchens, suitable for gas and induction cooktops.




[Hawkins Pressure Cooker Catalog 2021 - Classic, Futura, Contura, Bigboy & More](#)

Explore the 2021 Hawkins Pressure Cooker Catalog featuring Classic, Futura, Contura, and Bigboy models. Discover durable, safe, and efficient pressure cookers, cookware, and accessories for every kitchen, including induction-compatible and ceramic-coated options. Learn about Hawkins' commitment to quality, safety features, and delicious recipes.



[Hawkins Ventura Pressure Cooker Instruction Manual with 21 Tested Recipes](#)

A comprehensive guide to the Hawkins Ventura Pressure Cooker, covering safe operation, features, benefits, and including 21 tested recipes for efficient and delicious home cooking.



[Hawkins Contura Pressure Cooker Safety and Usage Guide](#)

Essential safety precautions and usage guidelines for the Hawkins Contura Stainless Steel Pressure Cooker, including instructions on dry heating, pre-heating, and preventing safety valve fusing.



[Hawkins Pizza Maker & Cake Baker: Instruction Manual, Recipes, and Guarantee](#)

Comprehensive instruction manual for the Hawkins Pizza Maker & Cake Baker, including features, usage guides, cleaning instructions, general cooking tips, 5 pizza recipes, 4 cake recipes, and a 2-year guarantee.



[Hawkins Instaa Pressure Cooker Induction Compatibility Guide](#)

This document provides additional information for using Hawkins Instaa pressure cookers with induction cooktops, including heat setting comparisons, recipe adaptations, and care instructions.