

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Nerf](#) /

› [Nerf ECS-10 Stock Instruction Manual](#)

Nerf B3206F07

Nerf ECS-10 Stock Instruction Manual

Model: B3206F07

1. INTRODUCTION

The Nerf ECS-10 Stock is an accessory designed to enhance compatible Nerf blasters. This stock provides improved stability during use and features an integrated storage slot for an extra dart magazine, allowing for quick reloads during play. This manual provides essential information for the safe and effective use of your Nerf ECS-10 Stock.

2. SAFETY INFORMATION

- **Recommended Age:** This product is intended for users aged 8 years and older.
- **Adult Supervision:** Adult supervision is recommended during play.
- **Proper Use:** Use this stock only with compatible Nerf blasters as intended. Do not modify the product.
- **Avoid Misuse:** Do not use the stock in any way that could cause injury to yourself or others.

3. PACKAGE CONTENTS

- 1 x Nerf ECS-10 Stock (Model B3206F07)

4. SETUP AND ATTACHMENT

The Nerf ECS-10 Stock is designed for easy attachment to compatible Nerf blasters that feature a stock attachment point. No assembly is required for the stock itself.

1. **Identify Attachment Point:** Locate the stock attachment point on the rear of your compatible Nerf blaster.
2. **Align and Slide:** Align the front end of the ECS-10 Stock with the blaster's attachment point. Slide the stock firmly onto the blaster until it clicks into place. Ensure the stock is securely fastened.
3. **Verify Connection:** Gently pull on the stock to confirm it is securely attached and does not wobble excessively.

To detach the stock, press the release button (if present on your blaster or stock) and slide the stock off the attachment point.



Image 1: The Nerf ECS-10 Stock. This image displays the Nerf ECS-10 Stock, a gray, orange, and white accessory designed to attach to compatible Nerf blasters. The stock features a textured shoulder rest, an open frame design, and an integrated slot for storing an extra dart magazine. It is shown against a plain cardboard background.

5. OPERATING INSTRUCTIONS

Once attached, the Nerf ECS-10 Stock provides several functional benefits:

- **Improved Stability:** Use the shoulder rest to brace the blaster against your shoulder for increased stability and accuracy during aiming and firing.
- **Magazine Storage:** The integrated slot on the stock is designed to hold one standard Nerf dart magazine (e.g., 6-dart, 10-dart, 12-dart, 18-dart, or drum magazines). Insert a loaded magazine into the slot for convenient access during play.
- **Magazine Removal:** To remove a stored magazine, firmly grasp the magazine and pull it out of the slot. Note that some magazines may fit snugly and require a firm pull.

6. MAINTENANCE

To ensure the longevity and proper function of your Nerf ECS-10 Stock, follow these simple maintenance

guidelines:

- **Cleaning:** Wipe the stock with a damp cloth to remove dust and dirt. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the stock in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the stock for any signs of damage or wear. Discontinue use if significant damage is observed.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stock feels loose or wobbly when attached.	Not fully engaged with the blaster's attachment point.	Ensure the stock is pushed firmly onto the blaster until it clicks securely.
Difficulty inserting or removing a magazine from the stock.	Magazine fit is snug; some magazines may be tighter than others.	Apply firm, steady pressure when inserting or removing magazines. Avoid forcing them.
Stock appears flimsy or bends under pressure.	Normal flexibility of the plastic components.	The stock is designed for light play. Avoid applying excessive force or weight to the stock.

8. SPECIFICATIONS

- **Model Number:** B3206F07
- **UPC:** 630509335893
- **Material:** Plastic
- **Item Weight:** Approximately 0.35 Pounds (0.16 kg)
- **Item Dimensions:** 3.74 x 6.61 x 10.98 inches (9.5 x 16.8 x 27.9 cm)
- **Assembly Required:** No (for the stock itself)
- **Batteries Required:** No
- **Operation Mode:** Manual
- **Manufacturer Minimum Age:** 8 years (96 months)

9. WARRANTY AND SUPPORT

Warranty: No specific manufacturer warranty is provided for this product.

Customer Support: For further assistance or inquiries regarding your Nerf ECS-10 Stock, please visit the official Nerf website or contact their customer service department. You can often find support information and FAQs on the brand's official online presence.

Please retain this instruction manual for future reference.

