

BANDAI BAN196419

Bandai Hobby Star Wars 1/48 X-Wing Starfighter Moving Edition Instruction Manual

Model: BAN196419 | Brand: BANDAI

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of the Bandai Hobby Star Wars 1/48 X-Wing Starfighter Moving Edition model kit. This highly detailed plastic model features movable S-foils, LED lights for the rear engine and cockpit, and sound effects, offering an immersive experience for enthusiasts.

Key Features:

- Motorized S-foils that open and close.
- LED illumination for the rear engines and cockpit.
- Integrated sound effects for proton torpedo attacks.
- Includes a dedicated display stand with effect switches.
- Detailed runner parts, foil stickers, and water-slide decals for customization.

SAFETY INFORMATION

WARNING: Product contains small parts which may pose a choking hazard. Not suitable for children under 3 years. Adult supervision is recommended during assembly and operation.

Always handle model parts with care. Keep batteries out of reach of small children. Dispose of batteries properly according to local regulations.

PACKAGE CONTENTS

- 1/48 X-Wing Starfighter Model Kit Runners (x8)
- Foil Sticker Sheet (x1)
- Water-slide Decal Sheet (x1)
- Instruction Manual (x1)
- Original Display Stand with Effect Switches (x1)
- Pilot Figure (x1)

Note: 2 AA batteries are required for the electronic features and are not included in this package.

Assembly

Follow the detailed diagrams in the included instruction manual for step-by-step assembly. No glue is required for basic assembly, as parts are designed to snap together. Use hobby nippers to carefully remove parts from the runners.

Battery Installation

The display stand requires 2 AA batteries (not included) to power the model's electronic features. Locate the battery compartment on the underside of the display stand, insert the batteries with correct polarity, and secure the cover.



Figure 1: The fully assembled Bandai 1/48 X-Wing Starfighter Moving Edition model, mounted on its dedicated display stand. The stand features control buttons for activating the model's electronic functions.

OPERATING INSTRUCTIONS

Once assembled and batteries are installed in the display stand, you can activate the X-Wing's dynamic features using the switches on the stand.

S-Foils Operation

Press the designated switch on the display stand to activate the motorized S-foils. The S-foils will automatically transition between their open (attack) and closed (flight) positions. This feature is only operational when the model is mounted on the powered stand.



Figure 2: The X-Wing Starfighter with its S-foils deployed in the attack position, showcasing the model's dynamic capabilities.



Figure 3: The X-Wing Starfighter with its S-foils retracted into the flight position, demonstrating the model's versatility in display options.

Light and Sound Effects

Additional switches on the display stand control the LED lights in the rear engines and cockpit, as well as the proton torpedo sound effects. Activate these features to enhance the realism of your X-Wing display.



Figure 4: A detailed view of the X-Wing's cockpit, illuminated by internal LEDs, highlighting the pilot figure and interior details.



Figure 5: The rear section of the X-Wing, displaying the vibrant red LED lights emanating from the four engine nozzles, simulating active propulsion.

Official Product Video



Video 1: This official product video demonstrates the assembly process and showcases the various features of the Star Wars: A New Hope X-Wing Fighter 1:63 Scale Model Kit. It highlights the detail and functionality of the model.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to gently wipe dust from the model. Avoid using harsh chemicals or abrasive materials, as these can damage the plastic or paint.
- **Storage:** Store the model in a cool, dry place away from direct sunlight to prevent discoloration or warping of plastic parts.
- **Battery Care:** Remove batteries from the display stand if the model will not be used for an extended period to prevent leakage and damage.

TROUBLESHOOTING

- **S-foils not moving/lights not working:**
 - Ensure batteries are correctly installed in the display stand with the proper polarity.
 - Check if the batteries are fresh and have sufficient charge.
 - Verify all connections between the model and the display stand are secure.
- **Parts not fitting correctly during assembly:**
 - Refer to the instruction manual diagrams to ensure correct part orientation.
 - Gently apply pressure; avoid excessive force to prevent breakage.

SPECIFICATIONS

Brand	BANDAI
Model Name	1/48 X-Wing Starfighter Moving Edition "Star Wars"
Item Model Number	BAN196419
Scale	1/48
Material	Plastic, Foil
Product Dimensions	8 x 8 x 8 inches
Item Weight	2.4 pounds (1090 Grams)
Number of Pieces	100
Recommended Age	13 years and up
Batteries Required	2 AA batteries (not included)

WARRANTY AND SUPPORT

This product is manufactured by Bandai Hobby. The presence of the official Bluefin logo ensures product support and authenticity. For any inquiries regarding assembly, missing parts, or operational issues, please contact the official Bandai Hobby or Bluefin distribution support channels. Retain your proof of purchase for warranty claims.

Visit the [BANDAI Store](#) for more information and products.