

Telestar 5310474

Telestar TD 2300 HD+ Satellite Receiver User Manual

Model: TD 2300 HD+ (5310474)

1. INTRODUCTION

This manual provides essential instructions for the installation, operation, and maintenance of your Telestar TD 2300 HD+ satellite receiver. Please read this manual thoroughly before using the device to ensure proper functionality and to prevent damage.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Telestar TD 2300 HD+ Satellite Receiver
- HD+ Card (for 6 months subscription)
- Remote Control with Batteries (2x AAA)
- User Manual (this document)
- Warranty Card

3. PRODUCT OVERVIEW

3.1 Front Panel



Image 1: Front view of the Telestar TD 2300 HD+ receiver. It features a central display, power button, channel navigation buttons, and the HD+ logo.

The front panel includes the 4-digit LED display, power button, channel up/down buttons, and the HD+ indicator.

3.2 Rear Panel Connections



Image 2: Rear panel of the Telestar TD 2300 HD+ receiver, showing various input and output ports.

The rear panel provides the following connection ports:

- **LNB IN:** Satellite signal input.
- **LOOP OUT:** For connecting to another satellite receiver.
- **CARD INSERT:** Slot for the HD+ smart card.
- **USB:** For firmware updates or media playback.
- **HDMI:** High-Definition Multimedia Interface for connecting to a TV.
- **DIGITAL AUDIO:** S/PDIF electrical output for digital audio.
- **TV SCART:** SCART connector for older televisions.
- **AC IN:** Power input (220-240V~ 50/60Hz).

3.3 Remote Control





Image 3: The remote control for the Telestar TD 2300 HD+ receiver, displaying all buttons and their functions.

The remote control allows full operation of the receiver. It requires 2 AAA batteries (included). Key functions include power, channel navigation, volume control, menu access, and EPG (Electronic Program Guide).

4. SETUP

1. **Connect the Satellite Cable:** Connect the satellite dish cable to the **LNB IN** port on the rear panel of the receiver.
2. **Connect to TV:**
 - For High-Definition (HD) viewing, connect an HDMI cable from the receiver's **HDMI** port to an HDMI input on your television.
 - For Standard-Definition (SD) viewing or older TVs, connect a SCART cable from the receiver's **TV SCART** port to the SCART input on your television.
3. **Insert HD+ Card:** Carefully insert the provided HD+ smart card into the **CARD INSERT** slot on the rear panel, ensuring the chip faces downwards and the card is fully seated.
4. **Connect Power:** Connect the power cable to the **AC IN** port on the receiver and then plug it into a wall outlet.
5. **Initial Power On:** Turn on your TV and select the correct HDMI or SCART input. Press the power

button on the receiver or remote control.

6. **First Installation Wizard:** The receiver will guide you through the initial setup process, including language selection, satellite configuration, and automatic channel search. Follow the on-screen instructions. The receiver is pre-programmed for Astra.

5. OPERATING INSTRUCTIONS

5.1 Basic Functions

- **Power On/Off:** Press the **POWER** button on the remote control or the front panel.
- **Channel Selection:** Use the **CH ▲/▼** buttons to change channels sequentially, or enter the channel number directly using the numeric keypad.
- **Volume Control:** Use the **VOL ◀/▶** buttons to adjust the volume.
- **Menu Access:** Press the **MENU** button to access the main menu for settings and features.
- **Electronic Program Guide (EPG):** Press the **EPG** button to view program information for up to 7 days.
- **Information Display:** Press the **INFO** button to display current program details.

5.2 Advanced Features

- **Language Settings:** Access the menu to change audio language or subtitle language. The device supports 5 languages.
- **Parental Control:** Set up parental control features via the menu to restrict access to certain channels or programs.
- **Automatic Station Search:** The receiver can automatically search for available channels. This function is typically found in the installation or channel settings menu.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the receiver's exterior. Do not use liquid or aerosol cleaners.
- **Ventilation:** Ensure the receiver has adequate ventilation. Do not block the ventilation slots.
- **Firmware Updates:** Periodically check the manufacturer's website for firmware updates. Updates can typically be installed via the USB port.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No picture or sound	Incorrect TV input selected; loose cable connections; receiver not powered on.	Check TV input source; ensure all cables (HDMI/SCART, LNB, power) are securely connected; power on the receiver.
"No Signal" message	LNB cable disconnected or damaged; satellite dish misalignment; severe weather.	Check LNB cable connection; ensure satellite dish is correctly aligned (professional assistance may be required); wait for weather conditions to improve.
Remote control not working	Batteries depleted or incorrectly inserted; obstruction between remote and receiver; remote sensor blocked.	Replace batteries (2x AAA); ensure correct battery polarity; remove any obstructions; clean receiver's IR sensor.

Problem	Possible Cause	Solution
HD+ channels not decrypting	HD+ card not inserted correctly or expired; card not activated.	Ensure HD+ card is fully and correctly inserted; check card validity; contact HD+ support for activation issues.

8. SPECIFICATIONS

Feature	Detail
Model Number	5310474
Dimensions (W x D x H)	21 x 12.8 x 4.1 cm
Weight	607 grams
Color	Black
Power Input	220-240V~ 50/60Hz
Connections	HDMI, SCART, USB (1 port), Digital Audio (S/PDIF electrical), LNB IN, LOOP OUT
Audio Output Mode	Surround
Display	4-digit LED
EPG	7-day Electronic Program Guide
Batteries for Remote	2x AAA (included)

9. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. Please refer to the included warranty card for specific terms and conditions. For technical support or service inquiries, please contact Telestar customer service. Contact information can typically be found on the warranty card or the official Telestar website.

© 2023 Telestar-Digital GmbH. All rights reserved.

Related Documents - 5310474

	TELESTAR STARSAT HD+ Digitaler Satelliten-Receiver Bedienhandbuch Dieses Bedienhandbuch für den TELESTAR STARSAT HD+ Digitalreceiver bietet detaillierte Anleitungen zur Installation, Einrichtung, Bedienung und Fehlerbehebung. Erfahren Sie, wie Sie unverschlüsselte DVB-S/S2 Signale empfangen und Ihr Gerät optimal nutzen.
---	---

 TELESTAR TOP 200 TOP 250 HU Kezelési útmutató	Telestar TOP 200 és TOP 250 Kezelési Útmutató Részletes felhasználói útmutató a Telestar TOP 200 és TOP 250 digitális rádiókhoz, ismerteti a telepítést, beállítást, funkciókat és hibaelhárítást.
 TELESTAR digital tv, multimedia & more Bedienungsanleitung TELESTAR DIGIBIT TWIN SAT>IP Router	Bedienungsanleitung TELESTAR DIGIBIT TWIN SAT>IP Router Umfassende Bedienungsanleitung für den TELESTAR DIGIBIT TWIN SAT>IP Router, inklusive Anschluss, Installation, Konfiguration, technische Daten und FAQ.
 TELESTAR TOP 300 HU Kezelési útmutató	TELESTAR TOP 300 Kezelési útmutató: Telepítés, Beállítás és Működés Ez a dokumentum a TELESTAR TOP 300 digitális rádió kezelési útmutatója, amely részletes információkat tartalmaz a telepítésről, beállításról, működésről és karbantartásról. Lefedi az internetrádió, DAB+, FM rádió, Bluetooth csatlakozás, USB-ről és hálózatról történő médialejátszás, időjárási információk, felvétel, streaming szolgáltatások és alkalmazásvezérlés funkcióit.
 TELESTAR TOP 400 DE Bedienungsanleitung EN User manual FR Mode d'emploi IT Istruzioni per l'uso NL Bedieningshandleiding	TELESTAR TOP 400 Internetradio Bedienungsanleitung Umfassende Bedienungsanleitung für das TELESTAR TOP 400 Digitalradio. Erfahren Sie, wie Sie Internetradio, DAB+, FM und Bluetooth einrichten und nutzen. Enthält Installationsschritte, Einstellungen, Fehlerbehebung und technische Daten.
 TELESTAR Bedienungsanleitung TELESTAR 1010 C-L	TELESTAR TD 1010 C-L Bedienungsanleitung Umfassende Bedienungsanleitung für den TELESTAR TD 1010 C-L DVB-C Kabelreceiver. Erfahren Sie mehr über Installation, Einstellungen, Funktionen und Fehlerbehebung.