

PHILIPS HP8302

Philips HP8302 Selfie Hair Straightener User Manual

Model: HP8302

1. IMPORTANT SAFETY INSTRUCTIONS

Please read this user manual carefully before using the appliance and save it for future reference. Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- **DANGER:** Keep the appliance away from water. Do not use it near bathtubs, showers, basins, or other vessels containing water.
- **WARNING:** This appliance is hot. Keep it out of reach of children. Always place it on a heat-resistant surface when not in use.
- Do not use this appliance with wet hands or if the appliance itself is wet.
- Always unplug the appliance after use and before cleaning.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Do not use attachments not recommended by Philips.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. PRODUCT OVERVIEW

The Philips HP8302 Selfie Hair Straightener is designed for quick and convenient hair styling at home. It features ceramic plates for smooth gliding and SilkPro Care technology to minimize heat damage.



Figure 2.1: Philips HP8302 Selfie Hair Straightener, showing its sleek black design and pink ceramic plates.

Key Features:

- **SilkPro Care Technology:** Optimized temperature plates that evenly distribute heat and minimize damage.
- **Ceramic Plates:** For smooth gliding and shiny, straight hair.
- **210°C Professional Temperature:** Provides optimal heat for effective styling.
- **Fast Heat-up:** Ready to use in 60 seconds.
- **Swivel Cord:** Rotates to prevent tangled wires during use.
- **Universal Voltage:** Compatible with 110V-240V for worldwide use.

PHILIPS SELFIE STRAIGHTNER

HP8302/06



Silk Protect Technology
minimizes heat damage



Ceramic plates for smooth
gliding and straight hair



**210°C professional
temperature** gives you
the perfect salon look



Instant heat up
ready to use in 60 sec



Useful swivel cord rotates
& prevents tangled wires



Universal voltage use
anywhere in the world

Figure 2.2: Overview of key features including Silk Protect Technology, Ceramic plates, 210°C temperature, 60-second heat-up, swivel cord, and universal voltage.



Silk Protect Technology

Optimized temperature plates that evenly distributes heat and minimizes damage

Figure 2.3: Close-up view illustrating Silk Protect Technology, designed to minimize heat damage.




Figure 2.4: Detail of the ceramic plates, which glide smoothly for effective hair straightening.



Figure 2.5: Image showing the swivel cord feature, which prevents tangles during use.

3. SETUP

Before first use, ensure the appliance is clean and free from any packaging materials.

1. **Unpack:** Carefully remove the straightener from its packaging.
2. **Inspect:** Check the appliance for any visible damage. Do not use if damaged.
3. **Plug In:** Insert the power plug into a suitable wall socket. Ensure the voltage matches your local power supply (110V-240V compatible).

4. OPERATING INSTRUCTIONS

Follow these steps for effective and safe hair straightening.

1. **Prepare Hair:** Ensure your hair is clean, dry, and detangled. For best results, apply a heat protectant spray.
2. **Power On:** Plug in the straightener. The appliance will begin to heat up automatically.
3. **Heat-up Time:** The straightener reaches its optimal temperature of 210°C in approximately 60

seconds.



Figure 4.1: The straightener heats up quickly, ready for use in 60 seconds.

4. **Section Hair:** Divide your hair into small, manageable sections (about 1-2 inches wide).
5. **Straighten:** Place a section of hair between the ceramic plates, close the plates gently, and glide the straightener slowly and evenly from roots to ends. Avoid holding the straightener in one place for too long to prevent heat damage.



Figure 4.2: The straightener operates at a professional temperature of 210°C for effective styling.

6. **Repeat:** Repeat the process for all sections of your hair until desired straightness is achieved.
7. **Power Off:** After use, unplug the appliance from the power socket.
8. **Cool Down:** Allow the straightener to cool down completely on a heat-resistant surface before storing.

5. MAINTENANCE AND CLEANING

Regular cleaning and proper storage will prolong the life of your straightener.

- **Cleaning:** Ensure the appliance is unplugged and completely cool. Wipe the ceramic plates and the exterior with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Storage:** Store the appliance in a dry, safe place, away from moisture and direct sunlight. Do not wrap the cord tightly around the appliance, as this can damage the cord.

6. TROUBLESHOOTING

If you encounter any issues with your Philips HP8302 Selfie Hair Straightener, refer to the following

common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not heat up.	Not plugged in correctly or power outlet issue.	Ensure the plug is fully inserted into a working power outlet. Test the outlet with another appliance.
Hair is not straightening effectively.	Hair is not completely dry, sections are too large, or gliding too quickly.	Ensure hair is completely dry. Work with smaller sections of hair. Glide the straightener more slowly and evenly.
Burning smell.	Product residue on plates or hair product burning.	Clean the plates thoroughly when cool. Ensure hair is clean and free of excessive product buildup. If the smell persists, discontinue use and contact support.

If the problem persists after trying these solutions, please contact Philips customer support.

7. SPECIFICATIONS

Model Number	HP8302
Plate Material	Ceramic
Max Temperature Setting	210°C
Heat-up Time	60 seconds
Plate Size	19 mm x 85 mm
Cord Length	1.6 m
Swivel Cord	Yes (360°)
Power Source	Corded Electric
Product Dimensions (LxWxH)	28.5 x 9.5 x 0.1 cm
Item Weight	407 g
Universal Voltage	110V-240V
Included Components	Product, Warranty card, User manual

8. WARRANTY AND SUPPORT

Your Philips HP8302 Selfie Hair Straightener comes with a comprehensive warranty and dedicated customer support.

- Warranty:** This appliance is covered by a **2-year Philips India warranty** from the date of purchase. Please retain your purchase receipt and warranty card for any claims.

- **Customer Support:** For any queries, assistance, or to register a warranty claim, please contact Philips customer service.

Philips India Customer Contact: 180010229229

You can also visit the official Philips website for more information and support resources.