

[Manuals.plus](#) /

> [MisterVac](#) /

> MisterVac Automatic Floor Nozzle Replacement for Hecht 8314 Z Wet/Dry Vacuum Cleaner Instruction Manual

MisterVac 4054288676620

MisterVac Automatic Floor Nozzle Replacement for Hecht 8314 Z Wet/Dry Vacuum Cleaner Instruction Manual

Model: 4054288676620

INTRODUCTION

This manual provides essential instructions for the proper use, setup, and maintenance of your MisterVac Automatic Floor Nozzle, designed for compatibility with the Hecht 8314 Z Wet/Dry Vacuum Cleaner. This innovative nozzle is engineered to adapt autonomously to various floor types, ensuring efficient cleaning without manual adjustments.

Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

1



Image: Top-down view of the MisterVac Automatic Floor Nozzle, showcasing its design and the MisterVac brand logo.

PRODUCT FEATURES

- **Automatic Floor Adjustment:** The nozzle autonomously switches between carpet and hard floor settings using air membrane technology, eliminating the need for manual intervention.
- **Smooth Gliding:** Equipped with two free-running rollers and an ergonomically designed, highly polished base plate for effortless movement across surfaces.
- **Integrated Thread Lifter:** A practical thread lifter is incorporated to effectively pick up threads and fibers.
- **No External Power Required:** The automatic function operates mechanically, requiring no electrical connection.
- **360-Degree Swivel Joint:** The connection joint allows for full 360-degree rotation, enhancing maneuverability.

3



Image: The MisterVac Automatic Floor Nozzle demonstrating its 360-degree swivel joint for enhanced cleaning flexibility.



Image: Side view of the nozzle illustrating its ergonomic design and flexible movement across different angles.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the MisterVac Automatic Floor Nozzle from its packaging.
2. **Attach:** Connect the nozzle securely to the wand or hose of your Hecht 8314 Z Wet/Dry Vacuum Cleaner. Ensure a snug fit to prevent loss of suction.
3. **Ready:** The nozzle is now ready for use. No further adjustments are required for initial operation.

OPERATING INSTRUCTIONS

The MisterVac Automatic Floor Nozzle is designed for straightforward operation. Once attached to your vacuum cleaner, it will automatically adjust its settings based on the floor surface it encounters.

- **Carpet Mode:** When cleaning carpets, the nozzle's bristles will retract, allowing the vacuum to glide smoothly and effectively clean carpet fibers. An indicator on the nozzle will show the carpet setting.
- **Hard Floor Mode:** When transitioning to hard floors (e.g., tile, wood, stone), the bristles will extend to gently sweep and clean the surface without scratching. An indicator on the nozzle will show the hard floor setting.

Simply guide your vacuum cleaner as usual. The nozzle's internal mechanism, powered by air membrane technology, handles the floor type detection and adjustment automatically.

7



Image: Detailed view of the "AUTO MATIC" indicator on the nozzle, showing the setting for carpet cleaning.

8



Image: Detailed view of the "AUTO MATIC" indicator on the nozzle, showing the setting for hard floor cleaning.

MAINTENANCE

To ensure continued optimal performance of your MisterVac Automatic Floor Nozzle, regular cleaning is recommended.

- **Inspect Rollers and Bristles:** Periodically check the rollers and bristles on the underside of the nozzle for tangled hair, threads, or debris.
- **Clean Debris:** Use scissors or a brush to carefully remove any accumulated hair or debris from the rollers and bristles. Ensure the thread lifter is also clear.
- **Wipe Down:** Wipe the exterior of the nozzle with a damp cloth to remove dust and dirt. Do not immerse the nozzle in water.

6



Image: Underside view of the nozzle, highlighting the smooth-gliding rollers and the bristles for different floor types.

TROUBLESHOOTING

If you experience any issues with your MisterVac Automatic Floor Nozzle, consider the following:

- **Reduced Suction:** Ensure the nozzle is securely attached to the vacuum cleaner's wand/hose. Check for any blockages in the nozzle or the vacuum system.
- **Poor Gliding:** Inspect the rollers and base plate for debris or damage. Clean as described in the Maintenance section.
- **Automatic Adjustment Not Working:** Verify that there are no obstructions preventing the internal mechanism from moving freely. Ensure the nozzle is clean and free of excessive dirt buildup.

For persistent issues, please refer to the Warranty and Support section for contact information.

SPECIFICATIONS

Brand	MisterVac
Model Number	4054288676620

Product Compatibility	Hecht 8314 Z Wet/Dry Vacuum Cleaner
Manufacturer	MisterVac
Country of Origin	Germany
Dimensions (Approx.)	29 cm (length) x 9 cm (width)



Image: The MisterVac Automatic Floor Nozzle displaying its approximate dimensions of 29 cm in length and 9 cm in width.

WARRANTY AND SUPPORT

MisterVac® Device Warranty

The warranty is valid in all member states of the European Union. Legal rights regarding material defects remain fully in force and are not limited by this warranty. The warranty covers all repair and shipping costs for defects that occur during the warranty period and are reported to MisterVac by the end-user, provided they are not based on unintended use, wear and tear, improper handling, or the use of force.

In the event of a warranty claim, please contact the guarantor directly. Upon submission of proof of purchase and the defective goods, the guarantor will, at their discretion, either repair the item free of

charge or exchange it for a product of equal value. Other claims are not created by this warranty.

For support or warranty claims, please contact MisterVac directly through their official channels or the seller from whom the product was purchased.