

[Manuals.plus](#) /

› [Winner](#) /

› Winner Automatic Mechanical Watch for Men, Model TM340 Instruction Manual

Winner TM340

Winner Automatic Mechanical Watch for Men, Model TM340

Instruction Manual

1. PRODUCT OVERVIEW

Thank you for choosing the Winner Automatic Mechanical Watch, Model TM340. This timepiece combines classic design with reliable mechanical movement, offering a sophisticated accessory for men. This manual will guide you through its features and proper care.



Image: The Winner Automatic Mechanical Watch, Model TM340, featuring a black skeleton dial and a silver stainless steel bracelet.

Key Features:

- **Modern Skeleton Design:** This mechanical watch features a transparent skeleton dial, showcasing the intricate movement. Its classic design is suitable for various occasions.
- **Automatic and Manual Winding:** The watch operates without a battery, powered by automatic movement from arm motion. It also supports manual winding and features an analog display.
- **Durable Materials:** Constructed with wear-resistant, high-quality electroplated case that resists fading. The stainless steel case and durable alloy bracelet provide a comfortable wearing experience.
- **Water Resistance (30M):** The watch is water-resistant up to 30 meters (3 ATM), suitable for daily use such as hand washing, sweating, and light rain. It can withstand splashes or brief immersion in water but is not suitable for swimming or diving. Do not operate the crown while submerged.

2. SETUP

Initial Winding:

1. Before first use, or if the watch has stopped, manually wind the watch by rotating the crown clockwise approximately 20-30 times while it is in its normal, pushed-in position. This provides the initial power reserve.
2. The watch will then continue to operate through the automatic movement as you wear it.

Setting the Time:

1. Pull the crown out to the first position.
2. Rotate the crown to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its normal position.

3. OPERATING INSTRUCTIONS

Automatic Movement:

This watch is powered by an automatic mechanical movement. It harnesses the motion of your arm to wind the mainspring. When worn regularly (approximately 8-10 hours a day), the watch will maintain its power reserve. If the watch is not worn for an extended period, it may stop and require manual winding to restart.

Water Resistance:

The watch has a water resistance rating of 30 meters (3 ATM). This means it is suitable for everyday activities such as hand washing, light rain, and accidental splashes. It is not designed for showering, bathing, swimming, or diving. Always ensure the crown is fully pushed in to maintain water resistance. Do not operate the crown while the watch is wet or submerged.

4. MAINTENANCE

Cleaning:

Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust and dirt. For stainless steel parts, a slightly damp cloth can be used, followed by immediate drying. Avoid using chemical cleaners, as they may damage the watch's finish.

Storage:

When not wearing the watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. A watch box or case is ideal for protection.

Avoid Shocks:

Mechanical watches are delicate instruments. Avoid dropping the watch or subjecting it to strong impacts, as this can damage the internal movement.

5. TROUBLESHOOTING

- **Watch Stops Running:** If the watch stops, it likely needs to be wound. Manually wind the watch by rotating the crown clockwise 20-30 times. If worn regularly, ensure you are active enough for the automatic movement to function.
- **Time is Inaccurate:** Ensure the watch is fully wound. Mechanical watches can have slight variations in timekeeping. If the inaccuracy is significant, it may require professional inspection.

- **Condensation Inside Dial:** If you notice condensation under the crystal, this indicates a breach in water resistance. Avoid further contact with water and seek professional service immediately to prevent damage to the movement.

6. SPECIFICATIONS

Brand	Winner
Model Number	TN340
Movement	Automatic Mechanical (Manual Wind Supported)
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	45 mm
Case Thickness	15 mm
Band Material	Stainless Steel
Band Width	20 mm
Dial Color	Black (Skeleton)
Band Color	Silver
Water Resistance Depth	30 Meters (3 ATM)
Glass Material Type	Mineral Glass or Sapphire Crystal
Included Components	Instruction manual, warranty, watch box or case

7. WARRANTY AND SUPPORT

Your Winner Automatic Mechanical Watch, Model TM340, comes with a warranty. Please refer to the included warranty card for specific terms and conditions. For any product-related inquiries, technical support, or warranty claims, please contact the seller or authorized service center for assistance.

Customer Support: For any product-related inquiries, please contact the seller for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question