

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Energizer](#) /

> [Energizer Vision HD+ LED Headlamp User Manual](#)

## Energizer HDD32E

# Energizer Vision HD+ LED Headlamp Instruction Manual

Model: HDD32E | Brand: Energizer

### INTRODUCTION

The Energizer Vision HD+ Focus LED Headlamp is designed to provide brilliant and precise illumination, offering hands-free lighting for various activities such as morning jogs, camping, or during power outages. It features 400 lumens on high mode, a beam distance of up to 85 meters, patented Digital Focus technology for seamless beam width transitions, and a pivoting head for directional lighting. This headlamp is also IPX4 water-resistant and impact-resistant up to 1 meter, ensuring reliability in diverse conditions.

### WHAT'S INCLUDED

- One (1) Energizer Vision HD+ Focus LED Headlamp
- Three (3) Energizer AAA Alkaline Batteries



Image: Energizer Vision HD+ LED Headlamp components, including the headlamp unit, adjustable strap, and three AAA batteries.

## SETUP

### Battery Installation

1. Locate the battery compartment on the back of the headlamp unit.
2. Gently open the battery compartment cover.
3. Insert three (3) AAA alkaline batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely until it clicks into place.

## Adjusting the Headband

1. Place the headlamp on your head with the light unit positioned on your forehead.
2. Use the adjustable buckle on the elastic strap to tighten or loosen the headband until it fits comfortably and securely.



Image: Side view of the headlamp, illustrating the adjustable elastic strap for a comfortable fit.

## OPERATING INSTRUCTIONS

### Power On/Off and Mode Selection

1. To turn the headlamp ON, press the power button located on the top of the unit.
2. Press the power button repeatedly to cycle through the different light modes: High, Low, Flood, and Red.
3. To turn the headlamp OFF, press the power button after cycling through all modes, or hold the power button for a few seconds.

### Digital Focus Technology

The Digital Focus technology allows you to seamlessly transition between beam widths. Press and hold the dedicated focus button (often red, next to the power button) to narrow or widen the light beam according to your needs.

## Pivoting Head Function

The headlamp unit can be pivoted up or down to direct the light exactly where you need it. Gently tilt the light unit to adjust its angle.

# PIVOTS LIGHT



Image: The headlamp unit demonstrating its ability to pivot, allowing users to direct the light beam.

## Memory Recall

The Memory Recall technology allows the headlamp to remember your last used focus setting (on low, spot, flood, and red modes) and activate it the next time the headlamp is turned on.

## KEY FEATURES

- **400 Lumens:** Provides powerful illumination for various tasks.
- **Digital Focus Technology:** Seamlessly transitions between wide and narrow beam widths.
- **Pivoting Head:** Directs light where needed.
- **IPX4 Water-Resistant:** Withstands splashing water from any direction.
- **Impact-Resistant:** Durable design, withstands drops up to 1 meter.
- **Multiple Light Modes:** Includes High, Low, Flood, and Red light options.
- **Memory Recall:** Remembers your last preferred focus setting.



# GREAT FOR **CAMPING**

Image: The headlamp shown with water splashing, highlighting its IPX4 water-resistant feature.



Image: The headlamp shown in a dynamic setting, emphasizing its impact-resistant design.

## MAINTENANCE

- **Cleaning:** Clean the headlamp with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Battery Care:** Remove batteries if the headlamp will not be used for an extended period to prevent potential battery leakage and damage to the device.
- **Storage:** Store the headlamp in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on	Dead or incorrectly inserted batteries	Replace batteries with new ones, ensuring correct polarity.
Light is dim or flickers	Low battery power or loose battery connection	Replace batteries. Check that batteries are seated firmly.
Headband feels loose	Improper headband adjustment	Adjust the elastic strap using the buckle until a snug fit is achieved.

Problem	Possible Cause	Solution
---------	----------------	----------

## SPECIFICATIONS

Specification	Detail
Model Name	Vision HD+ Focus LED Headlamp
Model Number	HDD32E
Brand	Energizer
Light Source Type	LED
White Brightness	400 Lumens (High Mode)
Special Feature	Digital Focus, Pivoting Head
Power Source	Battery Powered
Battery Type	3 AAA Alkaline Batteries (Included)
Water Resistance Level	IPX4 Water Resistant
Impact Resistance	Up to 1 Meter
Material	Plastic
Item Weight	0.18 Pounds
Product Dimensions	1.55"D x 5.75"W x 7.5"H
Manufacturer	Energizer Battery Company, inc.

## WARRANTY AND SUPPORT

The manufacturer states that warranty information is not applicable for this product. For any product inquiries or support, please refer to the contact information provided on the product packaging or the official Energizer website.