



Manuals.plus /

› Buffalo Tools /

› Buffalo Tools FPTRUCK Folding Platform Truck 19x29 Inch User Manual

Buffalo Tools FPTRUCK

Buffalo Tools FPTRUCK Folding Platform Truck User Manual

Model: FPTRUCK

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, assembly, and maintenance of your Buffalo Tools FPTRUCK Folding Platform Truck. Please read this manual thoroughly before initial use and retain it for future reference. This platform truck is designed for transporting various items, offering a convenient and foldable design for storage.

2. SAFETY INFORMATION

- **Load Capacity:** Do not exceed the maximum load capacity of 17 pounds. Overloading can cause damage to the truck and lead to injury.
- **Evenly Distribute Load:** Ensure items are placed evenly on the platform to maintain stability.
- **Secure Load:** Always secure items on the platform to prevent shifting or falling during transport.
- **Clear Path:** Ensure your path is clear of obstacles, debris, and uneven surfaces before moving the truck.
- **Personal Protective Equipment:** Wear appropriate safety footwear when operating the truck.
- **Folding/Unfolding:** Exercise caution when folding or unfolding the handle to avoid pinching fingers or hands.
- **Storage:** Store the truck in a dry, secure location when not in use.

3. PACKAGE CONTENTS

Upon unpacking, verify that all components are present and undamaged:

- 1 x Buffalo Tools FPTRUCK Folding Platform Truck (fully assembled)
- This User Manual

4. SETUP AND ASSEMBLY

The Buffalo Tools FPTRUCK Folding Platform Truck comes pre-assembled. Setup primarily involves unfolding the handle for use.

1. Unfolding the Handle:

Locate the handle mechanism at the rear of the platform. Gently pull the handle upwards until it locks securely into the upright position. Ensure the locking pins or levers (if present) are fully engaged to prevent accidental folding during use.



Image: The Buffalo Tools FPTRUCK Folding Platform Truck shown fully unfolded and ready for use. The handle is in the upright position, and the platform is flat.

2. Inspecting Wheels:

Before first use, check that all four wheels rotate freely and are securely attached to the platform.



Image: A side view of the platform truck, highlighting the wheels and the low-profile design of the platform.

5. OPERATING INSTRUCTIONS

1. Loading the Truck:

Place items centrally on the platform. For multiple items, distribute weight evenly. Ensure the load does not obstruct your view or interfere with the handle's movement. Do not exceed the stated load capacity.



Image: The platform truck in use, transporting two stacked cardboard boxes. This demonstrates proper load placement and the truck's functionality.

2. Moving the Truck:

Grasp the handle firmly with both hands. Push or pull the truck smoothly. Avoid sudden movements or sharp turns, especially with heavy loads. Navigate carefully over thresholds or uneven surfaces.

3. Folding for Storage:

When not in use, the handle can be folded down for compact storage. Locate the release mechanism (usually a foot pedal or lever) at the base of the handle. Engage the mechanism and gently push the handle forward and down until it rests flat against the platform.




Image: The platform truck shown in its folded configuration, illustrating its compact storage capability. The handle is collapsed onto the platform.

6. MAINTENANCE

- **Cleaning:** Wipe down the platform and handle with a damp cloth as needed. Avoid abrasive cleaners.
- **Wheel Inspection:** Periodically check the wheels for wear, damage, or debris accumulation. Remove any tangled hair or string from the axles.
- **Lubrication:** If wheels become stiff, apply a small amount of general-purpose lubricant to the wheel axles.
- **Storage:** Store the truck in a dry environment to prevent rust and prolong its lifespan.

7. TROUBLESHOOTING

- **Truck is difficult to push/pull:**
 - Check for overloaded conditions. Reduce the load if necessary.
 - Inspect wheels for debris or damage. Clean or replace as needed.
 - Ensure wheels are properly lubricated.
- **Handle does not lock into upright position:**
 - Ensure the handle is fully extended and the locking mechanism is engaged.
 - Check for any obstructions preventing the handle from locking.

8. SPECIFICATIONS

Feature	Specification
Brand	Buffalo Tools
Model	FPTRUCK
Product Dimensions (Unfolded)	Approximately 29 x 19 x 32 inches (L x W x H)
Item Weight	17 Pounds
Load Capacity	17 Pounds
Number of Wheels	4
Wheel Type	Solid
Color	Gray

Note: Specifications are approximate and subject to change without notice.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Buffalo Tools directly. Refer to the product packaging or the official Buffalo Tools website for current contact details and warranty terms.

Buffalo Tools is a registered trademark.

