Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nuwave 30341

NuWave PIC Titanium Induction Cooktop (Model 30341) User Manual

Your Guide to Operation and Care

Introduction

Thank you for choosing the NuWave PIC Titanium Induction Cooktop. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

The NuWave PIC Titanium offers advanced features including precise temperature control, variable wattage adjustment, and a larger cooking surface for enhanced culinary flexibility.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview



Image: NuWave PIC Titanium Induction Cooktop, showcasing its sleek design and control panel.

The NuWave PIC Titanium is an advanced induction cooktop designed for precision cooking. Key features include:

- **Precise Temperature Control:** Adjusts in 5-degree increments for optimal cooking results.
- **Larger Heating Surface:** A 9.5-inch heating surface (12-inch overall) accommodates larger pots and pans.
- **Variable Wattage Adjuster:** Select between 600W, 900W, or 1800W to suit different power needs and environments.
- **Delayed Shutoff Feature:** Allows you to temporarily remove cookware and resume cooking within 10 seconds without restarting.
- **Touch Controls:** Intuitive touch interface for easy operation.

Setup

1. Unpacking

Carefully remove the cooktop and all accessories from the packaging. Retain packaging for storage or future shipping.

2. Placement

- Place the cooktop on a dry, flat, stable, and heat-resistant surface.
- Ensure adequate ventilation around the unit. Do not block the air vents located on the bottom and sides of the cooktop.
- Keep the cooktop at least 4 inches (10 cm) away from walls or other appliances to allow for proper airflow.

3. Power Connection

Plug the power cord into a standard 120V AC electrical outlet. The cooktop is rated for 1800 watts. Ensure the outlet can support this wattage.

4. Compatible Cookware

The NuWave PIC Titanium works only with induction-compatible cookware. This includes pots and pans made of cast iron, enameled iron, steel, or stainless steel with a magnetic bottom. To test compatibility, hold a magnet to the bottom of your cookware. If it sticks, the cookware is compatible.

- Minimum cookware diameter: 4.5 inches (11.4 cm).
- Maximum cookware diameter: 12 inches (30.5 cm).

Operating Instructions

1. Powering On/Off

- Place induction-compatible cookware with food on the center of the cooktop.
- Press the **ON/OFF** button to turn the unit on. The display will illuminate.
- To turn off, press the **ON/OFF** button again.

2. Temperature Control

The NuWave PIC Titanium allows for precise temperature adjustments in 5-degree increments, ranging from 100°F to 575°F (38°C to 302°C). Use the **TEMP +** and **TEMP -** buttons to set your desired cooking temperature.

3. Wattage Adjustment

This model features a variable wattage adjuster. Press the **WATTAGE** button to cycle through the available power settings: 600W, 900W, and 1800W. This is useful for situations requiring lower power consumption, such as camping, RV use, or boating, or for delicate cooking tasks.

4. Delayed Shutoff Feature

If you temporarily remove your cookware from the cooktop surface during operation, the unit will pause. You can replace the cookware within 10 seconds to continue cooking without needing to restart the entire process. If cookware is not replaced within 10 seconds, the unit will automatically shut off.

5. Using the Timer

The built-in timer allows you to set a cooking duration. Press the **TIMER** button, then use the **+** and **-** buttons to adjust the time. The cooktop will automatically shut off once the timer expires.

6. Included Accessories

Your NuWave PIC Titanium comes with a NuWave PIC Complete Cookbook and a Quick Start Cooking Guide to help you get started with various recipes and cooking techniques.

Care and Maintenance

1. Cleaning the Cooktop

- Always unplug the cooktop and allow it to cool completely before cleaning.
- Wipe the ceramic glass surface with a damp cloth and a mild detergent. For stubborn stains, a non-abrasive cleaner specifically designed for ceramic cooktops can be used.
- Do not use abrasive pads, harsh chemicals, or steel wool, as these can scratch the surface.
- Wipe the control panel and exterior with a soft, damp cloth. Ensure no water enters the internal components.
- Never immerse the cooktop in water or any other liquid.

2. Storage

Ensure the cooktop is clean and dry before storing. Store it in a cool, dry place, preferably in its original packaging, away from direct sunlight and moisture.

Troubleshooting

If you encounter issues with your NuWave PIC Titanium, please refer to the following common problems and solutions:

Cooktop Does Not Turn On

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check your household circuit breaker or fuse box.
- Verify that the ON/OFF button has been pressed.

Cookware Not Heating / Error Code Displayed

- Ensure you are using induction-compatible cookware (magnetic bottom).
- Verify the cookware is centered on the heating zone.
- Check if the cookware diameter is within the recommended range (4.5 to 12 inches).
- If an error code (e.g., E0, E1, E2) is displayed, consult the Quick Start Guide or contact customer support for specific meanings and solutions.

Food Not Cooking Evenly

- Ensure the cookware has a flat bottom and is making full contact with the cooktop surface.
- Adjust the temperature setting.
- Consider the type and thickness of your cookware, as this can affect heat distribution.

For issues not covered here, please refer to the Warranty and Support section for contact information.

Specifications

Feature	Detail
Brand	Nuwave
Model Number	30341
Manufacture Year	2016
Wattage	1800 watts (Variable: 600W, 900W, 1800W)
Heating Elements	1
Controls Type	Touch
Burner Type	Radiant (Induction)
Special Feature	Adjustable Power Outage
Power Source	Induction
Item Weight	0.27 g (Note: This value seems unusually low and may be a data entry error. Please refer to product packaging for accurate weight.)
Included Components	NuWave PIC Complete Cookbook, Quick Start Cooking Guide
UPC	652185303416
ASIN	B00TPZYFK2

Warranty and Support

The NuWave PIC Titanium Induction Cooktop is engineered for durability, with an average lifespan of 13 to 15 years. This product is covered by a manufacturer's warranty against defects in materials and workmanship under normal household use.

For specific warranty details, including duration and coverage, please refer to the warranty card included with your product or visit the official NuWave website.

If you require technical assistance, have questions about operation, or need to make a warranty claim, please contact NuWave Customer Support:

- **Website:** www.nuwaveoven.com
- **Phone:** Refer to the contact information provided in your product packaging or on the official website.

Please have your model number (30341) and purchase date available when contacting support.

© 2024 Nuwave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00TPZYFK2

More documents and user manuals: **https://manuals.plus/**