

[Manuals.plus](#) /

> [Samsonite](#) /

> Samsonite S'Cure Spinner L Suitcase User Manual

Samsonite S'Cure Spinner L (75 cm - 102 L)

Samsonite S'Cure Spinner L Suitcase User Manual

Model: S'Cure Spinner L (75 cm - 102 L)

INTRODUCTION

Thank you for choosing the Samsonite S'Cure Spinner L suitcase. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new luggage. The S'Cure Spinner L is designed for durability and ease of use, featuring a robust polypropylene shell, multi-directional spinner wheels, and a secure locking system, ideal for two-week stays.

PRODUCT OVERVIEW

The Samsonite S'Cure Spinner L is a large suitcase crafted from 100% Flowlite polypropylene, offering a lightweight yet strong solution for your travel needs. Its design focuses on security, maneuverability, and efficient packing.

Key Features:

- **Durable Construction:** Made from 100% Flowlite polypropylene for impact resistance.
- **Multi-directional Spinner Wheels:** Four double castors allow for smooth 360-degree rotation and effortless movement.
- **Secure Locking System:** Features a three-point locking system with an integrated TSA lock and a seal for enhanced water resistance.
- **Telescopic Pull Handle:** A double tube pull handle provides comfortable grip and adjustable height.
- **Functional Interior:** Equipped with low cross straps in one compartment and a zipped divider tray with a large storage pocket in the other, to keep belongings organized.



Image: Front view of the Samsonite S'Cure Spinner L suitcase, showcasing its silver hard shell and telescopic handle.



Image: Interior view of the Samsonite S'Cure Spinner L suitcase, showing the cross straps and zipped divider for organized packing.

SETUP

Setting the TSA Combination Lock

Your Samsonite S'Cure suitcase is equipped with a TSA-approved combination lock. The initial combination is typically 0-0-0. To set your personal combination:

1. Open the suitcase by sliding the TSA lock button (if locked) or ensuring the default 0-0-0 combination is set.
2. Locate the small reset button or lever next to the combination dials. This is usually a small, recessed button that requires a pen or pointed object to press.
3. Press and hold the reset button/lever.
4. While holding the reset button/lever, set your desired 3-digit combination by rotating the dials.
5. Release the reset button/lever. Your new combination is now set.
6. Test your new combination by scrambling the dials and then entering your new code to open the lock.

Important: Remember your combination. Samsonite cannot open your lock or provide your combination if you forget it.



Image: Detailed view of the integrated TSA combination lock on the Samsonite S'Cure suitcase.

OPERATING YOUR SUITCASE

Using the Telescopic Handle

The suitcase features a multi-stage telescopic handle for comfortable maneuvering. To extend the handle, press the button located on the top of the handle and pull upwards. To retract, press the button again and push the handle down until it is fully nested.



Image: Close-up of the ergonomic button on the telescopic handle for extension and retraction.

Maneuvering with Spinner Wheels

Your S'Cure Spinner L is equipped with four double spinner wheels, allowing for 360-degree rotation. This enables you to push, pull, or roll the suitcase alongside you with minimal effort, enhancing maneuverability in crowded spaces.



Image: Detailed view of the durable double spinner wheels designed for smooth movement.

Packing Your Suitcase

The interior of the S'Cure Spinner L is designed for efficient packing. Utilize the low cross straps in one compartment to secure your clothing and prevent shifting during transit. The other compartment features a zipped divider tray with an integrated pocket, ideal for separating items or storing smaller accessories.



Image: Interior of the suitcase demonstrating the cross straps and zipped divider for organized packing.

MAINTENANCE

Cleaning the Exterior

To clean the polypropylene exterior, wipe with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or solvents, as these can damage the finish. Dry thoroughly after cleaning.

Wheel and Handle Care

Periodically check the wheels for debris such as hair or lint and remove them to ensure smooth operation. The telescopic handle mechanism should be kept free of dirt and obstructions. Do not force the handle if it feels stiff.

Storage

Store your suitcase in a cool, dry place away from direct sunlight when not in use. Avoid placing heavy objects on top of the suitcase during storage to prevent deformation.

TROUBLESHOOTING

- **Wheels not rolling smoothly:** Check for and remove any debris (hair, lint, dirt) caught in the wheel axles. If the issue persists, contact customer support.
- **Telescopic handle is stiff or stuck:** Ensure no items are obstructing the handle mechanism inside the suitcase. Do not force the handle. If it remains stuck, contact customer support.
- **Combination lock not opening:** Double-check that you are entering the correct 3-digit combination. If you have forgotten your combination, you will need to contact Samsonite customer service for assistance, as there is no universal override.
- **Suitcase not closing properly:** Ensure that the contents are not over-packed and that no fabric or items are caught in the sealing mechanism. The three-point locking system requires proper alignment to close securely.

SPECIFICATIONS

Model	S'Cure Spinner L
Size	L (75 cm - 102 L)
Dimensions (L x W x H)	29.53" x 20.47" x 12.2" (75 cm x 52 cm x 31 cm)
Capacity	102 Liters
Weight	4.6 Kilograms
Material	100% Polypropylene Flowlite
Shell Type	Hard
Wheel Type	Spinner (4 double castors)
Lock Type	TSA Combination Lock (3-point locking)
Handle Type	Telescopic Extendable Handle
Water Resistance Level	Waterproof (with seal)
Manufacturer Part Number	49539



Image: Size comparison chart for Samsonite S'Cure suitcases, illustrating S, M, L, and XL sizes relative to human height.

WARRANTY AND SUPPORT

Samsonite products are manufactured to stringent standards and undergo rigorous quality control. For information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official Samsonite website.

If you require assistance with repairs, replacement parts, or have any questions not covered in this manual, please contact Samsonite customer service. Contact details can typically be found on the Samsonite website or on your purchase documentation.

Online Support: For the most up-to-date support information, FAQs, and service center locations, please visit the official [Samsonite website](#).

