

## **BANDAI Complete Selection Modification Rider Card**

# **Bandai Complete Selection Modification Rider Card Set Instruction Manual**

*Model: Complete Selection Modification Rider Card*

---

## **INTRODUCTION**

This manual provides essential instructions for the proper use and care of your Bandai Complete Selection Modification Rider Card set. Please read this manual thoroughly before use to ensure optimal enjoyment and longevity of your product.


## **WHAT'S IN THE BOX**

The Bandai Complete Selection Modification Rider Card set includes the following components:

- Rider Cards (77 cards)
- 4-Pocket Binders (2 binders)
- Instruction Booklet

## セット内容

### カード 77枚



※画像はイメージです。実際の商品とは異なります。

### 4ポケットバインダー2冊



### 小冊子



Image: Overview of the complete set contents, including the 77 Rider Cards, two 4-pocket binders, and the instruction booklet.

## SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Inspect for any damage.
2. **Card Organization:** The set includes 77 Rider Cards. It is recommended to organize these cards into the provided 4-pocket binders for protection and easy access.




Image: Detailed view of the 77 Rider Cards, showcasing their unique designs.

3. **Binder Use:** Insert the cards into the pockets of the binders. Ensure cards are fully seated to prevent bending or damage.



Image: The two 4-pocket binders, featuring artwork related to Kamen Rider Decade, used for card storage.

## OPERATING THE RIDER CARDS

These Rider Cards are designed for use with compatible Bandai Complete Selection Modification (CSM) devices, such as the CSM Decadriver (sold separately). The cards feature unique codes and designs that interact with these devices to activate sounds and lights, replicating effects from the Kamen Rider series.

- **Card Insertion:** Insert a Rider Card into the designated slot of your compatible CSM device. Ensure the card is inserted correctly, facing the right direction as indicated by the device's instructions.
- **Activation:** Once inserted, the device will typically recognize the card and activate specific sounds or phrases associated with that Rider or ability.
- **Experimentation:** Explore the various cards and their unique interactions with your CSM device. Some cards may trigger different effects depending on the device or sequence of insertion.

*Note: This product consists of collectible cards and does not include any electronic devices. A compatible*

CSM device is required to experience the full interactive features of these cards.

## MAINTENANCE

- **Cleaning:** To clean the cards, gently wipe them with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the card surface and printing.
- **Storage:** Store cards in the provided binders or other protective sleeves to prevent bending, scratching, or exposure to dust and moisture. Keep the binders in a cool, dry place away from direct sunlight.
- **Handling:** Handle cards by their edges to avoid leaving fingerprints or smudges on the printed surfaces.

## TROUBLESHOOTING

If you encounter issues while using your Rider Cards with a compatible CSM device, consider the following:

- **Card Not Recognized:**
  - Ensure the card is inserted correctly and fully into the device's slot.
  - Check for any obstructions in the card slot.
  - Verify that the CSM device itself is powered on and functioning correctly (refer to the device's manual).
- **Damaged Cards:** If a card is bent, torn, or has significant wear, it may not be recognized by the device. Handle cards with care to prevent damage.

## SPECIFICATIONS

Feature	Detail
Product Name	Complete Selection Modification Rider Card
Brand	BANDAI
Model Number	B00TTBVPSM
Number of Cards	77
Included Accessories	2 x 4-Pocket Binders, 1 x Instruction Booklet
Recommended Age	6 years and up
Product Dimensions	13.23 x 8.11 x 4.65 inches
Item Weight	3.73 pounds

## WARRANTY AND SUPPORT

For information regarding warranty, returns, or product support, please refer to the retailer's policy where the product was purchased or visit the official BANDAI website. Keep your proof of purchase for any warranty claims.

For further assistance, you may contact BANDAI customer service through their official channels.

---

© 2023 BANDAI. All rights reserved.