



Manuals.plus /

- › Sharp /
- › Sharp LC-40LE653U 40-Inch Smart LED TV User Manual

Sharp LC-40LE653U

Sharp LC-40LE653U 40-Inch Smart LED TV User Manual

Model: LC-40LE653U

1. SETUP

1.1 Unpacking and Contents

Carefully remove the TV and all accessories from the packaging. Ensure all components are present:

- Sharp LC-40LE653U 40-Inch Smart LED TV
- Remote Control
- 2 AA Batteries

1.2 Stand Installation

If placing the TV on a table, attach the included stand. Refer to the diagram below for proper assembly. Ensure all screws are securely fastened.




Figure 1.2.1: TV Dimensions and Stand Placement. This image illustrates the overall dimensions of the television, including its depth, width, and height, which are crucial for stand installation and placement.

1.3 Connecting External Devices

Connect your external devices such as cable boxes, Blu-ray players, or gaming consoles to the TV's input ports. The TV features multiple connectivity options.





Figure 1.3.1: Side Panel Connections. This image displays the side profile of the TV, highlighting accessible ports such as USB and HDMI for convenient connection of devices.



Figure 1.3.2: Rear Panel Connections. A detailed view of the rear input panel, showing HDMI, Ethernet, Component/Video, and DTV/TV (Antenna) ports. This is where most permanent connections are made.

Available ports include:

- **HDMI:** 2 ports for high-definition audio and video. One HDMI port supports MHL (Mobile High-Definition Link).
- **USB:** 1 port for media playback or connecting a USB device.
- **Ethernet:** For wired network connection.
- **Component/Video:** For older video devices.
- **DTV/TV (Antenna):** For connecting an antenna or cable TV feed.
- **Audio Out:** Optical for digital audio, and RCA for analog audio.

1.4 Power Connection

After connecting all necessary devices, plug the TV's power cord into a wall outlet.

1.5 Initial Setup

Upon first power-on, the TV will guide you through an initial setup process. This includes language selection, time zone, and network configuration. For Wi-Fi setup, select your network and enter the password.

2. OPERATING INSTRUCTIONS

2.1 Remote Control Functions

The remote control allows you to access all TV functions. Insert the two AA batteries into the remote control, ensuring correct polarity.





Figure 2.1.1: Remote Control Layout. This image displays the full layout of the remote control, including power, input, volume, channel, navigation, and dedicated app buttons like Netflix.

- **Power (Red Button):** Turns the TV on or off.
- **Input:** Selects the input source (HDMI, TV, USB, etc.).
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes TV channels.
- **Navigation Buttons (Up/Down/Left/Right/Enter):** Used to navigate menus and select options.
- **SMART:** Accesses the Smart Central Apps menu.
- **MENU:** Opens the main TV menu for settings adjustments.
- **NETFLIX:** Direct access button for the Netflix application.

2.2 Smart TV Features (Smart Central Apps)

The Sharp LC-40LE653U features Smart Central Apps, providing access to various online services and a web browser. Ensure your TV is connected to the internet via Wi-Fi or Ethernet.



Figure 2.2.1: Smart Central Apps Interface. This image shows the TV screen with the Smart Central Apps overlay, featuring icons for Netflix, YouTube, Pandora, and other applications.

- **Accessing Apps:** Press the 'SMART' button on your remote to open the Smart Central Apps menu.
- **Supported Services:** Includes Hulu Plus, Netflix, Pandora, Vudu, and YouTube.
- **Web Browser:** Use the built-in web browser for general internet browsing. Navigation is done via the remote control.

2.3 Wallpaper Mode

When the TV is turned off, Wallpaper Mode can display virtually any image. To use this feature, connect a USB drive containing your desired images to the TV's USB port. Navigate to the Wallpaper Mode settings in the TV menu to select and configure your images.

3. MAINTENANCE

3.1 Cleaning the TV

To clean the screen, gently wipe it with a soft, dry, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals, abrasive cleaners, or direct spraying of liquids onto the screen or cabinet.

Clean the TV cabinet with a soft, dry cloth. Ensure the TV is unplugged before cleaning.

3.2 Software Updates

Periodically check for software updates through the TV's settings menu to ensure optimal performance and access to the latest features. Updates can be performed via the internet connection.

4. TROUBLESHOOTING

If you encounter issues with your Sharp LC-40LE653U TV, refer to the following common solutions:

- **No Power:** Ensure the power cord is securely plugged into both the TV and a working wall outlet. Check if the power indicator light on the TV is on.
- **No Picture/Sound:** Verify the correct input source is selected using the 'Input' button on the remote. Check all cable connections (HDMI, component, etc.) are secure.
- **Poor Picture Quality:** Adjust picture settings (brightness, contrast, sharpness) in the TV menu. Ensure the input source is providing a high-quality signal.
- **No Internet Connection:** Check your Wi-Fi router or Ethernet cable connection. Re-enter your Wi-Fi password in the TV's network settings. Restarting your router may resolve connectivity issues.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.

For more detailed troubleshooting steps, consult the full online manual or contact customer support.

5. SPECIFICATIONS

Key technical specifications for the Sharp LC-40LE653U 40-Inch Smart LED TV:

| Feature | Specification |
|--------------------------------|--|
| Model Number | LC-40LE653U |
| Screen Size | 39.5 Inches (40-Inch Class) |
| Display Technology | LCD |
| Resolution | 1080p (Full HD) |
| Refresh Rate | 60 Hz |
| Aspect Ratio | 16:9 |
| Connectivity Technology | Wi-Fi |
| Hardware Interface | Ethernet, HDMI, USB |
| Total Number of HDMI Ports | 2 (one with MHL support) |
| Total USB Ports | 1 |
| Audio Input | HDMI, Optical, USB |
| Speaker Maximum Output Power | 20 Watts |
| Product Dimensions (D x W x H) | 7.56" x 35.5" x 21.91" |
| Item Weight | 16.3 Pounds |
| Mounting Type | Table Mount |
| Supported Internet Services | Hulu Plus, Netflix, Pandora, Vudu, YouTube |
| Energy Star Certified | Yes |

6. WARRANTY AND SUPPORT

6.1 Product Warranty

This Sharp LC-40LE653U TV comes with a **1-year limited warranty**. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use conditions.

6.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Sharp customer support. Refer to the official Sharp website or your product registration card for the most current contact information.