

Quercetti 064344

Quercetti Skyrail Jurassic Marble Run

Model: 064344

WELCOME TO YOUR SKYRAIL JURASSIC ADVENTURE!

Thank you for choosing the Quercetti Skyrail Jurassic Marble Run. This toy allows you to construct intricate and exciting ball tracks, extending up to 6 meters in length. It provides a dynamic setting for prehistoric adventures with your favorite dinosaur-themed marbles.

The Skyrail Jurassic is designed to be used with large transparent balls, often containing dinosaur figures, facilitating engaging observations and experiments in physics. Users can intuitively grasp fundamental principles such as velocity, gravity, centrifugal force, and friction through play.

This product is designed to stimulate creativity and reasoning in children aged 4 to 15 years. It is manufactured in Italy and adheres to international safety standards, ensuring a child-safe play experience.

PACKAGE CONTENTS

Upon opening your Quercetti Skyrail Jurassic Marble Run, please ensure all components are present. The set includes 127 puzzle pieces for track construction and a detailed instruction manual.

If any parts are missing or damaged, please contact customer support.

ASSEMBLY INSTRUCTIONS

Assembly is required for the Skyrail Jurassic Marble Run. Please follow these general steps to construct your track. Refer to the included printed instructions for detailed diagrams and specific piece identification.

1. **Unpack Components:** Carefully remove all 127 pieces from the packaging. Sort them by type (e.g., bases, pillars, straight tracks, curved tracks, connectors).
2. **Construct the Base:** Begin by assembling the base supports. These provide stability for the entire structure.
3. **Erect Pillars:** Attach the support pillars to the base sections. Ensure they are securely fastened and upright.

4. **Connect Track Sections:** Start connecting the track pieces to the pillars, following the design in the instruction manual or creating your own unique layout. Ensure all connections are firm to prevent track separation during play.
5. **Integrate Special Features:** If your design includes loops, spirals, or other special track elements, integrate them according to the instructions.
6. **Final Check:** Once assembled, gently test the stability of the entire structure. Ensure all track pieces are correctly aligned and securely connected.



Image: The fully assembled Quercetti Skyrail Jurassic Marble Run, showcasing its intricate track design and marbles in motion.

OPERATING INSTRUCTIONS

Once your Skyrail Jurassic Marble Run is fully assembled and stable, it's time to begin playing.

1. **Select Marbles:** Use the large transparent marbles provided or other suitable marbles. Ensure marbles are not too small to avoid choking hazards for young children.

2. **Place Marbles:** Position a marble at the designated starting point at the highest elevation of your track.
3. **Release and Observe:** Release the marble and watch it travel through the various twists, turns, and drops of your Skyrail Jurassic track. Observe how gravity and momentum affect its speed and trajectory.
4. **Experiment:** Try different starting points, release marbles simultaneously, or modify small sections of the track to observe changes in marble behavior.




Image: A child engaging with the Quercetti Skyrail Jurassic Marble Run, demonstrating active play and interaction with the toy.



Image: A detailed view of one of the transparent marbles, featuring a Nodosaurus dinosaur figure encased within, used with the marble run.

CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your Quercetti Skyrail Jurassic Marble Run, please follow these care guidelines:

- **Cleaning:** Wipe plastic components with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the plastic.
- **Storage:** When not in use, store the marble run in a cool, dry place away from direct sunlight. Disassembling the track for storage can help prevent warping or damage to the plastic pieces.
- **Inspection:** Periodically inspect all track pieces and connectors for any signs of wear, cracks, or damage. Replace any compromised parts to maintain structural integrity and safety.

TROUBLESHOOTING GUIDE

If you encounter any issues while using your Skyrail Jurassic Marble Run, refer to the following common problems and solutions:

- **Marbles getting stuck:**
 - Check for misaligned track pieces. Ensure all connections are flush and smooth.
 - Verify that the track has sufficient incline in all sections to allow marbles to roll freely.
 - Ensure no foreign objects or debris are obstructing the track.
- **Unstable structure:**
 - Confirm that all base supports are placed on a flat, stable surface.
 - Ensure all pillar and track connections are fully engaged and secure.
 - Avoid building excessively tall or wide structures without adequate support points.
- **Pieces not fitting together:**
 - Ensure you are using the correct pieces for the intended connection. Refer to the printed instruction manual for diagrams.
 - Apply gentle, even pressure when connecting pieces. Do not force them, as this can cause damage.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Quercetti
Model Number	064344
Number of Puzzle Pieces	127
Product Dimensions (L x W x H)	40 x 9 x 34 cm
Item Weight	1.32 kg
Manufacturer Recommended Age	4 - 15 years
Educational Objective	Colour Recognition, Creative Skill
Assembly Required	Yes
Batteries Required	No
Color	Multicolor
Manufacturer	Quercetti and CSPA

WARRANTY AND CUSTOMER SUPPORT

Specific warranty information for the Quercetti Skyrail Jurassic Marble Run is not available in the provided product data. For details regarding warranty coverage, returns, or to contact customer support for assistance with your product, please refer to the contact information provided on the product packaging or the official Quercetti website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question