

Manuals.plus /

- › LG /
- › LG BP250 Blu-Ray and DVD Disc Player User Manual

## LG BP250.DGBRLLK

# LG BP250 Blu-Ray and DVD Disc Player User Manual

MODEL: BP250.DGBRLLK

This manual provides essential information for the safe and efficient operation of your LG BP250 Blu-Ray and DVD Disc Player. Please read it thoroughly before use and retain it for future reference.

## 1. Setup

Follow these steps to set up your LG BP250 Blu-Ray and DVD Disc Player.

### 1.1 Package Contents

- LG BP250 Blu-Ray and DVD Disc Player
- Remote Control
- Power Lead (UK Plug)
- Instruction Manual (this document)

Note: An HDMI cable is not included and must be purchased separately for connecting to your TV.

### 1.2 Connecting the Player

1. Connect one end of an HDMI cable (not supplied) to the HDMI OUT port on the rear of the player.
2. Connect the other end of the HDMI cable to an HDMI IN port on your television.
3. Connect the supplied power lead to the AC IN port on the rear of the player, then plug the other end into a wall outlet.
4. Turn on your television and select the correct HDMI input source.



Image: Rear view of the LG BP250 Blu-Ray player, highlighting the HDMI output and power input ports for connection to a television and power supply.

### 1.3 Initial Setup

Upon first power-on, the player may guide you through an initial setup wizard. Follow the on-screen prompts to select your preferred language and other basic settings.

## 2. Operating Instructions

This section details the primary functions and operations of your Blu-Ray player.

### 2.1 Basic Disc Playback

1. Press the **POWER** button on the player or remote control to turn on the unit.
2. Press the **OPEN/CLOSE** button (*eject icon*) on the player or remote control to open the disc tray.
3. Place a Blu-Ray or DVD disc gently onto the disc tray with the label side facing up.
4. Press the **OPEN/CLOSE** button again to close the disc tray.
5. The player will automatically begin reading the disc. If a menu appears, use the arrow buttons on the remote to navigate and the **ENTER** button to select.




Image: Front view of the LG BP250 Blu-Ray player, showing the disc tray and front panel controls.

## 2.2 USB Playback

The player supports playback of media files from external USB storage devices.

- Insert a USB storage device into the USB port on the front of the player.
- Navigate to the USB input source using the remote control.
- Browse your files and select the desired media for playback.

Supported media types include: MP4, MP3, AAC, FLAC, WMA, PCM.

## 2.3 Full HD Up-scaling

The LG BP250 features Full HD Up-scaling, which enhances the picture quality of standard definition DVDs to near Full HD resolution when connected to a compatible television.

# 3. Maintenance

Proper maintenance ensures the longevity and optimal performance of your player.

## 3.1 Cleaning

- Disconnect the power cord before cleaning.
- Use a soft, dry cloth to wipe the exterior of the player. Do not use liquid cleaners or abrasive materials.
- For discs, wipe gently from the center outwards with a clean, lint-free cloth.

## 3.2 Firmware Updates

Firmware updates may be released periodically to improve performance or add features. These updates are typically performed via USB.

1. Visit the official LG support website for your model (BP250.DGBRLLK) to check for available firmware updates.
2. Download the firmware file to a USB storage device.
3. Insert the USB device into the player's USB port and follow the on-screen instructions to initiate the update process.

Caution: Do not power off the player or remove the USB device during a firmware update.

# 4. Troubleshooting

Refer to this section for solutions to common issues you may encounter.

Problem	Possible Cause / Solution
No picture on TV.	<p>Ensure the HDMI cable is securely connected to both the player and the TV.</p> <p>Verify that your TV is set to the correct HDMI input source.</p> <p>Check if the player is powered on.</p>
No sound.	<p>Check the audio settings on your TV and the player.</p> <p>Ensure the TV volume is not muted or set too low.</p> <p>If using an external audio system, verify its connections and input selection.</p>
Disc does not play.	<p>Ensure the disc is clean and free of scratches or smudges.</p> <p>Verify the disc type is supported by the player (Blu-Ray, DVD).</p> <p>Check if the disc is inserted correctly with the label side facing up.</p> <p>If the disc is recorded in NTSC format and you have a PAL color system TV, you may see distorted images. Ensure your TV is a multi-system color TV to receive all signals.</p>
Remote control not working.	<p>Check and replace the batteries (1 A battery required).</p> <p>Ensure there are no obstructions between the remote and the player's sensor.</p> <p>Point the remote directly at the player.</p>

## 5. Specifications

Key technical specifications for the LG BP250 Blu-Ray and DVD Disc Player.

Feature	Detail
Model Number	BP250.DGBRLLK
Product Dimensions (W x D x H)	27 x 19.5 x 4.3 cm
Item Weight	830 Grams
Power Consumption (On-mode)	12 Watts
Connectivity Technology	HDMI, Optical Audio
Connector Type	HDMI, USB (front)
Resolution	1920x1080 (Full HD)
Special Features	3D Playback, Full HD Up-scaling, External HDD playback
Supported Media Types	Blu-Ray Disc, DVD, MP4, MP3, AAC, FLAC, WMA, PCM
Colour	Black
Batteries Required	1 A battery (for remote)



Image: The LG BP250 Blu-Ray player with an overlay indicating its compact dimensions: 270 mm width, 195 mm depth, and 43 mm height.

## 6. Warranty and Support

For warranty information and technical support, please refer to the following:

- **Warranty:** Your LG BP250 Blu-Ray and DVD Disc Player comes with a standard manufacturer's warranty. Please retain your proof of purchase for warranty claims. Specific warranty terms and duration may vary by region.
- **Technical Support:** For further assistance, troubleshooting not covered in this manual, or service requests, please visit the official LG Electronics support website or contact LG customer service in your region.
- **Online Resources:** Additional support documents, FAQs, and software updates can be found on the LG website.