

Battat BT7252C1Z

Battat Play Circle Kids' Toy Ironing Board Set (Model BT7252C1Z) - Instruction Manual

Your guide to setting up, operating, and maintaining your toy ironing set.

INTRODUCTION

The Battat Play Circle Best Pressed Kid's Ironing Board Set is a 3-piece pretend ironing board and iron designed for children aged 3 and up. This set allows children to engage in imaginative play, mimicking household tasks in a safe and fun environment. The toy iron features realistic steaming sounds and a "ready" light, while the ironing board is foldable for convenient storage.

WHAT'S INCLUDED

- 1 pink plastic toy iron with light and sounds
- 1 foldable pink plastic ironing board
- 1 removable ironing board cover

Batteries are included with the toy iron.

SETUP INSTRUCTIONS

1. Remove all components from the packaging.
2. Unfold the ironing board to its upright position. Ensure all locking mechanisms (if present) are securely engaged.
3. Place the ironing board cover onto the ironing board.
4. Locate the battery compartment on the toy iron. Insert the included batteries, ensuring correct polarity. Securely close the battery compartment.



Figure 1: Assembled Battat Play Circle Toy Ironing Board Set. The pink ironing board is unfolded with the toy iron resting on its stand.

OPERATING INSTRUCTIONS

1. Place the toy iron onto the ironing board.
2. To activate the realistic steam sounds and "ready" light, gently press the toy iron onto a piece of fabric or the ironing board cover.
3. The iron is designed for pretend play and does not generate heat.



Figure 2: A child engaging in pretend play, pressing the toy iron onto the ironing board. The iron is pink and teal, and the ironing board has a colorful polka-dot cover.

Video Demonstration: Toy Iron Features

Your browser does not support the video tag.

Video 1: This video demonstrates the sound and light features of the Battat Play Circle toy iron. It shows the iron being pressed down to activate the realistic steam sounds and the "ready" light.

MAINTENANCE AND CARE

- **Toy Iron:** Clean the surface of the toy iron with a damp cloth and a small amount of mild soap. Do not immerse the iron in water.
- **Ironing Board Cover:** The polyester fabric ironing board cover can be machine washed on a delicate cycle. Hang to dry.
- **Storage:** The ironing board folds flat for easy storage when not in use.



Figure 3: The Battat Play Circle Toy Ironing Board shown in its folded, compact state for convenient storage.

SAFETY INFORMATION

- This toy is recommended for ages 3 and up due to small parts.
- The toy iron does not produce heat and is safe for children to use for pretend play.
- All Play Circle products meet or exceed US & CAN safety standards.
- Adult supervision is recommended during play.

PRODUCT SPECIFICATIONS

Brand	Battat
Model Number	BT7252C1Z
Product Dimensions	7.5 x 19.75 x 19 inches
Item Weight	2.68 pounds
Recommended Age	36 months - 8 years
Batteries	4 CR123A batteries (included)
Manufacturer	Branford Ltd



Figure 4: Diagram illustrating the approximate dimensions of the Battat Play Circle Toy Ironing Board, showing a height of 19 inches and a length of 18.5 inches.

TROUBLESHOOTING

If the toy iron's sounds or lights are not functioning:

- Check the battery compartment to ensure batteries are correctly inserted and not depleted. Replace batteries if necessary.
- Ensure the iron is being pressed firmly enough to activate the internal switch for sounds and lights.

For any other issues, please refer to the warranty and support section.

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or additional support, please contact Battat customer service.

Contact details can typically be found on the product packaging or the official Battat website.

You can also visit the official [Battat Store on Amazon](#) for more information.