

**BLACK+DECKER VF110**

# **BLACK+DECKER VF110 Dustbuster Replacement Filter Instruction Manual**

## **1. INTRODUCTION**

This instruction manual provides detailed guidance for the proper installation, maintenance, and care of your BLACK+DECKER VF110 Dustbuster Replacement Filter. Adhering to these instructions will help ensure the optimal performance and extended lifespan of your handheld vacuum cleaner.

---

## **2. PRODUCT OVERVIEW**



Image: The BLACK+DECKER VF110 Dustbuster Replacement Filter, shown as a pack of five filters.

The BLACK+DECKER VF110 is a genuine OEM replacement filter designed for various BLACK+DECKER Dustbuster handheld vacuum models. This filter is crucial for maintaining the suction power and efficiency of your vacuum by trapping dust and debris, preventing them from re-entering the air or damaging the motor. Each pack contains five replacement filters, ensuring you have spares readily available.

### 3. COMPATIBILITY

The BLACK+DECKER VF110 Replacement Filter (part number 90558113) is compatible with the following Dustbuster models:

- BDH1220AV Type 1
- BDH2000L Type 1
- CHV1210 Type 1
- CHV1410 Type 1
- CHV1410B Type 1
- CHV1410L Type 1
- CHV1510 Type 1
- CHV9610 Type 1
- BDH2010LP

Please verify your vacuum's model number to ensure proper fit and function.

---

## 4. INSTALLATION INSTRUCTIONS

Follow these steps to replace the filter in your BLACK+DECKER Dustbuster:

1. **Ensure the vacuum is off and unplugged:** Disconnect the vacuum from its charging base or power source before proceeding.
  2. **Remove the dust bowl:** Locate the release button or latch on your Dustbuster and detach the dust bowl from the main unit.
  3. **Remove the old filter:** Carefully pull out the existing filter from the dust bowl. Dispose of the old filter responsibly.
  4. **Clean the dust bowl:** Empty any debris from the dust bowl and wipe it clean with a damp cloth if necessary. Ensure it is dry before reassembly.
  5. **Insert the new filter:** Place the new BLACK+DECKER VF110 filter into the dust bowl, ensuring it is seated correctly and securely. The filter should fit snugly.
  6. **Reattach the dust bowl:** Align the dust bowl with the main vacuum unit and snap it back into place until you hear a click, indicating it is securely fastened.
  7. **Test the vacuum:** Plug in or charge your Dustbuster and perform a brief test to ensure it operates correctly with the new filter.
- 

## 5. MAINTENANCE

Regular maintenance of your VF110 filter is essential for optimal vacuum performance:

- **Regular Cleaning:** The VF110 filter is reusable. After each significant use or when suction power appears reduced, remove the filter and gently tap it over a waste bin to dislodge accumulated dust and debris. For a more thorough cleaning, the filter can be rinsed under cool running water.
  - **Drying:** If rinsed, allow the filter to air dry completely for at least 24 hours before reinserting it into the vacuum. Do not use heat to dry the filter, as this can damage the material.
  - **Replacement:** It is recommended to replace the filter every 6 to 12 months, or more frequently if the vacuum is used often or for heavy-duty cleaning. Replace the filter immediately if you notice any tears, holes, or significant degradation of the filter material, as this can compromise filtration and potentially damage the vacuum motor.
- 

## 6. TROUBLESHOOTING

If you encounter issues with your Dustbuster after filter replacement, consider the following:

- **Reduced Suction:** If suction power is low, ensure the filter is clean and properly seated. A clogged or improperly installed filter is a common cause of reduced suction. If the filter is old or damaged, replace it with a new one.

- **Filter Degradation:** The filter material is designed to capture fine particles. Over time, or with improper handling, the material may show signs of wear or tear. If the filter material appears to be deteriorating or falling apart, it indicates the filter needs immediate replacement to prevent debris from entering the motor.
- **Unusual Noises:** Ensure all parts, including the dust bowl and filter, are correctly assembled and securely latched. Loose components can cause unusual noises during operation.

---

## 7. SPECIFICATIONS

<b>Item Model Number</b>	90558113
<b>Product Dimensions</b>	5.19"L x 3.62"W x 4.87"H
<b>Item Weight</b>	2.72 ounces
<b>Material</b>	Plastic
<b>Number of Pieces</b>	5
<b>Reusability</b>	Reusable

---

## 8. WARRANTY AND SUPPORT

For information regarding product warranty, technical support, or to purchase additional replacement parts, please refer to the official BLACK+DECKER website or contact their customer service directly. Keep your proof of purchase for any warranty claims.