

Lumisky STANDY W150

Lumisky Standy W150 Wired Floor Lamp

User Instruction Manual

1. INTRODUCTION

The Lumisky Standy W150 is a modern and sleek wired LED floor lamp designed for both indoor and outdoor environments. It provides cold white LED illumination and features an E27 bulb socket. This manual provides essential information for the safe and proper installation, operation, and maintenance of your Lumisky Standy W150 floor lamp.

Please read this manual thoroughly before using the product and retain it for future reference.

2. SAFETY INFORMATION

- This product is not suitable for children under 3 years of age. Use under adult supervision is required.
- Ensure the lamp is placed on a stable, level surface to prevent tipping.
- The lamp is splash-proof (IP44 rated), making it suitable for outdoor use in areas where it may be exposed to splashes, but it should not be submerged in water.
- Always disconnect the power supply before cleaning or performing any maintenance.
- Do not attempt to modify the lamp or its electrical components. Any modifications will void the warranty and may pose a safety risk.
- Use only an E27 bulb as specified.
- Keep the power cable away from heat sources, sharp edges, and heavy objects.

3. SETUP

1. **Unpack the Lamp:** Carefully remove all components from the packaging. Ensure all parts are present and undamaged.
2. **Position the Lamp:** Place the floor lamp on a desired stable surface. The lamp is designed for floor mounting.
3. **Install the Bulb:** The lamp comes with an E27 bulb. Carefully screw the provided E27 bulb into the lamp's socket. Ensure it is securely fastened but do not overtighten.
4. **Connect to Power:** Plug the power cable into a standard 220V mains power socket.



Lumisky Standy W150 floor lamp on a balcony overlooking the sea at sunset. This image illustrates the lamp's aesthetic and outdoor placement.



Lumisky Standy W150 floor lamp positioned indoors next to a grey sofa. This image demonstrates the lamp's suitability for indoor use.

4. OPERATING

The Lumisky Standy W150 floor lamp is equipped with a touch switch for easy operation.

- **To Turn On/Off:** Gently touch the designated area on the lamp to switch it on or off.
- **Light Output:** The lamp provides a cold white light with a luminous flux of over 250 Lumens, suitable for ambient or accent lighting.

5. MAINTENANCE

- **Cleaning:** Disconnect the lamp from the power supply before cleaning. The lamp can be easily cleaned with lukewarm water and mild soap. Use a soft cloth and avoid abrasive cleaners or solvents that could damage the finish.
- **Bulb Replacement:** The E27 bulb is changeable. To replace the bulb, ensure the lamp is unplugged from the

power outlet. Unscrew the old bulb and screw in a new E27 LED bulb of appropriate wattage (max 23W).

- **Storage:** If storing the lamp for an extended period, ensure it is clean, dry, and stored in a safe place away from extreme temperatures and direct sunlight.


6. TROUBLESHOOTING

- **Lamp Does Not Turn On:**
 - Check if the power cable is securely plugged into the wall socket.
 - Ensure the wall socket is functional by testing it with another appliance.
 - Verify that the E27 bulb is correctly installed and not faulty. Replace if necessary.
- **Light Flickers:**
 - Check the bulb connection; ensure it is screwed in tightly.
 - Try a different E27 bulb to rule out a faulty bulb.
- **Touch Switch Unresponsive:**
 - Ensure your hands are clean and dry when operating the touch switch.
 - Disconnect and reconnect the power to reset the lamp.

If problems persist, please contact customer support.

7. SPECIFICATIONS

Brand	Lumisky
Model Number	303235
Dimensions (L x W x H)	35 x 35 x 150.01 cm
Item Weight	6.8 kilograms
Bulb Base	E27
Bulb Type	LED
Wattage	23 Watts (Max)
Voltage	220V
IP Rating	IP44 (Splash-proof)
Switch Type	Touch
Material (Base)	Metal
Material (Shade)	Plastic
Color	White
Manufacturer	BATIMEX



Energy label for Lumisky Standy W150, indicating energy efficiency class G and 10 kWh/1000h consumption. For more details, visit the [EPREL database](#).

8. WARRANTY

The Lumisky Standy W150 floor lamp comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for any warranty claims.

9. SUPPORT

For further assistance, technical support, or warranty inquiries, please refer to the contact information provided with your purchase or visit the official Lumisky website.

© 2026 Lumisky. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question