

Maxell 190560

Maxell EB-95 Stereo Earphone User Manual

Model: EB-95 (Part No. 190560)

INTRODUCTION

Thank you for choosing the Maxell EB-95 Stereo Earphones. These earphones are designed to deliver dynamic sound reproduction from various audio sources. Their lightweight and durable plastic design, combined with a convenient 4-foot cord and a silver-plated 3.5mm L-plug, make them ideal for use with smartphones, tablets, laptops, and other portable stereo devices. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your earphones.

SAFETY INFORMATION

Please read and follow these safety guidelines to prevent damage to the earphones or personal injury:

- **Volume Control:** Avoid listening at excessively high volumes for prolonged periods to prevent hearing damage. Start with a low volume and gradually increase it to a comfortable level.
- **Environmental Awareness:** Do not use earphones in situations where the inability to hear ambient sounds could be dangerous, such as while driving, cycling, or walking in traffic.
- **Cleaning:** Use a soft, dry cloth for cleaning. Avoid using liquid cleaners or harsh chemicals.
- **Water Exposure:** These earphones are not water-resistant. Avoid exposure to water, moisture, or extreme temperatures.
- **Disassembly:** Do not attempt to disassemble, modify, or repair the earphones. This will void the warranty and may cause damage.
- **Choking Hazard:** Keep out of reach of small children due to small parts that may pose a choking hazard.

PACKAGE CONTENTS

The Maxell EB-95 Stereo Earphone package typically includes:

- Maxell EB-95 Stereo Earphone (1 pair)

PRODUCT OVERVIEW

The Maxell EB-95 earphones feature a simple and functional design for everyday use.





Figure 1: Front view of the Maxell EB-95 Stereo Earphones, showing the individual earpieces and the cable extending downwards. The left earpiece clearly displays the "Maxell" brand name and an "L" indicator.



Figure 2: Maxell EB-95 Stereo Earphones with the cable coiled, highlighting the 3.5mm L-plug connector. Both earpieces are visible, showing their rounded tips.

- **Earpieces:** Lightweight plastic design with rounded tips for in-ear placement.

- **Cable:** Approximately 4 feet (1.2 meters) in length, connecting the earpieces to the audio source.
- **3.5mm L-Plug:** Silver-plated connector for universal compatibility with most audio devices.

SETUP

Setting up your Maxell EB-95 earphones is straightforward:

1. **Identify Left and Right:** Each earpiece is marked with an "L" for left and "R" for right. Insert the corresponding earpiece into your ear.
2. **Connect to Device:** Locate the 3.5mm audio jack on your smartphone, tablet, laptop, or other portable stereo device.
3. **Insert Plug:** Firmly insert the 3.5mm L-plug of the earphones into the audio jack of your device. Ensure it is fully seated to prevent sound issues.
4. **Adjust Volume:** Before playing audio, set the volume on your device to a low level. Gradually increase the volume to a comfortable listening level once audio begins playing.

OPERATING

Once connected, operating your Maxell EB-95 earphones is simple:

- **Audio Playback:** Play audio from your connected device (music, videos, podcasts, etc.). The sound will be reproduced through the earphones.
- **Volume Control:** Adjust the volume directly on your connected device. These earphones do not feature inline volume controls.
- **Compatibility:** The 3.5mm L-plug ensures broad compatibility with most devices featuring a standard headphone jack.

MAINTENANCE

Proper care will extend the life of your earphones:

- **Cleaning:** Gently wipe the earpieces and cable with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or solvents.
- **Storage:** When not in use, store the earphones in a clean, dry place, away from direct sunlight and extreme temperatures. Avoid tangling the cable by coiling it loosely.
- **Cable Care:** Do not pull the cable forcefully when disconnecting from a device. Always grasp the plug itself. Avoid sharp bends or kinks in the cable.

TROUBLESHOOTING

If you encounter issues with your Maxell EB-95 earphones, try the following solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound or sound from only one side	Plug not fully inserted. Incorrect audio output selected on device. Device volume too low or muted. Damaged cable or plug.	Ensure the 3.5mm plug is fully inserted into the device's audio jack. Check your device's audio settings to ensure output is directed to the headphone jack. Increase the volume on your device and ensure it is not muted. Try the earphones with another device. If the problem persists, the earphones may be damaged.
Distorted or poor sound quality	Loose connection. Audio source quality. Damaged cable or earpiece.	Re-insert the 3.5mm plug firmly. Try playing different audio files or from a different source to rule out source issues. Inspect the cable for visible damage. If damaged, replacement may be necessary.
Earphones fall out easily	Improper fit.	Ensure you are inserting the earpieces correctly into your ears.

SPECIFICATIONS

Feature	Detail
Model Name	Maxell EB-95 Stereo Earphone
Part Number	190560
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack (L-plug)
Frequency Response	23000 Hz
Impedance	32 Ohm
Material	Plastic
Color	Black
Cable Length	Approx. 4 feet (1.2 meters)
Noise Control	None
Water Resistance Level	Not Water Resistant

WARRANTY AND SUPPORT


Maxell products are manufactured to high-quality standards. For information regarding warranty coverage and customer support, please refer to the warranty card included with your purchase or visit the official Maxell website. Keep your proof of purchase for warranty claims.

Online Support: For frequently asked questions, product registration, and additional support resources, please visit the Maxell support page.

Contact Information: Refer to the Maxell website for the most current contact details for customer service.

© 2025 Maxell. All rights reserved. Information in this manual is subject to change without notice.

Documents - Maxell – 190560



[\[pdf\]](#) **Guide Accessories**

PRODUCT GUIDE 2f90c93b675c3a30b9873f9d2566497e static6 arrow aro conversion

d47bd9201108db58a0689daaf891c54d6f091899 |||

PRODUCT GUIDE BLU-RAY DISC MEDIA DISC MEDIA VIDEO TAPE

RECORDABLE AUDIO AUDIO/VIDEO ACCESSORIES COM ... 8 190565 190566

190567 190561 190318 190317 190316 190329 190538 190412 190508 190507

190439 190562 **190560** 190319 190399 190398 190397 UPC CODE 0-25215-

19030-8 36002-2 19158-9 19159-6 19144-2 19031-...

lang:en **score:28** filesize: 6.11 M page_count: 56 document date: 2022-03-25



[\[pdf\]](#)

cdn cnetcontent 9d 55 9d55b9fc 79e5 450c bcd5 3f98bd09206c What Size Driver Needed For Gaming

Headset Do You Need |||

Stereo EB-125s Stereo Ear Buds n Ideal for all portable CD/DVD/Mp3/iPod players n

Light-weight ear ... isotropic Ferrite 0.009mm 7.3mm 95 dB 3dB 3 dB 1 mW 5 mW 20-23,000 Hz Silver Plated 3.5mm L-plug **190560** 0-25215-19024-7 0.5 x 3.5 x 7.25 0.05 lbs 100-25215-19024-4 6 / 7.5 x 10.0625 x 4 0.1...

lang:en **score:11** filesize: 7.01 M page_count: 16 document date: 2009-05-12