

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Smeg](#) /

› [Smeg SF6922NPZ Built-in Electric Oven Instruction Manual](#)

Smeg SF6922NPZ

Smeg SF6922NPZ Built-in Electric Oven Instruction Manual

Model: SF6922NPZ

[Safety Information](#)

[Setup & Installation](#)

[Operating Instructions](#)

[Maintenance &](#)

[Cleaning](#)

[Troubleshooting](#)

[Specifications](#)

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Smeg SF6922NPZ built-in electric oven. Please read these instructions carefully before installation, use, or maintenance. Keep this manual for future reference.

SAFETY INFORMATION

General Safety:

- Ensure the oven is installed by a qualified technician in accordance with local regulations.
- Do not allow children to operate the oven unsupervised.
- The oven surfaces become hot during operation. Avoid contact with heating elements.
- Always use oven mitts when handling hot dishes or accessories.
- Do not store flammable materials in or near the oven.
- Disconnect the appliance from the power supply before any cleaning or maintenance.

Electrical Safety:

- Verify that the voltage and frequency of the electrical supply match the specifications on the appliance rating plate.
- Do not use adapters, multiple sockets, or extension cords.
- If the power cable is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

SETUP & INSTALLATION

The Smeg SF6922NPZ is a built-in electric oven designed for integration into kitchen cabinetry. Proper installation is crucial for safety and performance.

Unpacking

Remove all packaging materials and accessories from the oven. Inspect the appliance for any damage incurred during transit. Report any damage to your retailer immediately.

Installation Requirements

- Ensure adequate ventilation around the oven.
- The cabinet material must be heat-resistant.
- The electrical connection must be accessible after installation.

Mounting Dimensions

Refer to the diagram below for precise installation dimensions. The oven requires a minimum cabinet width and height for proper fitting and ventilation.




Image Description: A technical diagram illustrating the required cutout dimensions for installing the Smeg SF6922NPZ built-in oven. Key measurements include a minimum width of 560mm, a height range of 583-585mm, and overall oven dimensions of approximately 597mm width, 592mm height, and 550mm depth.

The oven dimensions are approximately 59.7 cm (width) x 59.2 cm (height) x 56 cm (depth). The required cabinet opening should accommodate these measurements with appropriate clearances for ventilation.

OPERATING INSTRUCTIONS

Your Smeg SF6922NPZ oven features 10 cooking functions, a Vapor Clean function, and 20 automatic programs, controlled via a large LCD display with touch controls.

Control Panel Overview

The oven is equipped with a touch control panel and an LCD display. Use the touch interface to select functions, set temperatures, and program cooking times.



Dieses Szenebild ist beispielhaft. Alle Informationen entnehmen Sie bitte der Artikelbeschreibung.

Image Description: A Smeg SF6922NPZ built-in oven integrated into a modern kitchen cabinet, showcasing its sleek black finish and touch control panel. The image provides a visual context of the oven within a home environment.

Basic Operation

1. **Switching On:** Press the power button or touch the display to activate the oven.
2. **Function Selection:** Use the touch controls to navigate through the 10 available functions (e.g., conventional, fan-assisted, grill, pizza).
3. **Temperature Setting:** Adjust the temperature between 30°C and 280°C using the dedicated controls.
4. **Timer & Program:** Set the cooking duration using the timer. The programmable timer allows for delayed start and end of cooking. An acoustic signal indicates the end of cooking.

Special Functions

- **Vapor Clean:** A cleaning function utilizing steam. Refer to the Maintenance section for details.
- **Defrost by Time/Weight:** Specific programs for defrosting food based on duration or weight.

- **Leavening:** A function designed for optimal dough rising.
- **Sabbath Mode:** Allows the oven to operate for an extended period without direct user interaction, suitable for religious observances.
- **Pizza Function:** Optimized for baking pizzas, often utilizing the included refractory stone.

Using Accessories

The oven comes with several accessories to enhance your cooking experience:

- 1 deep tray (40 mm)
- 1 traditional enamel tray (20 mm)
- 2 grids with back stop
- 1 tray support
- Refractory stone, pizza peel, and cover (for pizza function)
- 1 full-extension telescopic guide (non-mobile)



Dieses Szenebild ist beispielhaft. Alle Informationen entnehmen Sie bitte der Artikelbeschreibung.

Image Description: A hand using a pizza peel to insert a freshly prepared pizza into the Smeg SF6922NPZ oven. The oven interior and a pizza stone are visible, highlighting the pizza function.



Pizzafunktion - Pizzabacken wie beim Profi - Pizzastein inklusive

Dieses Szenebild ist beispielhaft. Alle Informationen entnehmen Sie bitte der Artikelbeschreibung.

Image Description: A perfectly baked pizza with melted cheese and basil, resting on a round Smeg-branded refractory pizza stone inside the oven. This image demonstrates the result of using the pizza function.



Teleskopauszug (Teil- oder Vollauszug) für maximalen Komfort - Backbleche bequem herausziehen
Dieses Szenebild ist beispielhaft. Alle Informationen entnehmen Sie bitte der Artikelbeschreibung.

Image Description: A close-up view of the telescopic runners inside the oven, showing a baking tray extended for easy access. This feature allows for comfortable handling of hot dishes.

MAINTENANCE & CLEANING

Regular cleaning and maintenance ensure the longevity and optimal performance of your Smeg SF6922NPZ oven.

General Cleaning

- Always allow the oven to cool down completely before cleaning.
- Use a soft cloth and mild detergent for external surfaces. Avoid abrasive cleaners or harsh chemicals.
- The oven interior is enameled. For light soiling, wipe with a damp cloth.
- The full-glass inner door has a smooth surface for easy cleaning.



Die Vollglas-Innentür hat eine glatte Oberfläche und ermöglicht eine einfache Reinigung.
Dieses Szenebild ist beispielhaft. Alle Informationen entnehmen Sie bitte der Artikelbeschreibung.

Image Description: The Smeg oven with its door fully open, highlighting the smooth, full-glass inner surface designed for effortless cleaning. This feature simplifies maintenance of the oven interior.

Vapor Clean Function

The Vapor Clean function uses steam to soften food residues, making them easier to remove. Follow these steps:

1. Pour approximately 200ml of water into the designated cavity at the bottom of the oven.
2. Select the Vapor Clean function.
3. Allow the cycle to complete.
4. Once the oven has cooled, wipe away softened residues with a sponge or cloth.

Removable Protective Cover

The oven includes a removable, dishwasher-safe protective cover for easy cleaning.




Herausnehmbare, spülmaschinenfeste Schutzabdeckung - exklusive Reinigungslösung
Dieses Szenebild ist beispielhaft. Alle Informationen entnehmen Sie bitte der Artikelbeschreibung.

Image Description: A close-up view of a removable protective cover inside the Smeg oven, designed for easy cleaning and maintenance. This cover can be detached and is dishwasher-safe.

Door Maintenance

The oven features a Soft Close door system and triple glazing to maintain low external temperatures.



Geringe Außentemperaturen an der Gerätetür durch 3-fache Thermoverglasung

Dieses Szenebild ist beispielhaft. Alle Informationen entnehmen Sie bitte der Artikelbeschreibung.

Image Description: A visual representation of the Smeg oven door's triple glazing, showing multiple layers of glass. This design ensures low external temperatures during operation, enhancing safety.

TROUBLESHOOTING

Before contacting customer service, please consult the following table for common issues and solutions.

Problem	Possible Cause	Solution
Oven does not turn on.	No power supply; door not closed properly; child lock activated.	Check power connection; ensure door is fully closed; deactivate child lock.
Oven not heating.	Incorrect function/temperature setting; fuse tripped.	Verify settings; check household fuse box.
Uneven cooking.	Food placed incorrectly; oven overloaded.	Ensure proper spacing; avoid overloading; use recommended shelf positions.
Display shows an error code.	Internal malfunction.	Note the error code and contact Smeg customer service.

If the problem persists after attempting these solutions, please contact Smeg customer support.

SPECIFICATIONS

Detailed technical specifications for the Smeg SF6922NPZ Built-in Electric Oven.

Feature	Detail
Model Number	SF6922NPZ
Brand	Smeg
Type	Built-in Electric Oven
Color	Black
Capacity	65 Liters
Dimensions (L x W x H)	59.7 x 56 x 59.2 cm
Weight	44.2 Kilograms
Energy Class	A
Heating Method	Electric
Functions	10 functions (including Vapor Clean, Defrost, Leavening, Sabbath, Pizza)
Control Type	Touch Control, LCD Display
Temperature Range	30°C to 280°C
Door Features	Soft Close, Triple Glazing, Removable Full-Glass Inner Door
Included Accessories	Deep tray, enamel tray, grids, tray support, refractory stone, pizza peel, telescopic guide.

WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Smeg website. Keep your proof of purchase for warranty claims.

Availability of Spare Parts: Information regarding the availability of spare parts is currently unavailable. Please contact Smeg customer service for further details.

Contact Smeg: For technical assistance, service requests, or to inquire about spare parts, please visit the [Smeg official website contact page](#) or refer to the contact details provided in your product documentation.

© 2024 Smeg. All rights reserved.

This manual is for informational purposes only. Smeg reserves the right to make changes to its products at any time.