

[Manuals.plus](#) /

› [RevJams](#) /

› RevJams Active Sport Wireless Bluetooth Headset REV300 User Manual

RevJams REV300

RevJams Active Sport Wireless Bluetooth Headset REV300 User Manual

Model: REV300

1. INTRODUCTION

Thank you for choosing the RevJams Active Sport Wireless Bluetooth Headset. This manual provides essential information for the proper setup, operation, and maintenance of your headset. Please read it thoroughly before use to ensure optimal performance and longevity of your device.



Image 1.1: The RevJams Active Sport Wireless Bluetooth Headset, featuring a blue design with in-ear hooks and an in-line remote.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your product package:

- RevJams Active Sport Wireless Bluetooth Headset
- 3 Sets of ActiveFit Ear Gels (Sizes S, M, L)
- 1 Carrying Case
- USB Charging Cable
- 1 Sizing Clip (for cable adjustment)



Image 2.1: Contents of the RevJams Active Sport headset package, including the headset, three pairs of ear gels, a carrying case, a USB charging cable, and a cable sizing clip.

3. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your RevJams Active Sport headset.

REVJAMS ACTIVE® WIRELESS

BLUETOOTH 4.0 IN-EAR HEADPHONES WITH BUILT-IN MICROPHONE




Image 3.1: Detailed view of the in-line remote control. From top to bottom, it features the Micro USB Charging Port, Volume Down/Next button, Power/Play/Pause/Pair button, Microphone, Volume Up/Previous button, and the Pairing/Power Indicator light.

- **Micro USB Charging Port:** Used for charging the headset battery.
- **Volume Down / Next:** Press to decrease volume. Hold to skip to the next track.
- **Power / Play / Pause / Pair:** Press and hold to power on/off. Press to play/pause music. Hold to enter pairing mode.
- **Microphone:** For hands-free calls.
- **Volume Up / Previous:** Press to increase volume. Hold to go to the previous track.
- **Pairing / Power Indicator:** LED light indicating power status, charging, and Bluetooth pairing.

4. SETUP

4.1. Charging the Headset

1. Connect the supplied USB charging cable to the Micro USB Charging Port on the in-line remote.
2. Connect the other end of the USB cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The LED indicator will illuminate during charging.
4. Charging typically takes approximately 2 hours. The LED indicator will change color or turn off once fully charged.

A full charge provides up to 6 hours of continuous talk or play time and over 150 hours of standby time.

4.2. Fitting the Ear Gels

The headset comes with three sizes (S, M, L) of ActiveFit ear gels designed to lock in and stay secure during physical activity. Proper fit is crucial for comfort and sound quality.

1. Select the ear gel size that provides a snug and comfortable fit in your ear canal.

2. Gently insert the earbud into your ear, rotating slightly until the ear gel hook rests securely in the concha (outer ear bowl).
3. Test the fit by moving your head; the earbuds should remain stable.



Image 4.1: Close-up view of an earbud with an ActiveFit ear gel and the in-line remote, demonstrating the design for secure fit.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

- **Power On:** Press and hold the **Power / Play / Pause / Pair** button for approximately 3 seconds until the LED indicator flashes.
- **Power Off:** Press and hold the **Power / Play / Pause / Pair** button for approximately 3 seconds until the LED indicator turns off.

5.2. Bluetooth Pairing

To connect your headset to a Bluetooth-enabled device for the first time:

1. Ensure the headset is powered off.
2. Press and hold the **Power / Play / Pause / Pair** button for approximately 5-7 seconds until the LED indicator flashes rapidly, indicating pairing mode.
3. Enable Bluetooth on your mobile phone or audio device and search for available devices.
4. Select "RevJams Active" (or similar name) from the list of found devices.
5. Once paired, the LED indicator will flash slowly or turn solid, and you may hear an audible confirmation.
6. If prompted for a password, enter "0000".

The headset will automatically attempt to reconnect to the last paired device when powered on.

5.3. Music Playback

- **Play/Pause:** Press the **Power / Play / Pause / Pair** button once.
- **Volume Up:** Press the **Volume Up / Previous** button.
- **Volume Down:** Press the **Volume Down / Next** button.
- **Next Track:** Hold the **Volume Down / Next** button.
- **Previous Track:** Hold the **Volume Up / Previous** button.

5.4. Call Management

- **Answer Call:** Press the **Power / Play / Pause / Pair** button once when a call comes in.
- **End Call:** Press the **Power / Play / Pause / Pair** button once during a call.
- **Reject Call:** Press and hold the **Power / Play / Pause / Pair** button for approximately 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the **Power / Play / Pause / Pair** button when not on a call.

6. MAINTENANCE

To ensure the longevity and optimal performance of your headset, follow these maintenance guidelines:

- **Cleaning:** Wipe the earbuds and remote with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the headset in the provided carrying case to protect it from dust, moisture, and physical damage.
- **Temperature:** Avoid exposing the headset to extreme temperatures (hot or cold) or direct sunlight for extended periods.
- **Water Exposure:** The headset is designed for sport use but is not fully waterproof. Avoid submerging it in water or exposing it to heavy rain.

7. TROUBLESHOOTING

If you encounter issues with your RevJams Active Sport headset, refer to the following common solutions:

Problem	Possible Cause	Solution
Headset does not power on.	Low battery.	Charge the headset fully.
Cannot pair with device.	Headset not in pairing mode; Bluetooth off on device; device too far.	Ensure headset is in pairing mode (rapid flashing LED). Turn on Bluetooth on your device. Move device closer to headset (within 10 meters).
No sound or poor sound quality.	Volume too low; headset not properly paired; ear gels not fitted correctly.	Increase volume on both headset and connected device. Re-pair the headset. Adjust ear gel fit.

Problem	Possible Cause	Solution
Intermittent connection.	Interference; device too far; obstacles.	Move closer to the connected device. Avoid physical obstructions between headset and device. Avoid areas with strong Wi-Fi or other wireless interference.

8. SPECIFICATIONS

Technical details for the RevJams Active Sport Wireless Bluetooth Headset REV300:

- **Model Number:** REV300
- **Connectivity:** Wireless (Bluetooth 4.0 with AptX Technology)
- **Form Factor:** In-Ear
- **Microphone:** In-line microphone included
- **Noise Control:** Active Noise Cancellation, Sound Isolation
- **Battery Life:** Up to 6 hours play/talk time, 150+ hours standby time
- **Charging Time:** Approximately 2 hours
- **Wireless Range:** Up to 33 feet (10 meters)
- **Product Dimensions:** 4.32 x 8.89 x 13.31 cm
- **Weight:** 136.08 g

ACTIVEFIT[®] EAR GELS
SPECIALLY DESIGNED TO LOCK IN, AND STAY IN, DURING EXTREME CONDITIONS. PERFECT FOR RUNNING, CYCLING AND MORE

IN-LINE REMOTE AND MIC
EASY ACCESS TO CONTROLS FOR VOLUME, SONG SELECTION, PLAY/PAUSE AND TO ANSWER AND END INCOMING CALLS

LIGHTWEIGHT
SUPER LIGHTWEIGHT DESIGN WEIGHS LESS THAN 1 OZ. OFFERS A COMFORTABLE WEIGHTLESS FEEL

BATTERY LIFE
BUILT-IN LITHIUM RECHARGEABLE BATTERY CHARGES FULLY IN 2 HOURS AND OFFERS UP TO 6 HOURS OF CONTINUOUS TALK OR PLAY TIME ON ONE CHARGE

WIRELESS HD SOUND
HIGH QUALITY DRIVERS PRODUCE HIGH DEFINITION AUDIO WITH CRYSTAL CLEAR TREBLE AND DEEP BASS

33 ft[®] BLUETOOTH RANGE
CAN BE USED UP 33 FT. FROM YOUR BLUETOOTH DEVICE. NO WIRES! NO LIMITS!

REVJAMS ACTIVE[®]
WIRELESS HD IN-EAR BLUETOOTH 4.0 STEREO HEADPHONES, WITH IN LINE MICROPHONE

Image 8.1: Overview of key features including ActiveFit ear gels, lightweight design, 6-hour battery life, wireless HD sound, and 33ft Bluetooth range.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official RevJams website. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question