

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Craftmade](#) /

› [Jeremiah 1015C-BNK 5 Light Mini Chandelier User Manual](#)

Craftmade 1015C-BNK

Jeremiah 1015C-BNK 5 Light Mini Chandelier User Manual

Brand: Craftmade | Model: 1015C-BNK

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup & Installation](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Jeremiah 1015C-BNK 5 Light Mini Chandelier. This elegant lighting fixture, part of the Craftmade family of brands, features clear crystal accents and a brushed nickel finish, designed to enhance various indoor spaces. Please read this manual thoroughly before beginning installation or use to ensure proper function and safety.



Figure 1: Jeremiah 1015C-BNK 5 Light Mini Chandelier. This image displays the complete chandelier with its five light sources, brushed nickel frame, and hanging clear crystal accents.

2. SAFETY INFORMATION

Always follow basic safety precautions when installing or using electrical products to reduce the risk of fire, electric shock, and personal injury.

- **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Please check your local laws before purchasing this product.
- Disconnect power at the circuit breaker or fuse box before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Do not exceed the maximum wattage specified for the light bulbs (60 watts per bulb, 120 volts total).

- Ensure the mounting surface can support the weight of the fixture.
- Handle crystal components with care to prevent breakage.
- Keep packaging materials away from children.

3. PACKAGE CONTENTS

Carefully unpack your chandelier and identify all components. Keep all packaging materials until you are sure all parts are present and in good condition. If any parts are missing or damaged, do not attempt to assemble or install the fixture.

- Chandelier Body (Model: 1015C-BNK)
- Mounting Chain
- Canopy/Ceiling Plate
- Mounting Hardware (screws, wire nuts, etc.)
- Clear Crystal Accents (pre-attached or separate for assembly)
- Instruction Manual



Figure 2: Product Configuration Overview. This image illustrates various mini chandelier models, including the 1015C-BNK, highlighting its design and general appearance.

4. SETUP & INSTALLATION

Installation should be performed by a qualified electrician or a knowledgeable individual following all local electrical and building codes.

4.1. Preparation

1. Turn off power at the main circuit breaker or fuse box.
2. Ensure the existing junction box is securely mounted and capable of supporting the fixture's weight (approximately 4 pounds).
3. Gather necessary tools: screwdriver, wire strippers, electrical tape, ladder, safety glasses.

4.2. Mounting the Fixture

1. Attach the mounting bracket to the junction box using the provided screws.
2. Determine the desired hanging length for the chain. Adjust the chain by removing links if necessary.
3. Thread the electrical wires through the chain and canopy.

4. Connect the fixture's ground wire to the house ground wire (usually bare copper or green) using a wire nut.
5. Connect the fixture's neutral wire (usually white) to the house neutral wire (white) using a wire nut.
6. Connect the fixture's hot wire (usually black) to the house hot wire (black) using a wire nut.
7. Carefully tuck all wires into the junction box.
8. Secure the canopy to the mounting bracket, ensuring it sits flush against the ceiling.

4.3. Attaching Crystal Accents and Bulbs

1. If not pre-attached, carefully hang the clear crystal accents onto the designated hooks on the chandelier frame. Refer to the product image for placement.
2. Install five candelabra-base (E12) bulbs, up to 60 watts each (not included). Do not overtighten.



Figure 3: Detail of Light Socket and Crystal. This close-up shows the candelabra-style light socket and the attachment point for the clear crystal accents.

5. OPERATION

Once installed, your Jeremiah 1015C-BNK Chandelier is ready for use.

- **Power On:** Restore power at the circuit breaker.
- **Control:** This chandelier is designed to be controlled by a remote (if supplied with the fixture) or a standard wall switch.
- **Lighting Direction:** The fixture provides up/down light, illuminating both the ceiling and the area below.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your chandelier.

- **Cleaning:**
 - Always turn off the power and allow the fixture to cool before cleaning.
 - Wipe the brushed nickel finish with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
 - For crystal accents, gently wipe with a damp cloth and then dry with a soft, lint-free cloth to maintain their sparkle.
- **Bulb Replacement:**

- Ensure power is off and bulbs are cool before replacing.
- Unscrew the old bulb and screw in a new candelabra-base (E12) bulb, not exceeding 60 watts.
- **Inspection:** Periodically check all connections and mounting hardware for tightness.

7. TROUBLESHOOTING

If your chandelier is not functioning as expected, consult the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Faulty bulb. Faulty wall switch or remote.	Check circuit breaker/fuse. Verify all wire connections are secure (ensure power is off first). Replace bulb with a known good one. Test wall switch or remote.
Lights flicker.	Loose bulb. Loose wire connection. Incorrect dimmer switch (if applicable).	Tighten bulbs. Check wire connections (ensure power is off first). Ensure dimmer switch is compatible with LED/incandescent bulbs.
Humming noise.	Incompatible dimmer switch.	Replace dimmer switch with a high-quality, compatible model.

If the problem persists after trying these solutions, contact customer support or a qualified electrician.

8. SPECIFICATIONS

Feature	Detail
Brand	Craftmade / Jeremiah
Model Name	1015C-BNK
Color	Brushed Nickel (Fixture), Clear (Shade)
Material	Alloy Steel (Fixture), Crystal (Shade)
Style	Traditional
Light Fixture Form	Chandelier
Specific Uses	Ceiling lighting
Indoor/Outdoor Usage	Indoor, Outdoor (Note: "Outdoor" might be a general brand spec, but chandeliers are typically indoor. User should verify for specific installation.)
Power Source	Corded Electric
Control Method	Remote (or wall switch)

Feature	Detail
Finish Type	Finished
Number of Light Sources	5
Voltage	120 Volts
Included Components	1015C-BNK (Chandelier unit)
Embellishment	Crystal
Lighting Method	Up/Down Light
Certification	ETL
Item Weight	3.97 pounds (approx. 4 Pounds)
Product Dimensions	18.05 x 15 x 18.5 inches
Wattage	60 watts (per bulb, max)
Mounting Type	Protruding, Chain Hung
UPC	647881134693

9. WARRANTY & SUPPORT

9.1. Warranty Information

This product is covered by a manufacturer's warranty. Specific details regarding the warranty period and coverage are not provided in this manual. Please refer to the product packaging or contact Craftmade customer support for complete warranty information.

9.2. Customer Support

For technical assistance, missing parts, or warranty inquiries, please contact Craftmade customer support. You can find more information and contact details by visiting the official Craftmade store:

[Visit the Craftmade Store on Amazon](#)

When contacting support, please have your model number (1015C-BNK) and purchase information readily available.




[Craftmade X6611-BNK-LED 11-inch Flushmount LED Light Fixture - Specifications](#)

Detailed specifications for the Craftmade X6611-BNK-LED 11-inch flushmount LED light fixture, including lumens, CRI, dimensions, warranty, and color options. This fixture offers integrated LED lighting with 3000K color temperature and 90 CRI.




[Bionik Power Stand Pro for Xbox Series XS User Guide](#)

Comprehensive user guide for the Bionik Power Stand Pro, detailing setup, charging of smartphones and Xbox Series XS controllers, and usage of Quickshot Pro trigger grips. Includes care, maintenance, and FCC information.



[Bionik Power Stand Pro for PS5 User Guide](#)

This guide provides instructions for the Bionik Power Stand Pro for PS5, including setup, charging a smartphone, and charging DUALSENSE controllers. It also covers the use of Quickshot Pro trigger caps and care instructions.




[Bionik NeoGlow Controller User Guide](#)

User guide for the Bionik NeoGlow Controller, detailing button layouts, setup for Nintendo Switch, PC, and Android, color modes, charging, and warranty information.



[Bionik VULKAN Gaming Controller User Manual - BNK-9046 Setup & Guide](#)

Comprehensive user guide for the Bionik VULKAN gaming controller (BNK-9046). Includes setup instructions, connectivity options for PC and Android, button mapping, FAQ, and maintenance tips.



[BWE Shower Panel System Installation and Mounting Guide](#)

Comprehensive instructions for installing and mounting a BWE shower panel system, including component lists, step-by-step installation procedures, and essential safety warnings.